


Operating instructions for actuators type AB with SMARTCON control unit



Contents

Contents	2
Operating instructions for actuators type AB with SMARTCON control unit	4
1 Introduction/Notes	4
2 General	4
2.1 Overview	4
2.2 Serial number and nameplate	5
2.3 Operating mode	5
2.4 Protection class	6
2.5 Mounting position	6
2.6 Direction of rotation	6
2.7 Protection devices	7
2.7.1 Electromechanical protection devices	7
2.7.2 Electrical protection devices	7
2.8 Ambient temperature	7
2.9 Delivery condition of the actuators	7
2.10 Information notice (tag)	8
3 Packaging, transport and storage	8
3.1 General	8
3.2 Storage	8
3.3 Long-term storage	9
4 Installation Instructions	9
4.1 Mechanical Connection	9
4.2 Electrical connection	10
5 Commisioning	12
5.1 General	12
5.2 Switching the actuator to manual operation	12
5.3 Mechanical default settings, preparation	13
5.4 Adjustment of the mechanical position indication (Option)	14
5.5 Additional components (Option)	14
5.6 Parameterize of the SMARTCON control unit	14
5.7 End limit setting	14
5.7.1 End limit OPEN	14
5.7.2 End limit CLOSE	17
5.8 Final works	17
6 Control unit	18
6.1 Operating unit	18
6.2 Display elements	19
6.2.1 Graphic display	19
6.2.2 LED Display	19
6.3 Operation	20
6.3.1 Operation mode	21
6.3.2 Configuration	21
6.3.3 Configuration example	22
6.3.4 "TEACHIN"	23
7 Parameter menu	24
7.1 Parameter group: End limit	24
7.2 Parameter group: Torque	25
7.3 Parameter group: Speed (option)	26
7.4 Parameter group: Ramp (optional)	27
7.5 Parameter group: Control	27
7.6 Parameter group: Password	27

7.7	Parameter group: Position	28
7.8	Parameter group: Binary inputs	28
7.9	Parameter group: Binary outputs	30
7.10	Parameter group: Position output (option)	34
7.11	Parameter group: Step mode	34
7.12	Parameter group: Positioner (option)	35
7.13	Parameter group: PID controller (optional)	37
7.14	Parameter group: PROFIBUS DP (option)	39
7.15	Parameter group: DeviceNet (option)	39
7.16	Parameter group: Characteristic curves (optional)	39
7.17	Parameter group: Identification (optional)	41
7.18	Parameter group: System parameters (locked)	41
7.19	Parameter group: Miscellaneous	41
8	Status area	42
8.1	Status	42
8.1.1	Status – Bin. Outputs	42
8.1.2	Status – Bin. Inputs	42
8.1.3	Status – Analogue values	42
8.1.4	Status – Absolute values	43
8.1.5	Status – Firmware	43
8.1.6	Status – Serial number	43
8.2	History	43
9	Infrared connection	43
10	Maintenance	44
11	Troubleshooting	45
11.1	Error list	45
12	Fuses	45
13	Spare parts	47
14	Recommendations of Lubricants (for all manufactures)	47
14.1	Main Casing	47
14.1.1	Application temperature from -35°C to +100°C	47
14.1.2	Application temperature from -50 to +100 °C	47
14.1.3	Application temperature from -60 to +100 °C	47
14.2	Spur Gears (actuator size AB8 - AB80)	48
14.3	Output Drive Type A and Spindle Drive (Linear Actuators)	48
14.4	Precision Components	48
14.5	Basic Lubricant Service Interval	48
14.6	Lubricant Requirements	49
15	Training	49
16	Original Declaration of Incorporation of Partly Completed Machinery	50
17	Declaration of Conformity	51
18	Declaration of Conformity	52
19	Technical data	54
19.1	Binary inputs	54
19.2	Binary outputs	54
19.3	Analogue inputs	54
19.4	Analogue outputs	54
19.5	Auxiliary voltage input and output	55
19.6	Mechanic reversing starters	55
19.7	Elektronic reversing starter	56
19.8	Power supply	56
19.9	Connections	57
19.10	Miscellaneous	57

Operating instructions for actuators type AB with SMARTCON control unit

1 Introduction/Notes

These operating instructions apply to SCHIEBEL actuators of the type AB with integrated SMARTCON control unit.

The scope of application covers the operation of industrial valves, e.g., globe valves, gate valves, butterfly valves and ball valves. For other applications please consult with the factory.

The manufacturer shall not be liable for incorrect use and possible damage arising thereof. The risk shall be borne solely by the user.

Using the unit as intended also entails the observance of these operating instructions!



When operating electrical equipment, certain parts inevitably carry hazardous voltage levels. Work on the electrical system or equipment must be carried out only in accordance with electrical regulations by a qualified electrician himself or by specially instructed personnel under the control and supervision of a qualified electrician.

Maintenance instructions must be observed as otherwise the safe operation of the actuator cannot be guaranteed.

Failure to follow the warning information may result in serious bodily injury or property damage. Qualified personnel must be thoroughly familiar with all warnings contained in this operating manual.

Proper transport, storage, installation, assembly and careful commissioning are essential to proper and safe operation.

When working in potentially explosive areas, observe the European Standards EN 60079-14 "Electrical Installations in Hazardous Areas" and EN 60079-17 "Inspection and Maintenance of Electrical Installations in Hazardous Areas".



Maintenance work on open actuators may only be conducted if these are de-energized. Reconnection during maintenance is strictly prohibited.



2 General

2.1 Overview




Figure 1: 1... Motor, 2... Connection compartment, 3... SMARTCON control unit, 4... Operating unit, 5... Handwheel, 6... Signalling lid, 7... Lever for manual operation

2.2 Serial number and nameplate

Each actuator and each SMARTCON control unit carries a serial number. The serial number is a 8-digit number that begins with the year and that can be read from the nameplate (see Figure 2 and 3)

The nameplate of the actuator is located under the hand lever and the nameplate of the SMARTCON control unit is located on the control unit (see Figure 4).

Using this serial number, SCHIEBEL can uniquely identify the actuator (type, size, design, options, technical data and test report).




Figure 2: nameplate of the actuator




Figure 3: nameplate of the SMARTCON control unit




Figure 4: 1... nameplate of the SMARTCON control unit, 2... nameplate of the actuator

Actuators which are suitable for operation in explosive atmosphere (see EU-Richtlinie 94/9/EG and EN60079-0 Standard) are separately designated by a special model plate (Ex, TÜV-Standard, see Figure 5 and 6).




Figure 5: nameplate of the actuator for operation in explosive atmosphere




Figure 6: nameplate of the SMARTCON control unit for operation in explosive atmosphere

2.3 Operating mode

There are two distinct modes of operation: open-loop control operation (operational mode S2 for ON-OFF) and closed-loop control operation (operational mode S4) according to EN 60034-1. But since there is a great number of varying and special models made to order, it is recommended to consult the motor model plate for the mode of operation and the running time.

2.4 Protection class

Actuators with three-phase motors are standardly equipped with the IP 66 protection system (according to DIN-Standard 40050). **Explosion-proof** actuators and actuators with plugs are furnished with the IP 65 protection system. Exceptions are the AC, DC and brake-motor actuators as well as those for other protection systems made to special order.

CAUTION: The protection class specified on the nameplate is only effective when cable glands also provide the required protection class, the cover of the connection compartment is carefully screwed and the mounting position (see section 2.5, page 6) is observed.



We recommend metallic screwed cable glands with a metrical thread. Furthermore, cable inlets not be needed must be closed with screw plugs. On explosion-proof actuators cable glands with protection class



EEx e according EN60079-7 must be used. **After removing covers** for assembly purposes or adjustment work, take special care upon reassembly so that seals are not damaged and remain properly fastened. Improper assembly may lead to water entrances and to failures of the actuator.

Allow a certain sag in the connector cables before reaching the screwed cable glands so that water can drip off from the connector cables without running to the screwed cable glands. As a result, forces acting on the screwed cable glands are also reduced. (see section 2.5)

2.5 Mounting position

In principle, the installation position is irrelevant. However, based on practical experience, it is advisable to consider the following for outdoors use or in splash zones:

- Mount actuators with cable inlet facing downwards
- Do not arrange the motor so that it hangs downwards
- Ensure that sufficient cable slack is available

2.6 Direction of rotation

Unless specifically ordered otherwise, the standard direction is (see Figure 7 and Figure 8):

Clockwise rotation = Close

Counter-clockwise rotation = Open

Clockwise rotation of the actuator is given when the output shaft turns counter clockwise when looking on the output shaft.




Figure 7: AB3 - AB80




Figure 8: AB100 - AB500

All data in these operating instructions refer to the standard rotating direction.

2.7 Protection devices

2.7.1 Electromechanical protection devices

The torque protection of the actuators with integral SMARTCON control unit is controlled mechanically by plate springs which pass the current torque through a conductive plastic potentiometer to the control unit.

The switch off torque can be changed in the menu of the control unit for the left and right direction. The factory default switch off torque is set to the ordered torque. If no torque was specified in the order, the actuator is supplied from the factory with the maximum adjustable torque.

See also section 7.2, page 25

2.7.2 Electrical protection devices

All motors have temperature switches as standard equipment (temperature sensors upon special order), which are wired into the control and protect the motor from overheating.

In the housing of the connection plug super fast safety fuses are located to protect the integrated thyristors (electronic reversing contactors).

Further we recommend the installation of a motor protection circuit breaker on site as additional protection for rapid engine warming up (block). The tripping current must be adjusted to 1.2 . . . 1,5-times of the motor current, or at explosion-proof models proceed according to the corresponding guidelines of the National Explosion Protection Authority.

2.8 Ambient temperature

Unless otherwise defined according to special order, the following operational temperature generally applies:

- open-loop control actuators from -25°C to +70°C
- closed-loop control actuators from -25°C to +60°C
- Explosion-proof actuators from -20°C to +40°C (according to EN60079-0 Standard).

Warning: The maximum operational temperature also depends on the built-in components. Please observe the technical data sheets.

2.9 Delivery condition of the actuators

For each actuator, an inspection report is generated upon final inspection. In particular, this comprises a full visual inspection, calibration of the torque measurement in connection with an extensive run examination and a functional test of the micro controllers.

These inspections are conducted and documented according to the quality system and can be found in the document gag (mounted on the handwheel).

The basic setting of the end position must be performed after assembly on the actuator.

CAUTION: Commissioning instructions (see section 5, page 12) must be strictly observed!

During assembly of the supplied valves at the factory, end positions are set and documented by attaching a label (see Figure 9). During commissioning at the plant, these settings must be verified.




Figure 9: Label

2.10 Information notice (tag)

Each actuator is provided with a bilingual tag containing key information, which is attached to the handwheel after final inspection. This tag also shows the internal commission registration number (see Figure 10)




Figure 10: tag

3 Packaging, transport and storage

You can order the actuators to be delivered with or without packing. Special packing requirements must be specified along with your order. Use extreme caution when unpacking or repacking the actuator.

Use soft belts for hoisting equipment. Do not attach hoisting belts to the handwheel.



3.1 General

The indicator lids of all actuators contain a minimum of 5 g of silica gel ex factory.

WARNING! Prior to start-up of the actuator (refer to section 5, page 12) all of the silica gel must be removed!



3.2 Storage

CAUTION

Observing the following precautions will help to avoid damage when storing actuators:

- Store actuators in well-ventilated, dry premises
- Protect against floor dampness by storing actuators on wooden grating, pallets, mesh boxes or shelves
- Protect the actuators against dust and dirt with plastic foil
- Actuators must be protected against mechanical damage. It is not necessary to open the controller of the actuator for servicing batteries or similar operations.
- The storage temperature must be between -20°C to $+40^{\circ}\text{C}$

It is not necessary to open the controller of the actuator for servicing batteries or similar operations.

3.3 Long-term storage

CAUTION: If you intend to store the actuator for over 6 months, follow additionally the instructions below:



- **CAUTION:** The silica gel in the connection compartment must be replaced after 6 months of storage (from date of delivery from SCHIEBEL's factory in Vienna)
- After replacing the silica gel, brush with glycerine the connection cover seal. Then, carefully close again the connection compartment
- Coat screw heads and bare spots with neutral grease or long-term corrosion protection
- Renovate damaged paintwork arising from transport, improper storage, or mechanical influences.
- Wrap the motor (especially the brake motor) with oiled paper.
- Every 6 months, all measures and precautions for long term storage must be checked for effectiveness and corrosion protection and silica gel renewed.
- Failure to follow the above instructions may lead to condensation which can damage to the actuator.



4 Installation Instructions

Installation work of any kind of actuator may only be performed by qualified personnel.

4.1 Mechanical Connection

Make sure that the fitting flanges and the actuator flanges match each other, and that the borehole matches the shaft or, in the case of actuator model "A"(threaded bushing), that the actuator and fitting threads match each other.

- Grease the spindle.
- Clean all exposed parts which have been coated with anti-corrosive.
- Thoroughly clean the bolting surfaces of the fittings.
- Lightly grease the connecting joints between the actuator and the fittings.
- Place the actuator on the fittings or the gear.
- Tighten the fastening screws crosswise (torque acc. below table).

size	torque [Nm] for screws 8.8
M6	10
M8	25
M10	48
M12	84
M16	206
M20	415

For output type A (unbored threaded bushing), you must sufficiently lubricate both needle bearings in the output form after processing and cleaning the spindle nut.

For this purpose, use the optional SCHIEBEL grease lubricant or a grease lubricant according to our recommendation (section 14, page 47).



4.2 Electrical connection

Electrical connections may only be carried out by qualified personnel. Please observe all relevant national security requirements, guidelines, and regulations. The equipment should be de-energized before working on electrical connections. Furthermore, confirm the absence of electrostatic discharges during the connection. First of all, connect the ground screw.



The line and short circuit protection must be done on the system side. The ability to unlock the actuator is to be provided for maintenance purposes. For the dimensioning the rated current is to be used (see Technical Data).



Check whether the power supply (voltage, frequency) is consistent with the connection data (see name plate of the motor)

The connection of electrical wiring must follow the circuit diagram.

This can be found in the appendix of the documentation. The circuit diagram can be ordered from SCHIEBEL by specifying the serial number.



The standard model can be ordered with the following connection options:

- size 1: connection of the control signals and power supply via plugs (see Figure 11) with screw connection.
- size 2: connection of the control signals is the same as size 1, the connection of the power supply is made by an additional plug (see Figure 13), both plugs aer with screw connection.
- **Explosion-proof actuators** or on special request the connection will be made via terminals (see Figure 12).




Figure 11: 1...metallic cable glands (closed with blind screw connections at delivery) M32x1,5, 2... M40x1,5, 3... M25x1,5, 4... plug Han6E (for power supply), 5... plug Han24E (for control signals), 6... plug for options, 7... connection plug plate, 8... connection plug housing




Figure 12: 1... connection plug housing, 2... terminal strip, 3... inside ground connection, 4... metallic cable glands (closed with blind screw connections at delivery) M40x1,5, 5... M32x1,5, 6... M25x1,5, 7... outside ground connection




Figure 13: size 2 with the additional plug

3 phase power is applied in positive turning direction of the electric field on the connectors L1, L2, L3 according the wiring diagram.

Before starting the actuator the turning direction of the electronic field should be checked.

NOTE: If phase sequence of the three phase power supply system is wrong the integrated phase sequence monitoring generates an error and the actuator is blocked. (see section 7.1, page 24)



If you need a reverse rotation of the actuator (ccw) you must change this in the control unit (section 7.1, page 24).

Please also note the information about the installation of an external motor protection circuit breaker - see section 2.7.2, page 7.



If, during outdoor installation, commissioning is not carried out immediately after electrical connection, the power supply must be connected at a minimum to achieve a heating effect. In this case, the silica gel may remain in the connection compartment until commissioning.

CAUTION: see section 3.3, page 9

5 Commissioning

Before commissioning, please ensure the actuator is correctly assembled and electrically connected. (see section 4, page 9)

CAUTION: Remove silica gel from the connection compartment

5.1 General

CAUTION: During commissioning and after every disassembly of the actuator, you have to make the mechanical preadjustment (see section 5.3, page 13), adjust the mechanical position indication (see section 5.4, page 14), adjust the additional components (see section 5.5, page 14) and adjust the end positions (see section 5.7, page 14).



ATTENTION: The torque unit is adjusted at work and **must not** be changed.






Figure 14: 1... torque unit , 2... hand lever, 3... heating resistor - **Attention: HOT!!!**, 4... gearing of travel unit, 5... potentiometer for travel sensing, 6... mech. position indicator (option)

5.2 Switching the actuator to manual operation

The actuator is switched to manual operation by moving the hand lever (see Figure 15 u. 16) by approximately 15°, and by simultaneously turning the hand wheel. The lever remains in this position and will be switched back automatically as the motor starts up.

WARNING:

- When switching to manual operation, the actuator's **automatic interlock is deactivated**, that means that the driven valve must not initiate reverse torque to the output shaft of the actuator! 
- Switching back to motor operation is made **automatically** as the motor starts up. It **must not** be undertaken with the hand lever! 
- Only switch to manual operation when the motor is idle!
 - Hand lever has a slewing angle of approximately 15°, therefore release the hand lever immediately upon activation!

Labels on the actuator:



Figure 15: AB3, 5, 100, 200, 500




Figure 16: AB8, 18, 40, 80

5.3 Mechanical default settings, preparation

Instructions:

- Switch with the hand lever to manual operation (see section 5.2, page 12) and turn the actuator with the handwheel to the next end position
- Remove cover of the signalling unit
- Switch with the control switch (black switch) to the status menu S4 (see section 8.1.4, page 43)
- For units without mechanical position indicator turn the slotted shaft (see Figure 17) with a screwdriver carefully until the below value is reached (see Figure 20)
 - when the actuator in in the closed position: Pos: 10.0
 - when the actuator is in the open position: Pos: 90.0
- For units with mechanical position indicator turn the wheel (see Figure 18 and Figure 19) until the below value is reached (see Figure 20)
 - when the actuator in in the closed position: Pos: 10.0
 - when the actuator is in the open position: Pos: 90.0
- Close cover of the signalling unit. Take special care upon reassembly so that seals are not damaged and remain properly fastened




Figure 17: 1... potentiometer for position sensing, 2... slotted shaft for turning the potometer




Figure 18: 1... mechanical position indicator




Figure 19: 1... mechanical position indicator, 2... wheel turning the potentiometer




Figure 20: 1... absolute value of the position unit, 2... value for the torque unit (is factory adjusted)

For the set up of the end positions see section 5.7, page 14.

The above transmitter gear is made according to the customer's specifications. If another travel of the actuator is necessary, a new transmitter gearbox can be supplied.

5.4 Adjustment of the mechanical position indication (Option)

The adjustment of the mechanical position indication should be done together with the mechanical pre-setup. Vorgehensweise:

- Switch with the hand lever to manual operation (see section 5.2, page 12) and turn the actuator to the next end position.
- Remove cover of the signalling unit
- turn Indicator slide according below end position:
 - when the actuator in in the closed position: Display with the filled circle
 - when the actuator is in the open position: Display with the circle
- move the actuator to the other end position and turn the other Indicator slide. It is necessary that you hold the second slide in its earlier set position.
- Check the clamping screw
- Close cover of the signalling unit. Take special care upon reassembly so that seals are not damaged and remain properly fastened

5.5 Additional components (Option)

Possibly installed additional components have to be set-up according their separately supplied technical descriptions.

5.6 Parameterize of the SMARTCON control unit

After finishing the pre-setup of teh actuator (see section 5.3, page 13) all further settings can be done via the SMARTCON interface.

WARNING: It is absolutely necessarily to control the torque settings of the actuator and to teach in the end positions of the travel.



5.7 End limit setting

A detailed description of the operation of the SMARTCON control unit can be found in section 6.3, page 20.

5.7.1 End limit OPEN

Set the selector switch and control switch to the centre position.




Figure 21: 1... selector switch (red), 2... control switch (black)

Scroll through the menu with the control switch. Move the control switch towards the first menu item ⊖ „P 1.1 End limit – Open“.



Figure 22



Figure 23

Afterwards, flip up the selector switch slightly and let it snap back to its neutral position ✓



Figure 24



Figure 25



Figure 26

This changes the bottom line of the display from "EDIT?" to "SAVE?"



Figure 27



Figure 28

Then, push down the selector switch until it snaps into place. In doing so, the bottom right now on the display will show "TEACHIN" (⊗)

CAUTION: Once the display shows "TEACHIN", use the operating switch (black switch) to start the motorised operation of the actuator. In this mode, no travel-dependent switch off occurs in the end position.



CAUTION: Please note that, during motor operation, only torque monitoring remains active, as travel adjustment will happen subsequently. Therefore, please check beforehand whether the maximum torque has been already parameterised



Absolute and relative values on the display will change continuously along with position changes.



Figure 29



Figure 30

Manually move the actuator with the handwheel (see section 2.1, page 4 or 2.6, page 6) or by motor via the operating switch (black button) to the end position OPEN of the valve.

- Absolute value: Absolute value of the position feedback
- Relative value: the value to the other end position



Figure 31: 1... Absolute value, 2... Relative value

When the desired end position OPEN of the valve is reached, move the selector switch back to the middle position. Thus, the line "TEACHIN" disappears.



Figure 32



Figure 33

In order to confirm the end position (save), slightly flip up the selector switch and let it snap back to its neutral position ✓




Figure 34



Figure 35




Figure 36

This changes the bottom line of the display for "SAVE?" to "EDIT?" and the end position is stored.



Figure 37



Figure 38

5.7.2 End limit CLOSE

Use menu item "P 1.2 End limit - End limit CLOSE" as for End limit OPEN

5.8 Final works

Following commissioning, check for proper sealing the covers to be closed and cable inlets. (see section 2.4, page 6) Check actuator for paint damage (by transport or installation) and repair if necessary.

6 Control unit

The controller is intended to monitor and control the actuator and provides the interface between the operator, the control system and the actuator.

6.1 Operating unit

Operation relies on two switches: the control switch and a padlock-protected selector switch. Information visualization is provided by 4 integrated indicator lights, as well as the graphic display. For better visibility, switch symbols (✓, ✗, ⊕, ⊖) are on the cover




Figure 39: 1... Selector switch, 2... Control switch, 3... Graphic display, 4... Infrared interface

The controller switches serve on the one hand for electric-motor operation of the actuator and, on the other hand, to configure and view various menu items.

The controller cover may be wiped clean with a damp cloth.

6.2 Display elements

6.2.1 Graphic display

The graphic display used in the controller allows text display in different languages.



Figure 40

During operation, the displays shows the position of the actuator as a percentage, operation mode and status. When using the option "identification", a customer-specific label is shown at the bottom of the display (e.g., PPS Number).




Figure 41: 1... Status, 2... Operation mode, 3... Position

6.2.2 LED Display

To provide users with better status information, basic status data is displayed using 4-colour LEDs. As the device powers up, it undertakes a self-test whereby all 4 LEDs briefly lit up simultaneously.




Figure 42

Description	Colour	Lits up	Flashes quickly	Flashes slowly	off
L1 ¹⁾	red	Open	Run OPEN	applies to torque-dependent Opening: Occurs when the end position OPEN is reached but the switch off torque is not attained	Actuator is not in the OPEN position
L2 ¹⁾	green	Closed	Run CLOSED	applies to torque-dependent closing: Occurs when the end position CLOSED is reached but the switch off torque is not attained	Actuator is not in the CLOSED position
L3	yellow	No torque fault	Torque fault	—	—
L4	yellow	Ready (operational readiness)	Travel error (No operational readiness!)	—	Error (no operational readiness) motor temperature, no supply voltage, internal fault

6.3 Operation

The actuator is operated via the switches located on the controller (selection- and control switch). All actuator settings can be entered with these switches. Furthermore, configuration is also possible via the IR interface (see section 9, page 43). Flip the switch up or down to regulate the parameter menu scrolling speed.



Figure 43: Neutral position



Figure 44: Slight switch flip (it will move to the next parameter)



Figure 45: halfway switch flip (it will jump to the next parameter category)





Figure 46: Full switch flip (it will jump to the end of the menu)

¹⁾LED L1 and L2 can be changed by parameter P1.7 - see section 7.1, page 24.

6.3.1 Operation mode



Use the selector switch (red) to determine the various operating states of the actuator. In each of these positions, it is possible to block the switch by means of a padlock and thus protect the actuator against unauthorized access.

The selector switch has the following positions:

OFF	The actuator can be neither operated via the remote control nor via the control switches of the controller.
Local 	It is possible to operate the actuator by motor via the control switch. Control via the remote inputs may be possible with appropriate configuration (superimposed control commands, emergency commands)
Remote 	The actuator is ready to process control commands via input signals. The control switch for the motor operation of the actuator is not enabled.

Besides defining the operational status, the selector switch is used in configuration mode to confirm or cancel parameter inputs.

Depending on the selector switch position, the control switch performs different functions:

Selector switch in the OFF position:	The control switch is used to scroll up or down the menu according to internal symbolism. From the neutral position towards \oplus you reach the status and history data areas. Towards the \ominus symbols you reach the parameter menu. Here, the selection switch either confirms \checkmark or rejects \otimes the current input according to associated symbolism.
Selector switch in the REMOTE position 	The control switch gives you access to status, history data and parameter area.
Selector switch in the LOCAL position 	With the control switch, the actuator can be operated by motor. You may also operate the actuator in inching and self-hold mode. Switches are spring-loaded to snap back automatically into their neutral position. (To confirm a control command, the control switch must be pushed all the way into its mechanical locking position.)

6.3.2 Configuration

In principle, all parameters are shown as numbers in the corresponding parameter point. From the actuator menu, use the control switch to access different menu points. The lower left corner of the display shows the "EDIT" option.




Figure 47

Confirm the selector switch (with a slight flip towards \checkmark , (see Figure 34, page 17 to Figure 36, page 17) to change the selected parameter. To confirm this input readiness, the display changes from "EDIT" to "SAVE".



Figure 48

Use the control switch towards to the characters to change the parameter. \oplus or \ominus (see Figure 43 til Figure 46,

page 20) After reaching the desired parameter value, confirm the value with the selector switch (again, flip it slightly towards , (see Figure 34, page 17 til Figure 36, page 17).

6.3.3 Configuration example

By way of example, we will change parameter P20.6 (infrared) from 0 (infrared communication off) to 1 (Infrared communication on). Thus, the IR connection is activated for a short time and then deactivated again automatically:

The operating and control switch must be in the neutral position




Figure 49: 1... Selector switch (red) , 2... Control switch (black)


Now, move the control switch down (towards ) until the menu item "P 20.6 Miscellaneous - Infrared" is displayed.



Figure 50



Figure 51

Afterwards, flip up slightly the selector switch (towards ) and let it snap back to its neutral position



Figure 52



Figure 53



Figure 54

This changes the bottom line of the display from "EDIT?" to "SAVE?"



Figure 55



Figure 56

Thereafter, flip up the control switch (toward) to change the value from 0 (off) to 1 (on)



Figure 57



Figure 58

If the value changes to 1, confirm the selection by flipping halfway up the selector switch (towards) and letting it snap back to its neutral position (see Figure 52 til Figure 54).



Figure 59



Figure 60

This changes the bottom line of the display from "SAVE?" to "EDIT?" and the parameter is stored.

6.3.4 "TEACHIN"

Furthermore, certain parameters (end positions, intermediate positions).can be set using "TEACHIN". Thus, their configuration is greatly simplified.

After selecting the appropriate menu item (for example: End position) and changing the the input type from "EDIT?" to "SAVE?", move the selector switch (red) to "manual mode" and lock it into place. As you do so, the display will show the message "TEACHIN" and the current position value will be applied continuously to the parameter value. In this mode, further to manual operation by hand wheel, the actuator can be motor-driven with the control switch to the desired position. (see section 5.7.1, Figure 30, page 16)



Figure 61

CAUTION: Please note that, during motor operation, only torque monitoring remains active, as travel adjustment will happen subsequently. Therefore, please check beforehand whether the maximum torque has been already set.



After reaching the desired, to-be-defined position, move the selector switch back to the neutral position. Finally,

the parameter value must still be saved by flipping the selector switch halfway up and letting it snap back to the neutral position (see Figure 52 til Figure 54, page 22).

7 Parameter menu

For each parameter group, you can find a description, tabular overview of the menu items and possible configurations. The parameter list below also includes all possible options per menu item. Please note that some of the menu items listed and described may not be delivered with your configuration.

7.1 Parameter group: End limit

These parameters are used to configure the end position and switch off behavior of the actuator. In this regards, it is important to ensure that the basic mechanical configuration described in section 5.3, page 13 and section 5.7, page 14 has already been made.

Ensure that these parameters are set during commissioning before operating the actuator. In addition, the settings in the "Torque" menu (see section 7.2, page 25 must be compared with the permissible values of the valve and corrected as appropriate)

CAUTION: Generally, 100% stands for fully open and 0% for fully closed. Please note that these values cannot be changed.



	menue item	sub menue item	poss. setting	notes / comments
P1.1	End limit	Open	TEACHIN; 0 - 100%	The parameter value can be set using TEACHIN. With a known travel, the second end position can be entered after setting the first end position
P1.2	End limit	Close	TEACHIN; 0 - 100%	The parameter value can be set using TEACHIN. With a known travel, the second end position can be entered after setting the first end position
P1.3	End limit	Switch off Open	by travel (0)	The actuator uses end-position signals to switch off and report the end position
			by torque (1)	The actuator signals the end position or stops the motor only after reaching the specified torque with the proviso that it has reached the end position. If the end position signal is not reached, the actuator reports an error
P1.4	End limit	Switch off Close	by travel (0)	The actuator uses end-position signals to switch off and report the end position
			by torque (1)	The actuator signals the end position or stops the motor only after reaching the specified torque with the proviso that it has reached the end position. If the end position signal is not reached, the actuator reports an error
P1.5	End limit	Closing directing	right (0)	Actuator is designed for clockwise = closing
			left (1)	Reverse direction of rotation! Counterclockwise = closing. The crossing of all signals and commands is performed by the controller
P1.6	End limit	Rot. sense pos.	0	Rotation sense of the Potentiometer
			1	

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / Comments
P1.7	End limit	Led function	Close=green (0)	Definition of the LED colour of the CLOSED or OPEN end position signalization
			Close=red (1)	
P1.8	End limit	End limit hyst.	0,1 - 10,0%	Hysteresis range for end position signals: Example: End position hysteresis 1% means, that the End position OFF is reached when closing 0%, and will leave it when opening only at 1%, i.e., a re-closing can only take place after leaving this hysteresis.
P1.9 ¹⁾	End limit	Endlimit ramp	1 - 100% {10%}	No function for actuators with fixed speed (Smartcon CSC) For variable speed actuators (Actusmart CM und Smartcon CSC FU): Speed limitation just before reaching the final end position. The endlimit ramp refers to the absolute position value and the max. adjustable speed. If the speed is already reduced, the influence of the ramp is retarded. With the steepest ramp (100%) the speed is limited just 0,1% _{absolut} before the final end position, with a ramp of 10% at 1% _{absolut} and with 1% even at 10% _{absolut} before the final end position.

CAUTION: When installing the actuator on an gear or a thrust unit, please take into account the limits and factors of the gear / thrust unit at parametrization.



When using end limit switch off by torque, the end position limit must be set before reaching the torque limit. Accordingly, the actuator will only signal the final end position if the configured torque and the associated end position are reached. If the end position is not reached, a torque error is reported (see section 6.2.2, page 19)

7.2 Parameter group: Torque

If no torque was specified with the order, the actuator is supplied from the factory with the maximum configurable torque.

	menue item	sub menue item	poss. setting	notes / comments
P2.1	Torque	Open	40 - 100%	Switch off torque in OPEN direction CAUTION: The range can be restricted via the menu item P2.3
P2.2	Torque	Close	40 - 100%	As P2.1 but in CLOSED direction
P2.3	Torque	Torque limit	40 - 100%	Torque to protect the valve, the transmission or the thrust unit. This value limits the setting of the Parameters P2.1 and P2.2 and to prevent an erroneous increase above the allowed value of these two parameters.
P2.4	Torque	latching	{off (0)}	For self locking actuators

continued on next page

¹⁾from Firmware 1.341

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / Comments
			on (1)	If the adjusted torque is reached the actuator cannot drive into the same direction. You must first drive the actuator in the other direction. That means that a reduction of the torque after a torque switch off, the actuator will not drive into the same direction. That is necessary for non self locking actuators
P2.5	Torque	Boost Open	0 – 120% {0%}	Increase the torque during motor start (approx. 0.5 sec) in direction OPEN. On large flywheel masses a unwanted shut off can be avoided. Furthermore, break free effect can thus be achieved. When setting values are less than the switch off torque in OPEN direction (P2.1) there will be no torque increasing during motor start. The torque increase should occur only if the valve is designed for it!
P2.6	Torque	Boost Close	0 – 120% {0%}	As P2.5 but in CLOSED direction.
P2.7	Torque	Hysteresis	{0: 50%}	After a torque shut off the current torque must be reduced by at least the hysteresis to enable the actuator to drive in the switch off direction.
			1: 25%	
			2: 12%	
			3: 6%	
			4: 3%	
			5: 1%	

When installing the actuator on an additional gear, please take into account the corresponding values of the gear / thrust unit as you enter the actuator parameters. To achieve an effective output torque (incl. gear) / output power (including thrust unit) ratio, the factor gear/thrust unit must be considered.



7.3 Parameter group: Speed (option)

	Menu item	Sub-menu item	poss. setting	Notes / Comments
P4.1	Speed	Local Open	5 – 100%	Output speed for local operation in direction OPEN
P4.2	Speed	Local Close	5 – 100%	As P4.1 but in direction CLOSE
P4.3	Speed	Remote Open	5 – 100%	Output speed for remote operation in direction OPEN
P4.4	Speed	Remote Close	5 – 100%	As P4.3 but in direction CLOSE
P4.5	Speed	Emergency Open	5 – 100%	Output speed for emergency operation in direction OPEN
P4.6	Speed	Emergency Close	5 – 100%	As P4.5 but in direction CLOSE
P4.7	Speed	Torque-dependent.	5 – 100%	seal-tight speed. Speed at which the actuator runs near the end position at torque-dependent switch off (see P1.3 u. P1.4)
P4.8	Speed	Minimum	5 – 100%	Minimum speed

CAUTION: 50% means nominal output speed (50Hz) and 100% means that the output speed is 2 times faster (100Hz)



7.4 Parameter group: Ramp (optional)

The start ramp can be set separately for each operation mode. Thus, a 100% start ramp means that the motor attains its maximum speed in about a second. Higher speeds (see section 7.3) lead to shorter runtimes. If the ramp is set below 100%, the starting time increases in an inversely proportional fashion.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P5.1	Ramp	Local	5... 100%	Start ramp for local operation
P5.2	Ramp	Remote	5... 100%	Start ramp for remote operation
P5.3	Ramp	Emergency	5... 100%	Start ramp for emergency operation

7.5 Parameter group: Control

	Menu item	Sub-menu item	poss. setting	Notes / Comments
P6.1	Steuerung	Phase sequence	off (0)	Phase sequence detection is deactivated. A wrong phase sequence will not be shown on the display and also not corrected. In case of wrong phase sequence the actuator will drive in the wrong direction.
			on (1)	Phase sequence detection is activated. A wrong phase sequence will be shown on the display but not corrected. In case of wrong phase sequence the actuator cannot be driven electrical.
			auto (2)	The phase sequence will be corrected automatically. The actuator will always drive in the right direction.
P6.2	Control	Ready delay	0 - 10 sec.	Drop-out delay for the ready signal (Bin. outputs)
P6.3	Steuerung	Failsafe-funktion	0: Aus	Only for failsafe actuators! This value must correspond to the mechanically realized Failsafe function!
			1: Auf	
			2: Zu	
P6.5 ²⁾	Control	24V output	0	24V auxiliary output is deactivated (chapter 19.5, page 55). The function of the auxiliary input is still activated.
			{1}	24V auxiliary output is activated (chapter 19.5, page 55).

7.6 Parameter group: Password

The actuator control can be password-protected to prevent access at different levels. It is possible to prevent entry by unauthorized personnel or to entirely lock motor operation.

Default password is set to "000" and thus deactivated.

You can use both numbers and capital letters in your password. After entering a password, password protection is activated. To remove password protection, enter an empty password (000).

When accessing a password-protected parameter, the user is automatically prompted to enter the password. Only after correctly entering the password, it is possible to change the corresponding parameters.

²⁾since firmware 1.303

	Menu item	Sub-menu item	Poss. setting	Notes / comments
P7.1	Password	Reading PWD	3-digit	Status display and history data are still viewable; access to the parameter menu is locked until this password is introduced. Parameter menu scrolling is only enabled after entering the password. Electric motor operation is unlocked.
P7.2	Password	Writing PWD	3-digit	Status display, history data and parameter menu can be viewed. However, parameters become read-only.

7.7 Parameter group: Position

In addition to OPEN and CLOSED end positions, you may define intermediate positions. These can be used as feedback signals for the binary outputs or as target value for fix position approach.

CAUTION: If you change the end positions (see section 7.1, page 24), intermediate positions are retained percentage-wise, i.e., the absolute positions of the intermediate positions change.



	Menu item	Sub-menu item	Poss. setting	Notes / comments
P8.1	Position	Intermed.pos.1	TEACHIN 0...100%	Position value of intermediate position 1
P8.2	Position	Intermed.pos.2	TEACHIN 0...100%	see above
P8.3	Position	Intermed.pos.3	TEACHIN 0...100%	see above
P8.4	Position	Intermed.pos.4	TEACHIN 0...100%	see above
P8.5	Position	Emerg.position	TEACHIN 0...100%	Position value of the emergency position.
P8.6	Position	Hysteresis	0.1...10.0%	Hysteresis range of intermediate positions. Within this hysteresis, no repositioning occurs upon reaching the intermediate positions (option: fix position approach). Furthermore, the output functions for position = intermediate position are active within this range (see P10.1 ...).

7.8 Parameter group: Binary inputs

The controller is equipped with 5 freely configurable binary inputs. Please find further information on technical data of the binary inputs in section 19.1, page 54. Binary inputs are also effective during actuator control via Profibus (option).

Default binary inputs are as follows:

Input 1: OPEN

Input 2: CLOSED

Input 3: STOP

Input 4: EMERGENCY OPEN

Input 5: EMERGENCY CLOSED

	Menu item	Sub-menu item	Poss. setting	Notes / comments
P9.1	Bin. Input	Input 1	0: no function	this input has no function
			1: Open	OPEN command in REMOTE mode (selector switch in position REMOTE).

continued on next page

continued from previous page

Menu item	Sub-menu item	Poss. setting	Notes / comments
		2: Closed	CLOSED command in REMOTE mode (selector switch in position REMOTE).
		3: Stop	STOP command in REMOTE mode (selector switch in position REMOTE).
		4: Open Self-hold	Self-hold for OPEN, i.e., a short pulse is sufficient and then the actuator moves to the end position. Use the STOP command to stop the actuator.
		5: Closed Self-hold	Self-hold for CLOSED, see OPEN SELF-HOLD
		6: Emergency Open	Superimposed run command; run the actuator in direction OPEN regardless of whether the selection switch is set to REMOTE or LOCAL operation
		7: Emergency Closed	Superimposed run command; run the actuator in direction CLOSED regardless of whether the selection switch is set to REMOTE or LOCAL
		8: Release	The actuator may be operated only with a switched signal. Both in local and remote operation
		9: Open/Closed	The actuator moves towards OPEN if input is active and towards CLOSED otherwise
		10: Close/Open	The actuator moves towards CLOSED if input is active and towards OPEN otherwise
		11: Positioner	Release of the positioner
		12: Open inv.	As OPEN but active low
		13: Close inv.	As CLOSED but active low
		14: Stop inv.	As STOP but active low
		15: Open Self-Hold.inv	As Open Self-Hold but active low
		16: Closed Self-Hold inv	As Closed Self-Hold but active low
		17: Emergency- Open inv.	As Emergency-Open but active low
		18: Emergency- Closed inv.	As Emergency-Closed but active low
		19: Block	with activated (switched) signal, the actuator is locked for operation also in local mode
		20: Controller lock	Positioner lock
		21: Release Local	The actuator may be operated only with a switched signal.
		22: Block Local	as Release Local but active low
		23: Lock Open	Trigger lock OPEN (in LOCAL and REMOTE mode). Actuator moves with the highest priority to OPEN; command continues internally active after reaching the end position OPEN. Dropping only with LOCK OFF, Supply OFF or operating mode OFF.

continued on next page

continued from previous page

	Menu item	Sub-menu item	Poss. setting	Notes / comments
			24: Lock Closed	Trigger lock CLOSED (in LOCAL and REMOTE mode). Actuator moves with the highest priority to CLOSED; command continues internally active after reaching the end position CLOSED. Dropping only with LOCK OFF, Supply OFF or operating mode OFF.
			25: Lock Off	Drop the lock
			26: Failsafe	Trigger the failsafe function in all operating modes (only functional in failsafe actuators).
			27: Failsafe inv.	As Failsafe but active low
			28: Lock Open inv.	As Lock Open but active low
			29: Lock Closed inv	As Lock Closed but active low
			30: Lock Off inv.	As Lock Off but active low
			31: Intermediate position 1	Approach intermediate position 1 (P8.1) in REMOTE mode (fix position approach). There is no repositioning upon reaching the intermediate position within the hysteresis (see P8.6) Higher priority than intermediate position 2, 3 and 4
			32: Intermediate position 2	As intermediate position 1 but with higher priority than intermediate positions 3 and 4
			33: Intermediate position 3	As intermediate position 1 but with higher priority than intermediate position 4
			34: Intermediate position 4	As intermediate position 1 but with lowest priority.
			35: Emergency position	Approach emergency position (P 8.5). As intermediate position 1 but with higher priority than intermediate positions 1, 2.
			36: Intermediate position 1 inv.	As Intermediate position 1 but active low
			37: Intermediate position 2 inv.	As Intermediate position 2 but active low
			38: Intermediate position 3 inv.	As Intermediate position 3 but active low
			39: Intermediate position 4 inv.	As Intermediate position 4 but active low
			40: Emergency position inv.	As Emergency position but active low
P9.2	Bin. Input	Input 2	see Input 1	
P9.3	Bin. Input	Input 3	see Input 1	
P9.4	Bin. Input	Input 4	see Input 1	
P9.5	Bin. Input	Input 5	see Input 1	

7.9 Parameter group: Binary outputs

The controller is equipped with 8 freely configurable binary outputs. Please find further information on technical data of the binary outputs in section 19.2, page 54. Provided with external supply, binary outputs are optically isolated from the rest of the controller.

Default binary outputs are as follows:

- | | |
|-------------------------------|-----------------------------|
| Output 1: Ready | Output 2: End position OPEN |
| Output 3: End position CLOSED | Output 4: Run OPEN |
| Output 5: Run CLOSED | Output 6: Torque |
| Output 7: LOCAL | Output 8: REMOTE |

	Menu item	Sub-menu item	poss. setting	Notes / comments
P10.1	Bin. Output	Output 1	0: User defined	Optional
			1: Ready	Actuator is ready
			2: Fault	General fault; actuator is not ready
			3: Open	Actuator is in open position
			4: Closed	Actuator is in closed position
			5: Running Open	Actuators runs in direction Open
			6: Running Closed	Actuators runs in direction Closed
			7: Runing	Actuator is running in either Open or Closed
			8: Torque Open	Switch-off torque was reached in Open direction, actuator has been switched off
			9: Torque Closed	Switch-off torque was reached in Closed direction, actuator has been switched off
			10: Torque	Switch-off torque was reached in either Closed or Open direction
			11: Travel Open	The Open end position has been reached
			12: Travel Closed	The Closed end position has been reached
			13: Pos. > Int.1	Position > Intermediate position 1
			14: Pos. < Int.1	Position < Intermediate position 1
			15: Pos. > Int.2	Position > Intermediate position 2
			16: Pos. < Int.2	Position < Intermediate position 2
			17: Pos. > Int.3	Position > Intermediate position 3
			18: Pos. < Int.3	Position < Intermediate position 3
			19: Pos. > Int.4	Position > Intermediate position 4
			20: Pos. < Int.4	Position < Intermediate position 4
			21: Local	Local operating mode (selector switch in position)
			22: Remote	Remote operating mode (selector switch in position Remote)
			23: Off	Off operating mode (selector switch in the Off position)
			24: no function	no function
			25: motor error	The motor temperature sensor has reported an error
			26: Always	Signal is always on
			27: Never	Signal is always off
			28: Bin. Input 1	Forwarding of binary input to output
			29: Bin. Input 2	Forwarding of binary input to output
			30: Bin. Input 3	Forwarding of binary input to output
			31: Bin. Input 4	Forwarding of binary input to output
32: Bin. Input 5	Forwarding of binary input to output			

continued on next page

continued from previous page

Menu item	Sub-menu item	poss. setting	Notes / comments
		33: Torque Open ma.	As Torque OPEN, but it will suppress (mask) this signal in the end position upon torque-dependent switch-off.
		34: Torque Closed ma.	As Torque CLOSED, but it will suppress (mask) this signal in the end position upon torque-dependent switch-off.
		35: Ready Remote	Ready and Remote operating mode
		36: Ready Local	Ready and Local operating mode
		37: Ready Local/remote	Ready and Local or Remote mode
		38: Lock Open	Lock OPEN is enabled. OPEN command is internally queued with the highest priority and will not be dropped even in the end position.
		39: Lock Closed	Lock CLOSED is enabled. CLOSED command is internally queued with the highest priority and will not be dropped even in the end position.
		40: Failsafe OK1	Failsafe OK (only for Failsafe actuators)
		41: Failsafe OK2	Failsafe OK and Ready (only for Failsafe actuators)
		42: Failsafe OK3	Failsafe OK, Ready and Remote (only for Failsafe actuators)
		43: Lock	Lock Open or Lock Closed is enabled.
		44: Ready/TorqueOK	Actuator is ready and no torque switch-off
		45: Ready / Remote / TorqueOK	Actuator is ready for operation in REMOTE mode and no torque switch-off
		46: Pos.=Int1	Position = Intermediate position 1. The width of the interval is set with the parameter P8.6.
		47: Pos.=Int2	Position = Intermediate position 2. The width of the interval is set in parameter P8.6.
		48: Pos.=Int3	Position = Intermediate position 3. The width of the interval is set in parameter P8.6.
		49: Pos.=Int4	Position = Intermediate position 4. The width of the interval is set in parameter P8.6.
		50: Pos.=EmergPos	Position = emergency position. The width of the interval is set in parameter P8.6.
		51: Bus Bit 1	In existing bus interface (hardware option), the output is set according to the selected bit bus. ³⁾
		52: Bus Bit 2	
		53: Bus Bit 3	
		54: Bus Bit 4	
		55: Bus Bit 5	
		56: Bus Bit 6	
		57: Bus Bit 7	
		58: Bus Bit 8	
		59: Virtual 1	Configurable output function
		60: Virtual 2	

continued on next page

³⁾from Firmware 1.323

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			61: Virtual 3	
			62: Virtual 4	
			63: Line voltage OK	Supply voltage for the motor is OK
			64: Control voltage OK	The auxiliary voltage for the SMARTCON control is OK. This function is only available if the auxiliary voltage output is not switched on (P6.5 to 0).
			65: Oil pressure OK	The oil pressure is higher than the minimum pressure (P6.10).
			66: Oil level OK	The oil level is OK.
			67: pump OK	The temperature sensor in the pump motor and the external motor protection have not tripped.
4-5 P10.2	Bin. Output	Output conf. 1	0: normal	Output 1 is set to normal, i.e. if the condition in point P10.1 is met, Output 1 is set to HIGH (active HIGH).
			1: inverted	If the condition in point P10.1 is met, Output 1 is set to LOW (active LOW).
			2: norm. flashing	If the condition in point P10.1 is met, Output 1 starts blinking (active HIGH).
			3: inv. flashing	If the condition in point P10.1 is not met, Output 1 starts blinking (otherwise it is set to HIGH).
P10.3	Bin. Output	Output 2	see Output 1	
P10.4	Bin. Output	Output 2 Konf.	see Output 1 conf.	
P10.5	Bin. Output	Output 3	see Output 1	
P10.6	Bin. Output	Output 3 Konf.	see Output 1 conf.	
P10.7	Bin. Output	Output 4	see Output 1	
P10.8	Bin. Output	Output 4 Konf.	see Output 1 conf.	
P10.9	Bin. Output	Output 5	see Output 1	
P10.10	Bin. Output	Output 5 Konf.	see Output 1 conf.	
P10.11	Bin. Output	Output 6	see Output 1	
P10.12	Bin. Output	Output 6 Konf.	see Output 1 conf.	
P10.13	Bin. Output	Output 7	see Output 1	
P10.14	Bin. Output	Output 7 Konf.	see Output 1 conf.	
P10.15	Bin. Output	Output 8	see Output 1	
P10.16	Bin. Output	Output 8 Konf.	see Output 1 conf.	

CAUTION: When using the parameters torque-dependent OPEN or torque-dependent CLOSED (see section 7.1, page 24, items P1.3 and P1.4), the actuator will only be open or closed when the set torque and the associated end position is reached. If the end position is not reached, a torque error is reported (see section 6.2.2, page 19).



7.10 Parameter group: Position output (option)

Position output is used to indicate the current position of the actuator using 0/4-20 mA; it can be retrofitted using smartcode.

If this option is not enabled, the menu point shows the message "inactive".

No adjustment to the end positions or the travel is required. Adjustment is automatically performed during the configuration of travel limit positions (see section 7.1, page 24)

No further settings are necessary for torque-dependent switch-off because the controller exclusively uses travel limit positions for the calculation, regardless of whether this is defined by the torque or the travel limit positions.

The factory default setting is:

4 mA at 0% position 20 mA at 100% position

	Menu item	Sub-Menu item	Poss. setting	Notes / comments
P11.1	Position-Output	Function	disabled	Position Output disabled
			enabled	Position Output enabled
P11.2	Position-Output	Start (at 0%)	0 – 20.5 mA {4 mA}	mA value for the Closed (0%) position
P11.3	Position-Output	End (at 100%)	0 – 20.5 mA {20 mA}	mA value for the On (100%) position
P11.4	Position-Output	Calib. 20 mA	-10% – +10%	Calibrating the output position during the setting of this parameter will output a 20 mA (100%) signal. Use this parameter to calibrate accurately the 20 mA output signal (e.g., if you measure 19.8 mA at the output, just add 1% (0.2 mA... 1% of 20 mA) to the displayed value).

7.11 Parameter group: Step mode

Step mode operation can be used to extend the operating time in certain ranges or for the whole travel; it is available in local, remote and emergency mode.

Step mode operation can be activated individually for the directions OPEN and CLOSED.

Cycle start, cycle end, cycle duration and interval time can be set separately for both directions (see chapter Figure 62, page 35).

	Menu item	Sub-Menu item	poss. setting	Notes / Comments
P12.1	Step mode function	Mode	disabled	Step mode operation is disabled
			enabled	Step mode operation is enabled in LOCAL, REMOTE and EMERGENCY operation
			Local only	Step mode mode is only enabled in LOCAL mode
			Remote only	Step mode mode is only enabled in REMOTE mode
			Local + Remote only	Step mode mode is enabled in REMOTE and LOCAL mode
P12.2	Step mode function	Start Open	0 - 100%	In OPEN direction, position in % from which the step mode operation should start.
P12.3	Step mode function	End Open	0 - 100%	In OPEN direction, position in % of which the step mode operation should end.

continued on next page

continued from previous page

	Menu Item	Sub-Menu item	poss. setting	Notes / Comments
P12.4	Step mode function	Runtime Open	0.1 - 60	Runtime in OPEN direction
P12.5	Step mode function	Pause time Open	0.2 - 60	Pause time in OPEN direction
P12.6	Step mode function	Start Closed	0 - 100%	In CLOSED direction, position in % from which the step mode operation should start.
P12.7	Step mode function	End Closed	0 - 100%	In CLOSED direction, position in % of which the step mode operation should end.
P12.8	Step mode function	Run time Closed	0.1 - 60	Runtime in Closed direction
P12.9	Step mode function	Pause time	0.2 - 60	Pause time in Closed direction
P12.10	Step mode function	Timebase	{0: Seconds}	Time basis for run and pause times
			1: Minutes	




Figure 62

NOTE: It is important to ensure that the mode of operation is not exceeded!
 The running info on the actuator (see section 6.2.2, page 19) only flashes while the drive is running, i.e. during the break, there is no flash!



7.12 Parameter group: Positioner (option)

The positioner SR option is used to control the electric actuator by means of a set point input 0/4-20 mA signal. The SR helps control the position of the actuator, i.e. the positioner ensures that the actual value and thus the position of the actuator matches the desired set point.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P13.1	Positioner	Function	off	Positioner disabled
			on	Positioner enabled

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments			
P13.2	Positioner	Begin (at 0%)	0 – 20.5 mA {4.0 mA}	mA value of the setpoint for the CLOSED (0%) position			
P13.3	Positioner	End (at 100%)	0 – 20.5 mA {20.0 mA}	mA value of the setpoint for the OPEN (100%) position			
P13.4	Positioner	Dead band	0.1 – 10.0% {1.0%}	Tolerance range for the control deviation (set point position – actual position) where no adjustment occurs. The deadband should not be set too low to prevent actuator oscillation.			
P13.5	Positioner	Gain	1 – 100% {100%}	The gain (gradient) affects the positioning close to the target position. The smaller the gain selected (e.g., 20%), the earlier the actuator starts reducing its speed in case of speed variable actuators on approaching the target position. In case of actuators with fixed speed (reversing starters), the speed reduction is done by pulsing (also see params P13.9 and P13.10). This provided a better positioning (smaller reachable deadband). A 100% setting disables this gradient.			
P13.6	Positioner	Live zero detect.	Ignore	The setpoint monitoring (monitoring the setpoint to below approximately 2 mA = loss of signal) is disabled.			
			{Stop}	Actuator stops on signal failure.			
			Open	On signal failure, actuator moves the OPEN position.			
			Close	Actuator moves on signal failure to the CLOSED position.			
P13.6	Positioner	Live zero detect.	Emerg.pos.	On signal failure, the actuator moves the defined emergency position (see parameter P13.7).			
			Emergency pos.	Determination of the emergency position (can also be set in menu P8.5)			
			P13.7	Positioner	Emergency pos.	0 – 100% {50.0%}	Determination of the emergency position (can also be set in menu P8.5)
			P13.8	Positioner	Calib. setpoint	-10% – +10%	Calibration value for the mA setpoint. Calibration process: By applying 20 mA on the setpoint input, this parameter is corrected until the readout matches 20 mA.
P13.9	Positioner	Min. Impuls	{0.2 s}	Variable speed actuators (Actusmart CM and Smartcon CSC FU): Without function Fixed speed actuators (Smartcon CSC): Minimum activation time of the reversing contactors. For very small activation times (<0.3 ... 0.5 s), the motor will be switched off during start-up process, which significantly increases wear on mechanical reversing contactors. For frequent periods of very small activation times (restless loop, small dead zone, clocking near the target value), we therefore recommend electronic reversing contactors.			
P13.10	Positioner	Period	{2,0 s}	Variable speed actuators (Actusmart CM and Smartcon CSC FU): Without function Fixed speed actuators (Smartcon CSC): This parameter is only relevant when Step mode is enabled and when approaching the target position (parameter gain smaller than 100 %) and determines the period of a run / pause cycle.			

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P13.11	Positioner	Begin pos. (a0)	0.0 – 25.0% {2.0%}	Smallest controllable position other than the end position CLOSED. The range 0% ... a0 is just passed through. Use the parameter a0 to define the beginning of the allowable control range of the valve (e.g., blind spot for ball segment valves, etc.).
P13.12	Positioner	End pos. (e0)	75.0 – 100.0% {98.0%}	Largest controllable position other than the end position OPEN. The range e0 ... 100% is just passed through. Use the parameter e0 to define the end of the allowable control range of the valve.
P13.13	Positioner	Begin setp. (a1)	0.0 – 25.0% {2.0%}	Below this value, the end position CLOSED is controlled. Control is not possible in the range 0% ... a1 (end position tolerance). The initial setpoint a1 is associated with a small hysteresis (1/4 of the deadband).
P13.14	Positioner	End setp. (e1)	75.0 – 100.0% {98.0%}	Above this value, the end position OPEN is controlled. Control is not possible in the range e1 ... 100% (end position tolerance). The final setpoint e1 is associated with a small hysteresis (1/4 of the deadband).




Figure 63: Assigning the position to the setpoint

7.13 Parameter group: PID controller (optional)

The optional PID controller is used for controlling an external actual value (process variable) to a setpoint using 0/4-20 mA signal by readjusting the actuator.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P14.1	PID-controller	Function	0: disabled	PID controller disabled

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			1: Position	The output of the PID controller corresponds to the position setpoint of the actuator. The positioning (tracking of the actual position to the setpoint) is done by the positioner (see 7.12).
			2: Speed	The output of the PID controller corresponds to the change of the position setpoint (speed) of the actuator. The positioning (tracking of the actual position to the setpoint) is done by the positioner (see 7.12). ⁴⁾
P14.2	PID-controller	External Setpoint	0: fixed	The PID controller uses an internal, fixed setpoint (see param P14.3).
			1: external	The PID controller uses the external setpoint. The adjustment of this setpoint is done with the params P13.2 and P13.3 (see 7.12).
P14.3	PID-controller	Fixed setpoint	0 – 100%	Specification of the internal fixed setpoint
P14.4	PID-controller	Start (at 0%)	0 – 20.5 mA	mA value at 0% of the external actual value
P14.5	PID-controller	End (at 100%)	0 – 20.5 mA	mA value at 100% of the external actual value
P14.6	PID-controller	Gain (P)	+50.0 - 50.0	Gain (proportional value) of the PID-controller
P14.7	PID-controller	Reset time (I)	0 – 100.0 s	The shorter the reset time (integral time, integral value), the stronger is the effect of the integral component of the PID-controller. Values below 1.0 will disable the integral component.
P14.8	PID-controller	Lead time (D)	0 – 100.0 s	The larger the lead time (differential/derivative value), the stronger is the effect of the derivative component of the PID-controller. To reduce the influence of noise, a first-order lag element with 1sec time constant is added (DT ₁) .
P14.9	PID-controller	Offset	-200 – 200%	The offset value will be added to the output value of the PID controller.
P14.10	PID-controller	Dead band	0.1 – 10.0% {1,0%}	Tolerance range for the control deviation (set point – external actual value) where no adjustment occurs. ⁵⁾
P14.11	PID-controller	Period	2.0 – 20.0 s	Equal to param P13.10 (see section 7.12) ⁶⁾
P14.12	PID-controller	Min. pulse time	0.1 – 20.0 s	Equal to param P13.9 (see section 7.12) ⁷⁾
P14.13	PID-controller	actual value monitoring	Ignore	The monitoring of the external actual value is disabled
			Stop	Actuator stops on signal failure of external actual value
			Open	Actuator moves on signal failure of external actual values to the OPEN position.

continued on next page

⁴⁾from firmware 1.338

⁵⁾from firmware 1.340

⁶⁾up to firmware 1.337

⁷⁾up to firmware 1.337

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			Closed	Actuator moves on signal failure of external actual values to the CLOSED position.
			Emergency position	Actuator moves on signal failure of external actual values to the EMERGENCY position (see param P13.7)
P14.13	PID-controller	Calibration of ext. actual value	-10.0 – 10.0%	Calibration process: By applying 20 mA to the external actual value input, this parameter is corrected until the readout matches to 20 mA.

7.14 Parameter group: PROFIBUS DP (option)

PROFIBUS DP defines the technical and functional characteristics of a serial field bus system, which can be networked with distributed digital automation devices. PROFIBUS DP is designed for the data exchange at the field level.

Central control devices such as PLC or PC communicate via a fast serial connection with distributed field devices such as input/output devices, valves and actuators.

Data exchange with these distributed devices is cyclical. The communication functions required to that end are defined by the PROFIBUS DP basic functions in accordance with EN 50 170.

The PROFIBUS DP option is a hardware option with which you should already be familiar upon ordering the actuator.

Subsequent installation of hardware components is possible but should only be performed by a professional SCHIEBEL installer or specially trained personnel.

The PROFIBUS-DP interface is described in the separate manual "Profibus-DP for SMARTCON controllers".



7.15 Parameter group: DeviceNet (option)

The DeviceNet[®] field bus is based on the CAN protocol and was originally developed by Rockwell Automation as an open field bus. Today, DeviceNet falls under the responsibility of ODVA (Open DeviceNet Vendors Association, Inc., <http://www.odva.org>) as an umbrella organization. DeviceNet is defined in EN 50325 2 and in IEC 62026 3. DeviceNet is a simple and powerful field bus system for the lowest field bus level to connect sensors and actuators (slaves) with the associated controllers in a network.

The DeviceNet option is a hardware option with which you should already be familiar upon ordering the actuator.

Subsequent installation of hardware components is possible but should only be performed by a professional SCHIEBEL installer or specially trained personnel.

The DeviceNet interface is described in the separate manual "DeviceNet for SMARTCON controllers".



7.16 Parameter group: Characteristic curves (optional)

With this option, customers can enable travel-dependent torque characteristic curves.

With these characteristic curves, torque limits already set under menu item P2 (torque), can be further **reduced** depending on travel. Characteristics can be configured via the infrared interface with the SMARTTOOL software. (see Figure 64, page 40)






Figure 64

If at least one of the characteristic curve is activated, it is shown in the graphical display (see Figure 65 40)



Figure 65: 1... Characteristic curve enabled

	Menu Item	Sub-Menu item	poss. setting	Notes / Comments
P17.1	Characteristic	Torque Open	Off	The torque characteristic curve is disabled for the OPEN direction
			On	The torque characteristic curve is enabled for the OPEN direction
			Local + Remote only	The torque characteristic curve is enabled for the OPEN direction only in LOCAL and REMOTE mode (while disabled in the EMERGENCY mode)
P17.2	Characteristic	Torque Closed	Off	The torque characteristic curve is disabled for the CLOSED direction
			On	The torque characteristic curve is enabled for the CLOSED direction
			Local + Remote only	The torque characteristic curve is enabled for the CLOSED direction only in LOCAL and REMOTE mode (while disabled in the EMERGENCY mode)

7.17 Parameter group: Identification (optional)

This option allows entering further custom-identification parameters.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P18.1	Identification	PPS number	15 digits	Used to enter a PPS number. This is displayed in the bottom line. CAUTION: Param P20.5 must be set to 0.

7.18 Parameter group: System parameters (locked)

Used for actuator configuration and not available for customers.

7.19 Parameter group: Miscellaneous

	Menu item	Sub-menu item	poss. setting	Notes / comments
P20.1	Miscellaneous	Language	0: German	Defines the menu language
			1: English	
			2: Russian	
			3: Czech	
			4: Spanish	
			5: French	
			6: Italian	
			7: Danish	
P20.2	Miscellaneous	Rotate display	no	Default setting
			yes	Rotates the display by 180° Warning: The operation of the control switch and the selector switch keeps the same.
P20.3	Miscellaneous	Load configuration	Customer conf. -	Actuator parameters, excluding params P1.1 to P1.6, will be overwritten with customer parameters.
			Customer conf. +	Actuator parameters, including params P1.1 to P1.6, will be overwritten with customer parameters.
			Backup parameters -	Actuator parameters, excluding params P1.1 to P1.6, will be overwritten with factory parameters.
			Backup parameters +	Actuator parameters, including params P1.1 to P1.6, will be overwritten with factory parameters.
P20.4	Miscellaneous	Save configuration	Customer conf.	Stores all parameters in the customer configuration.
P20.5	Miscellaneous	Info line	{0} - 31	The fourth line of the display shows various diagnostic values.
P20.6	Miscellaneous	Infrared	Off (0)	The infrared connection is disabled.
			On (1)	The infrared connection is activated for about 3 minutes.

8 Status area

The status area presents current process and diagnostic data. This data is read-only. To access the status area, move the control switch in the direction where the selector switch should be in the neutral position or in the remote position.

The status area is divided into 2 sub-areas:

- Status
- History

8.1 Status

8.1.1 Status – Bin. Outputs

Display of binary outputs: The display shows output control as opposed to output status, i.e. the supply of the binary outputs is ignored. A switched output is represented by 1.




Figure 66: 1... Output Number, 2... Signal (0 = LOW; 1 = HIGH)

8.1.2 Status – Bin. Inputs

Display of binary inputs: A set input is represented by 1.




Figure 67: 1... Input number, 2... Signal (0 = LOW; 1 = HIGH)

8.1.3 Status – Analogue values

Display of analogue values: Input 1 (In1) is used by the positioner as the setpoint; Input 2 (In2) serves as an external value for the optional PID controller. In the analogue output (out), only the control signal is shown, regardless of whether the output current actually flows or not (interruption of the current loop).




Figure 68: 1... Input 1, 2... Input 2, 3... Output, 4... all values in mA

8.1.4 Status – Absolute values

This is used for the mechanical pre-adjustment of the position unit. (see section 5.3, page 13)




Figure 69: 1... absolute value of the position unit, 2... value for the torque unit (is factory adjusted)

8.1.5 Status – Firmware




Figure 70: 1... Firmware, 2... Firmware date

8.1.6 Status – Serial number




Figure 71: 1... serial number of the control unit, 2... Serial number of the actuator, 3... Serial number of electronics

8.2 History

History shows the last 20 history entries. In addition to the plain text entry, the time since the last history entry is also provided.

Please note that the actuator can only calculate time if energised. For error analysis, please refer to section 11.1, page 45.

9 Infrared connection

For easier communication and better visualization of the menu options, the unit provides an infrared port for connection to a PC.

The required hardware (connection cable to the PC's RS-232 or USB connectors) and the corresponding software are available as options.

The SMARTTOOL software, in addition to communication with the actuator, allows the management of multiple actuators to transfer the configuration to different actuators.

This approach can greatly simplify operation.

Please refer to the SMARTTOOL software operating instructions manual for further information.

During operation, it must be ensured that the IR interface surface is protected from strong disturbances - which may otherwise compromise the communication.

Before mounting the infrared adapter, clean the surface of the infrared interface with a damp cloth.




Figure 72: 1... Infrared connection

When the infrared port is enabled, this is indicated on the display (see Figure 73) The infrared interface can be enabled in the menu option P20.6




Figure 73: 1...infrared port is enabled

10 Maintenance

Maintenance work on open actuators may only be conducted if these are de-energized. Reconnection during maintenance is strictly prohibited.

Work on the electrical system or equipment must be carried out only in accordance with electrical regulations by a qualified electrician himself or by specially instructed personnel under the control and supervision of a qualified electrician.



Actuators are ready for use after installation. By default, the actuator is delivered filled with oil.

On-going monitoring:

- Beware of increased running noise. During long downtime periods, operate the actuator at least every 3 months.
- For actuators with output types A, B and C according to DIN 3210-A, B1, B2 and C according to DIN ISO 5210, re-lubricate at least every 6 months on existing grease fittings (see section 14.3, page 48)

Actuators are designed for installation in any position (see section 2.5, page 6). Therefore, the main body is not equipped with a level indication or a drain plug.

The replacement of the lubricant from the main body must be performed via the handwheel.

Every approx. 10,000-20,000 hours (about 5 years - section 14, page 47), depending on the workload, you must:

- Change Oil
- Replace seals

Check all roller bearings and the worm-wheel assembly and replace if necessary.
 Check our lubricants table for recommended oils and greases. (14, page 47)

11 Troubleshooting

Upon warning or error, the bottom line of the display will show the corresponding, plain text description. This event will also be entered into the history (see section 8.2, page 43)

11.1 Error list

Error	LED indicators	Description
Motortemp. trip	L4 is off	there are 4 possibilities for this failure: 1. phase sequence of the power supply is wrong, exchange phase L1 with phase L2 2. loss of one phase, check the power supply 3. a fuse is blown – refer to section 12, page 45 4. motor is to hot
travel fault	L1 and L2 is on L4 is flashing	the travel device is out of its range and must be adjusted – refer to section 5.3, page 13
inverter fault	L4 is off	communication with frequency inverter fault, please contact the supplier
torque sensor fault	L3 and L4 is flashing	please contact the supplier

12 Fuses

Depending on the version of the SMARTCON control unit, there are fuses located in the terminal area, the dimension of the fuse is indicated next to the fuse holder.




Figure 74: 1... Connection compartment




Figure 75: size 1, electronic reversing starters
(1... main fuses, 2... control fuse)




Figure 76: size 2 (1... control fuse)




Figure 77: size 1, up to 440VAC
(1... control fuse)




Figure 78: size 1, larger than 440VAC
(1... control fuse)

fuse F1: main fuse before the electronic reversing starter (eW, see Figure 75)			
power of the motor	value	Recommended Type	Spare part designation
up to 1,5kW	20A FF (2 pcs)	G-fuse, brand SIBA, type 195100, ceramic 6,3 x 32mm; 20AFF,very fast acting, 500V, I ² t = 46A ²	C606d
3kW	12,5A T (2 pcs)	G-fuse, brand SIBA, type 189140, ceramic 6,3 x 32mm; 12,5AT; time lag, 500V, I ² t = 1300A ² s	C606e
fuse F2: control fuse before the control transformer			
supplyvoltage	value	Recommended Type	Spare part designation
≤ 440VAC	125mA T	G-fuse, brand SIBA, type 189140, ceramic 6,3 x 32mm; 125mA; time lag, 500V, I ² t = 0,08A ² s	C606g
> 440VAC	100mA T (2 Stück)	G-fuse, brand SIBA, type 189140, ceramic 6,3 x 32mm; 100mA; time lag, 500V, I ² t = 0,05A ² s	C606f

Actuators which are suitable for operation in explosive atmosphere, no fuses are located in the connection compartment! The control fuse is installed in the flameproof area of SMARTCON control unit and is not accessible to the user!



The logic board of the controller cover (see Figure 79, page 47) features two miniature fuses for the control lines




Figure 79: 1... Fuse F10a for the binary outputs, 2... Fuse F10b fuse for auxiliary supply

Fuses on the logic board			
Fuse	Value	Manufacturer	List of spare parts
F10a	375mA	Littelfuse 454 NANO2 Slo-Blo® träge	C302a
F10b	500mA	Littelfuse 454 NANO2 Slo-Blo® träge	C302b

13 Spare parts

When ordering spare parts, please provide us with the serial number of the (see section 2.2, page 5). Check the separate break-down image and separate list of spare parts.

14 Recommendations of Lubricants (for all manufactures)

14.1 Main Casing

14.1.1 Application temperature from -35°C to +100°C

Lubricating grease DIN 51826 - GP 00 P-30

i.e. High pressure (EP), complex grease on Li soap basis:
 work penetration 0.1 mm: 355 to 430
 Dripping temperature: about 200°C
 NLGI grade: 00
 Acid-free, not or only marginally reacting with water

14.1.2 Application temperature from -50 to +100 °C

Lubricating oil DIN 51 502 CLP-HC

i.e. fully synthetic high-performance industrial gear oil based on poly alpha olefins (PAOs):
 Viscosity class: ISO VG 68
 Pour point: <-55°C
 Compatibility with conventional coatings and sealants

14.1.3 Application temperature from -60 to +100 °C

Lubricating oil DIN 51 502 CLP-HC

i.e. fully synthetic high-performance industrial gear oil based on poly alpha olefins (PAOs):
 Viscosity class: min ISO VG 32
 Pour point: <-60°C
 Compatibility with conventional coatings and sealants

14.2 Spur Gears (actuator size AB8 - AB80)

Lubricating grease DIN 51826 - KPF -1/2 G-20

i.e. High-graphite, bitumen-free permanent lubricant with outstanding EP properties:

Work penetration 0.1 mm: between 265 and 340.

Observe operating temperature range!

14.3 Output Drive Type A and Spindle Drive (Linear Actuators)

Lubricating grease DIN 51862- G 1 -G

i.e. Water-resistant complex grease on Al soap basis, highly resistant to acids and alkalines:

work penetration 0.1 mm around 265

Dripping temperature: about 260°C

NLGI grade: 1

Acid-free, not or only marginally reacting with water

Observe operating temperature range!

14.4 Precision Components

Lubricating grease (or spray) DIN 58396- S1

i.e. High-creeping, water-displacing, low-viscosity grease chemically neutral to copper and plastics:

Work penetration 0.1 mm: 175 to 385

Dripping temperature: over 150°C

Evaporation loss: max. 1%

Water resistance: Evaluation grade DIN 51807-1-40

Observe operating temperature range!

14.5 Basic Lubricant Service Interval

On actuator maintenance, the old grease must be removed completely and replaced by a new one.

The service interval for Schiebel actuators is 10 years from the date of delivery

by Fa. SCHIEBEL Antriebstechnik Gesellschaft m.b.H, A-1230 Vienna

The functionality and operating life of the lubricants is, however, dependent upon operational conditions. It may be necessary to take reduction factors into account.



Operational condition(s)	Definition	Reduction Factor(Multiplier)
On-period (OP)	(Total of motor running time)	
Extremely high OP	over 1,250 hours/year	0,5
High OP	over 500 hours/year	0,7
Extremely low OP	less than 0.5 hours/year	0,8
Ambient temperature	(Permanent or long-term)	
Extremely changing	between -10 and +50°C	0,5
Extremely high	over +50°C	0,7
Extremely low	below -25°C	0,9
Output speed	(at main shaft of actuator)	
High revolution	over 80 rev./min	0,8
Utilization factor	(with respect to nominal performance)	
Very high	over 90%	0,8
High	between 80 and 90%	0,9

Example:

*Extremely low OP + extremely low ambient temperature + high revolution + utilization factor 87%
⇒ 0.8 x 0.9 x 0.8 x 0.9 = 0.51 reduction factor.*

Lubricant maintenance interval ⇒ 10 years x 0.51 = 5.1 years (62 months).

WARNING: A thusly calculated maintenance interval does not apply to the maintenance of the output type A (threaded bushing), nor to the maintenance of the linear and spindle actuator units. These must be regularly re-greased (at least once every six months) at the lubricating nipples (see section 14.3, page 48)!



During actuator maintenance, the old lubricants must be thoroughly removed and replaced by fresh ones. **No mixing of different makes of lubricant is permitted!**

The quantities needed for lubricant service can be seen from the table below.

14.6 Lubricant Requirements

Type of actuator	Main gear	Spur gears	Output form A (Threaded bushing)	Output form B (Plug bushing)	Output form C (Claw coupling)
AB3/5	1kg (1l oil)	—	5cm ³	3cm ³	3cm ³
AB8	1kg (1l oil)	1cm ³	5cm ³	3cm ³	3cm ³
AB18	1kg (1l oil)	1cm ³	8cm ³	5cm ³	5cm ³
AB40/80	1,5kg (1,5l oil)	1,5cm ³	9cm ³	6cm ³	6cm ³
AB100/200	3,5kg (3,5l oil)	1,5 kg (1,5l oil)	23cm ³	20cm ³	20cm ³

When lubricating precision components, such quantities of lubricant are to be used as to ensure fine moistening of the sliding surfaces.

15 Training

Warning: Should problems arise on site in connection with assembly or adjustment, please contact the SCHIEBEL Antriebstechnik Gesellschaft m.b.H, Josef-Benc Gasse 4, A-1230 Vienna, Telephone +43 (1) 66 108 or by internet <http://actuators.schiebel.com>, in order to avoid any incorrect operations or damage to the actuators. The Schiebel Company recommends to recruit only qualified personnel for assembly of Schiebel actuators. Upon special request by the ordering party, personnel can be trained on the premises of the Schiebel Company according to the operations listed in the instructions for use.



16 Original Declaration of Incorporation of Partly Completed Machinery

Accordinging Machinery Directive 2006/42/EC, (Annex II, sub. B)

The manufacturer, the company:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Vienna

hereby declares that the partly completed machinery described below:

Electric actuators series:

AB rAB exAB exrAB

with optional additional components:

Smartcon CSC Smartcon exCSC

the following basic requirements of the Machinery Directive (2006/42/EC) are applied and fulfilled:

Annex I, articles 1.1.2, 1.1.3, 1.1.5; 1.2.1, 1.2.1, 1.2.2, 1.2.6; 1.3.1, 1.3.2, 1.3.7;
1.5.1; 1.6.3; 1.7.1, 1.7.3, 1.7.4

The following European harmonized standards have been applied:

EN12100:2010
EN ISO 5210:1996 EN ISO 5211:2001 DIN 3358:1982

The relevant technical documentation for partly completed machinery referred to in Annex VII, Part B has been prepared. The manufacturer commits to submitting the documents for the incomplete machine the competent national authority electronically upon request.

For the preparation of the technical documents is authorized:

Head of mechanical Engineering
Schiebel Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Vienna

This partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC, where appropriate.


The electric actuators as partly completed machinery is in conformity with the relevant regulations of the EU directives:

Directive 2014/30/EU ("EMV-Directive")
Directive 2014/35/EU ("Low voltage directive")
Directive 2014/34/EU ("ATEX-Directive") for correspondingly marked devices

The corresponding separate EC Declarations of Conformity are valid.

Vienna,
(location)

den **14.12.2016**
(date)


.....
(Klaus Schiebel, general manager)

17 Declaration of Conformity (EMV- and Low voltage-directive)

The producer:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Wien

herewith confirms, that the equipment

electric actuators with control unit and following types

(r)AB ... CSC

meets the requirement of the EC-directive:

2014/30/EU („EMV-directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

EN 61000-6-2:2005

EN 61000-6-3:2007-01 + A1:2011-03

and are also consistent with the EC-directive:

2014/35/EU („Low-voltage-directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

IEC 60204-1:2005 + A1:2008 EN 60529:1991 + A1:2000

Vienna,
(location)

14.12.2016
(date)



.....
(Klaus Schiebel, general manager)

18 Declaration of Conformity (Ex-, EMV- and Low voltage-directive)

The producer:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Wien

herewith confirms, that the equipment

Description	Type	Marking	Certificate-No.
Electric Actuator	ex (r) AB	⊕II2G Ex de(q)(ib) II (B)C T4(T6) Gb	FTZU03ATEX0328X
Control Unit	V1 / V2	⊕II2G Ex de II C T4 Gb	FTZU03ATEX0329
Control Unit	CSCex	⊕II2G Ex de II C T4(T6) Gb	TÜV-A04ATEX0009X
Flameproof Induction Motor	D(.)()FU Y63/..-	⊕II2G Ex d II C T4 Gb	FTZU03ATEX0330X
Flameproof Induction Motor	D(.)()FU Y80/..-	⊕II2G Ex d II C T4 Gb	FTZU03ATEX0333X
Flameproof Induction Motor	ex DKF .. .X. ..	⊕II2G Ex d II C T4 Gb	TÜV-A03ATEX0016X
Microswitch	d 515U	⊕II2G Ex d II C Gb	FTZU03ATEX0332U
Flameproof Potentiometer	dP1 / dP2	⊕II2G Ex d II C Gb	FTZU03ATEX0387U
Flameproof capacitor	dK .	⊕II2G Ex d II B Gb	FTZU07ATEX0009U
Control Unit	CSCex FU	⊕II2G Ex de II B T4(T6) Gb	TÜV-A08ATEX0006X

meets the requirement of the EC-directive:

2014/34/EU

EC-Directive for Operation of Equipment in Potentially Explosive Atmospheres

and complies with the following harmonised standards in the version valid at signature date:

EN60079-0:2012	Electrical apparatus for explosive gas atmospheres – General requirements
EN60079-1:2007	Electrical apparatus for explosive gas atmospheres – Flameproof enclosures "d"
EN60079-7:2007	Electrical apparatus for explosive gas atmospheres – Increased safety "e"
EN60079-11:2012	Electrical apparatus for explosive gas atmospheres – Intrinsic safety "i"

Following notified bodies certificate the conform design of the equipment:

FTZU	CZ-716 07 Ostrava Radvanice	NB 1026: Quality system FTZU03ATEXQ019, Type examination certificates
TÜV Austria Services GMBH	A-1230 Wien	NB 0408: Type examination certificates

Furthermore they consistent with the EC-directive:

2014/30/EU („EMV-directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

EN 61000-6-2:2005

EN 61000-6-3:2007-01 + A1:2011-03

and are also consistent with the EC-directive:

2014/35/EU („Low-voltage-directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

IEC 60204-1:2005 + A1:2008

EN 60529:1991 + A1:2000

Vienna,
(location)

14.12.2016
(date)



.....
(Klaus Schiebel, general manager)

19 Technical data

19.1 Binary inputs

Count:	5
Nominal voltage:	24VDC
	towards common ground
Threshold voltage for input set:	>12V
Threshold voltage for input not set:	<5V
Maximum voltage:	30VDC
Current consumption at 24 V:	typ. 5mA

Binary inputs are separated from other controllers via optocouplers.




Figure 80

19.2 Binary outputs

Count:	8
Power supply:	24VDC +/- 6V
	(either from internal or external)
Max voltage drop at set output:	2V
output voltage at non-set output:	<1V
Maximum current per output:	50mA (short circuit proof)
Maximum permissible total current for all outputs:	150mA for internal power supply
Maximum permissible total current for all outputs:	250mA with external supply
Fuse:	375mA time-lag
	(Littelfuse 454 NANO ² Slo-Blö [®])

Binary outputs with external supply are separated from other controllers via optocouplers.

19.3 Analogue inputs

Count:	2
Current range:	0-20,5mA
Resolution:	10Bit
Accuracy:	0,5%
Input resistance:	120 Ohm

Reference ground is the common ground of the controller and the auxiliary voltage (see section 19.5).

19.4 Analogue outputs

Count:	1
--------------	---

Current range: 0-20,5mA
 Resolution: 10Bit
 Accuracy: 0,5%
 Max load: 600 Ohm

Reference ground is the common ground of the controller and the auxiliary voltage (see section 19.5).

19.5 Auxiliary voltage input and output

Input voltage range (auxiliary voltage input): 20-30VDC
 Maximum current consumption(auxiliary voltage input): 320mA
 Maximum current consumption in power-save mode 100mA
 (auxiliary voltage input):
 Output voltage (auxiliary voltage output): typ. 22V
 Max output current (auxiliary voltage output): 150mA
 Resistance of ground potential vs. body: typ. 100kOhm
 Capacitance of ground potential vs. body: typ. 400nF
 Voltage of ground potential vs. body: max. 40Vs
 Fuse: 500mA träge
 (Littelfuse 454 NANO² Slo-Blo[®])

Ground potential is the common ground of the controller and the analogue inputs and outputs.
 The auxiliary voltage output can be set by the menu P6.5 (see chapter 7.5, page 27).

The power-save mode is defined as follows:

- No power supply (the controller is powered exclusively through the 24V auxiliary voltage input).
- The lighting of the LCD display switches off automatically
- No additional hardware options available (Profibus Interface, DeviceNet interface, relay board, etc. ...).
- Binary outputs and the mA output are not enabled; when activating, the respective currents must be added to the total current.

19.6 Mechanic reversing starters

By default the motor with a mechanical reversing contactor is switched three-pole. The mechanical reversing contactor is both electrically and mechanically interlocked to prevent cross circuits.
 Depending on the engine size results in the following assignments:

size	Typ	power of the motor (with 400V 3-phase current)	
		open-loop control (operational mode S2)	closed-loop control (operational mode S4)
mW4	K09	3kW	1,5kW
mW5	K12	5,5kW	3kW
mW7	D18	7,5kW	5,5kW
mW11	D25	11kW	7,5kW
mW22	D38	22kW	11kW

The mechanical life (switching cycles) of the reversing starter can be roughly estimated with the help of the following diagram and the rated current (motor current):




Figure 81

19.7 Elektronische reversing starter

Optionally, the motor of the actuator is controlled by an electronic reversing contactor (thyristors). The electronic reversing contactor switches two of the three motor phases. The control of the two directions of rotation is locked by hardware in the electronic reversing contactor. Compared to conventional mechanical contactors there is no mechanical wear through contact burning; in case of electronic reversing starters this feature increases the life and reliability of modulating actuators with high switching frequency.

Attention: The third phase is not switched in the electronic reversing contactor and is therefore constantly on the motor winding.



voltage range: 48... 480Vrms
 current range: 0,1... 50Arms
 transient overvoltage: 720Vpk
 max. I²t of the fuse: 2320A²s
 lock time when changing direction: min. 100msec

19.8 Power supply

The internal supply of the SMARTCON control unit is made via the power connection. At 3-phase current a neutral phase is not required. The following table shows the possible different voltage ranges of the control.

voltage (3-phase, standard range): 3 x 380, 400, 415, 440 VAC +/-10%
 voltage (3-phase, on request): 3 x 110, 115, 120 VAC +/-10%
 voltage (3-phase, on request): 3 x 220, 230, 240 VAC +/-10%
 voltage (3-phase, on request): 3 x 460, 480, 500, 525 VAC +/-10%
 voltage (3-phase, on request): 3 x 575, 660, 690 VAC +/-10%
 voltage (single-phase, on request): 110, 115, 120 VAC +/-10%
 voltage (single-phase, on request): 220, 230, 240 VAC +/-10%
 frequency: 50/60Hz, +/-3Hz
 idle power consumption: max. 24W

For the supply voltage of the complete system (control unit and actuator) also the motor voltage must still be considered (see actuator data and name plate)!



19.9 Connections

Size 1 (mechanic reversing starters mW4, mW5, mW7K and electronic reversing starters):

Power / motor: Industrial plug with 6 pins, screw connection
16A, max. 2,5mm², AWG14
Control signals: Industrial plug with 24 pins, screw connection
16A, max. 2,5mm², AWG14

optional crimp contacts are available

Size 2 (mechanic reversing starters mW7, mW11 and mW22):

Power / motor: Industrial plug with 4 pins, screw connection
80A, 1,5...16mm²
Control signals: Industrial plug with 24 pins, screw connection
16A, max. 2,5mm², AWG14

optional crimp contacts for the control unit are available

Explosion-proof version:

Power / motor: terminals with screw connection
16A, 0,5...4mm², AWG20...AWG12
Control signals: terminals with screw connection
4A, 0,5...2,5mm², AWG20...AWG14

19.10 Miscellaneous

Ambient temperature:

On/Off Actuators: -25 to +70°C
Modulating actuators: -25 to +60°C
explosion-proof version: -20 to +40°C (acc. EN60079-0)

protection class:

standard actuators, size 1 1: IP67
standard actuators, size 2: IP65
explosion-proof version: IP65

colour: RAL7030 (other colors on request)

SCHIEBEL
www.schiebel-actuators.com

SCHIEBEL Antriebstechnik
Gesellschaft m.b.H.
Josef Benc Gasse 4
A 1230 Wien
Tel.: +43 1 66 108 - 0
Fax: +43 1 66 108 - 4
info@schiebel.com
actuators.schiebel.com