

Operating Manual 90° Actusafe CM FSQT



Contents

Contents	2
Operating Manual 90° Actusafe CM FSQT	6
Manual for 90-Degree Failsafe-Actuators - CMFSQT	6
1 Safety instructions	6
2 Introduction	7
3 Functional Description of the CM FSQT Failsafe Drive	8
3.1 Failsafe-direction	9
3.2 Moving-behaviour of the actuator	10
3.2.1 Moving behaviour electrical mode	10
3.2.2 Moving behaviour failsafe mode	10
4 General Information	10
4.1 Serial number	10
4.2 Protection class	10
4.3 Mounting position	10
4.4 Direction of rotation	10
4.5 Protective devices	10
4.6 Ambient temperature	10
4.7 Condition on delivery of the actuators	10
4.8 Note (tag)	11
5 Transport and Storage	11
6 Installation Instructions	11
6.1 Mechanical connection	11
6.2 Mounting position of the control unit	11
6.3 Electrical connection	12
7 Commissioning	12
7.1 General information	13
7.2 Manual operation	13
7.2.1 Direction of rotation handwheel for closing the valve, Failsafe direction „CW“	14
7.2.2 Direction of rotation handwheel for closing the valve, Failsafe direction „CCW“	15
7.2.3 Activate manual operation	16
7.2.4 Deactivate manual operation	16
7.2.5 Required force on the handwheel	16
7.3 Mechanical default setting, preparation	16
7.4 Setting the end positions	16
7.5 Setting the mechanical end stop	16
7.6 Adjusting of Failsafe speed	17
7.7 Final work	19
8 The control unit	19
9 Maintenance	20
10 Technical data failsafe brake	21
10.1 CM03FSQT	21
10.2 CM06FSQT	21
11 Spare parts	21
12 Lubricant recommendation / Lubricant requirements	21
12.1 Lubricant points FSQT	21
12.2 Basic lubricant service interval	22
13 Training	22
14 Mode of operation FSQT	23
14.1 CM03 FSQT	23
14.2 CM06 FSQT	23

Operating Manual ACTUSMART CM.V1.2	25
1 Introduction/Notes	25
2 General	25
2.1 Overview	25
2.2 Serial number and type label	25
2.3 Operating mode	26
2.4 Protection class	26
2.5 Mounting position	26
2.6 Direction of rotation	26
2.7 Protection devices	27
2.7.1 Torque	27
2.7.2 Motor temperature	27
2.7.3 Input fuse, thermal fuse	27
2.8 Ambient temperature	27
2.9 Delivery condition of the actuators	28
2.10 Information notice (tag)	28
3 Packaging, transport and storage	28
3.1 General	29
3.2 Storage	29
3.3 Long-term storage	29
4 Installation instructions	30
4.1 Mechanical connection	30
4.2 Mounting position of the operating unit	31
4.3 Electrical connection	31
4.3.1 Power supply connection	32
5 Commissioning	33
5.1 General	33
5.2 Manual operation	33
5.3 Mechanical default settings, preparation	33
5.4 End limit setting	33
5.4.1 End limit OPEN	33
5.4.2 End limit CLOSE	36
5.5 Final works	36
6 Control Unit	36
6.1 Operating unit	36
6.2 Display elements	38
6.2.1 Graphic display	38
6.2.2 LED Display	38
6.3 Operation	39
6.3.1 Operation mode	41
6.3.2 Configuration	41
6.3.3 Configuration example	42
6.3.4 „TEACHIN“	44
7 Parameter menu	44
7.1 Parameter group: End limit	44
7.2 Parameter group: Torque	46
7.3 Parameter group: Speed	46
7.4 Parameter group: Ramp (optional)	47
7.5 Parameter group: Control	47
7.6 Parameter group: Password	47
7.7 Parameter group: Position	47
7.8 Parameter group: Binary inputs	48
7.9 Parameter group: Binary outputs	50
7.10 Parameter group: Position output (optional)	52
7.11 Parameter group: Step mode	53
7.12 Parameter group: Positioner (optional)	55
7.13 Parameter group: PID controller (optional)	56
7.14 Parameter group: Bus systems (optional)	58
7.15 Parameter group: Characteristic curves (optional)	58
7.15.1 Torque characteristic	58
7.15.2 Speed characteristic	59
7.15.3 Valve characteristic	60

7.16	Parameter group: Identification (optional)	60
7.17	Parameter group: System parameters (locked)	61
7.18	Parameter group: Miscellaneous	61
8	Status area	62
8.1	Status	62
8.1.1	Status – binary outputs	62
8.1.2	Status – binary inputs	62
8.1.3	Status – analog values	62
8.1.4	Status – absolute values	63
8.1.5	Status – firmware	63
8.1.6	Status – serial number	64
8.1.7	Status – meter readings	64
8.2	History	64
9	Infrared connection	64
10	Bluetooth connection	65
11	Maintenance	65
12	Troubleshooting	67
12.1	History Entries	67
13	Fuses	69
14	Spare parts	69
15	Lubricant recommendation, lubricant requirements	69
15.1	Main body: -25 to +60°C	69
15.2	Main body: -40 to +60°C	69
15.3	Output type A and spindle drives (linear actuators) -40 to +60°C	70
15.4	Basic lubricant service interval	70
16	Training	70
17	Original Declaration of Incorporation of Partly Completed Machinery	71
18	Declaration of Conformity	72
19	Declaration of Conformity	73
20	Technical data	74
20.1	Binary outputs	74
20.2	Binary inputs	74
20.3	Analog inputs	76
20.4	Analog output	77
20.5	Auxiliary voltage input and output	77
20.6	Connections	78
20.6.1	Connections for non explosion-proof version	78
20.6.2	Connections for explosion-proof version	78
20.7	Mode of operation CM	78
20.8	Mode of operation CM03 + QT	80
20.9	Mode of operation CM03 + L	81
20.10	Mode of operation CM03 + LK	82
20.11	Miscellaneous	82
21	Technical data CM03	83
21.1	Standard version CM03	83
21.2	24 VDC version CM03	83
21.3	400 V version CM03	83
22	Technical data CM06	83
22.1	Standard version CM06	83
22.2	400V version CM06	84
23	Technical data CM12	84
23.1	Standard version CM12	84
24	Characteristic curves	85
24.1	Characteristic curves - CM03	85
24.2	Characteristic curves - CM06	85
24.3	Characteristic curves - CM12	86

Spare parts ACTUSMART (ex)(r)CM03 F(S)QT

87

Spare parts ACTUSMART (ex)(r)CM06 F(S)QT

89

Manual for 90-Degree Failsafe-Actuators - CMFSQT

SEC-DS-ENGLISH-CMFSQT-V1.06-2021.02.23

1 Safety instructions

WARNING

When operating electrical devices, certain parts are inevitably under dangerous voltage. Work on the electrical systems or components may only be carried out by electricians or by individuals who have been instructed how to do so, working under the guidance and supervision of an electrician in accordance with electro technical regulations.



When working in potentially explosive areas, heed European Standards EN 60079-14 "Installing Electrical Systems in Explosion Endangered Areas" and EN 60079-17 "Inspection and Maintenance of Electrical Installations in Explosion Endangered Areas". Working in potentially explosive areas is subject to special regulations (European Standard EN 60079-17), which must be complied with. Any additional national regulations must be heeded.



Working on the opened and energized actuator may only be carried out if it is ensured that there is no risk of explosion for the duration of the work.



2 Introduction

NOTICE: Also consider the Operating Manual for ACTUSMART CM.V1.2 starting at page 25!



90° Actusafe actuators are designed to operate appropriate fittings when a fail-safe functionality is required. Appropriate fittings are all kinds of fittings that require a 90° movement to operate (butterfly valves, ball valves, taps in general, etc.).

In the event of a power failure or if the fail-safe function is triggered deliberately, the 90° Actusafe actuator shifts the fitting to the fail-safe position, using the built-in energy storage device to do so.



Figure 1: CMFSQT-Actuator

3 Functional Description of the CM FSQT Failsafe Drive

3 Functional Description of the CM FSQT Failsafe Drive

In normal operation, the actuator is operated by a motor (1). Via a worm gear stage (2) and a planetary gear train (3), the motor drives the spindle nut of a ball screw (4). The sun gear shaft of the planetary gear train is fixed by an operating current brake (5).

The ball screw converts the rotational movement of the gear unit into linear motion. On the one hand the linear movement, charges the spring (7), which acts as an energy storage device. On the other hand, a rack-and-pinion gear (6) converts the linear motion into the 90° output motion to move the fitting shaft (9).

There are no engaging or disengaging elements between the motor, the energy storage device and the fitting shaft in the actuator. All the gear unit components are permanently engaged.

While moving against the fail-safe direction, the electric motor has to move both the fitting and the energy storage device (spring) for the fail-safe stroke.

If the supply for the operating current brake is interrupted (by a power failure, or intentionally to trigger a fail-safe stroke, the actuator will no longer be held, and the potential energy stored in the spring will be converted into kinetic energy to move the actuator and thereby the fitting to the fail-safe position. In this case, the entire gear chain for the actuator except of the worm gear stage will be moved until the adjustable, mechanical end stop (8) is reached or, if applicable, the stop for the fitting.

Owing to this operating principle, neither an initialising stroke nor resetting of the actuator is required after a fail-safe stroke. As soon as the power supply is restored, the actuator is immediately ready for operation.




Figure 2: 1... Motor, 2... Worm gear stage, 3... Planetary gear train, 4... Ball screw, 5... Operating current brake, 6... Rack-and-pinion gear, 7... Spring, 8... End stop, 9... Fitting shaft

3.1 Failsafe-direction

This failsafe actuator can be built as a version for “Failsafe CCW” (counter-clockwise direction of rotation when looking at the fitting shaft), see Figure 3, or “fail-safe CW” (clockwise direction of rotation). It is even possible to subsequently change the fail-safe direction (separate manual available), see Figure 4. Some assembly work is required for that. Having this conversion performed at our plant is recommended, however.




Figure 3: Fail-safe-direction counter clockwise (CCW)




Figure 4: Fail-safe-direction clockwise (CW)

3.2 Moving-behaviour of the actuator

How the actuator moves to the end limits depends on whether the actuator is in failsafe mode or in electrical mode.

3.2.1 Moving behaviour electrical mode

- **Moving in failsafe direction**

In this case the actuator moves in failsafe direction electrically by motor till the adjusted electrical end position. If the end limit is set travel dependent the actuator stops at this point. If the end limit is set torque dependent the actuator moves electrically till the end position. In the end position the electrical holding brake is released and the actuator build up the torque by the tensioned spring. **Attention: For torque dependent end limit the end position should be set in a sufficient range before the mechanical end position to avoid damage on the valve.**

- **Moving counter failsafe direction**

The actuator moves to the end position electrically by motor. If the end limit is set torque dependent the torque is build up by the motor. **Attention: For torque dependent end limit the end position should be set in a sufficient range before the real end position to avoid damage on the valve.**

3.2.2 Moving behaviour failesafe mode

- **Moving in failsafe direction**

In failsafe mode the actuator can only move in failsafe direction. When the electrical holding brake is released the actuator moves against the end limit by spring. In this case the end limit is generally torque dependent. The torque in end position is build up by the residual spring torque. Travel depended positioning of the end limit is possible by adjusting the mechanical end stops from the actuator. Thus the mechanical end position can be set from 85° to 95°.

The mechanical end stops in the actuator are not designed to move against them by torque regularly!



4 General Information

4.1 Serial number

See operating manual ACTUSMART CM.V1.2, section 2.2, page 25

4.2 Protection class

See operating manual ACTUSMART CM.V1.2, section 2.4, page 26

4.3 Mounting position

See operating manual ACTUSMART CM.V1.2, section 2.5, page 26

4.4 Direction of rotation

The standard direction of rotation for the actuator is:

- Clockwise = The actuator runs counter to the failsafe direction
- Counter-clockwise = The actuator runs in the failsafe direction



Which direction, opening or closing of the fitting causes, depends on:

- The fail-safe direction of the actuator
- The closing direction of the fitting



All the information in this Operating Manual refers to the standard direction of rotation.

4.5 Protective devices

See operating manual ACTUSMART CM.V1.2, section 2.7, page 27

4.6 Ambient temperature

See operating manual ACTUSMART CM.V1.2, section 2.8, page 27

4.7 Condition on delivery of the actuators

See operating manual ACTUSMART CM.V1.2, section 2.9, page 28

4.8 Note (tag)

See operating manual ACTUSMART CM.V1.2, section 2.10, page 28

5 Transport and Storage

See operating manual ACTUSMART CM.V1.2, section 3, page 28

6 Installation Instructions

Installation work of any kind for the actuator may only be performed by qualified personnel.

6.1 Mechanical connection

Check,

- whether the fitting flange and actuator flange match up
- whether the drilled hole matches up with the shaft
- whether there is sufficient engagement of the fitting shaft in the actuator hole

The actuator must not be electrically supplied during the installation work!

On delivery and as long as the failsafe actuator is not electrically connected, it is in the failsafe position. Make sure the fitting is in the same position as the actuator:



- **For a “failsafe open” actuator, the fitting has to be completely open.**
- **For a “failsafe close” actuator, the fitting has to be completely closed.**

In general, heed the following instructions:

- Clean the bare parts on the actuator coated with rust protectant.
- Clean the mounting surface for the fitting thoroughly.
- Lightly grease the fitting shaft.
- Set the actuator in place.
- Make sure of centred positioning and that the contact surface of the flange is full.
- Fasten the actuator with suitable bolts:
 - Minimum strength grade: 8.8 or A2-70
 - Ensure sufficient thread engagement (min. 1xd)

Screws that are too long may go against the thread root, creating the risk of the actuator moving radially vis-à-vis the fitting. This may lead to the bolts shearing off.



NOTICE: Unsuitable bolts may result in the actuator falling off!

- Tighten bolts to the correct torque, alternating between bolts on opposite sides

Thread	Tightening torque [Nm] for bolts with strength grade	
	8.8	A2-70 / A4-70
M6	11	8
M8	25	18
M10	51	36
M12	87	61
M16	214	150
M20	431	294
M30	1489	564

6.2 Mounting position of the control unit

See operating manual ACTUSMART CM.V1.2, section 4.2, page 31

6.3 Electrical connection

See operating manual ACTUSMART CM.V1.2, section 4.3, page 31

7 Commissioning

It is assumed that the actuator has been installed and electrically connected correctly. (See section 6, page 11)

NOTICE: Remove silica gel from the alarm cover.



Technical data

Type	Max. actuators torque [Nm]		Revolutions on the basic actuator			
	In failsafe direction	Counter failsafe direction	nominal [°]	Revolutions [U]	maximal [°]	Revolutions [U]
CM03FSQT30	8	17	90	16,02	100	17,8
CM03FSQT60	8	29	90	15,71	100	17,45
CM06FSQT100	16	64	90	9,42	100	10,47
CM06FSQT200	16	57	90	31,42	100	34,9
CM06FSQT300	16	62	90	39,27	100	43,63
CM06FSQT500	16	64	90	60,87	100	67,63

7.1 General information

NOTICE: When commissioning and each time after dismantling the actuator, the electrical end positions have to be reset (see operating manual ACTUSMART CM.V1.2, section 5.4, page 33).

7.2 Manual operation

The manual operation is only possible if the actuator is delivered with the optional handwheel. This option allows an adjustment of the valve in de-energized state.

Caution:

- By activating the manual drive the failsafe function is disabled
- By activating the manual drive the electrical function of the drive is disabled. In normal operation, the hand wheel (9) has no effect, it rotates idly by.



- Note: The manual mode can be activated only when the drive is in the failsafe position.




Figure 5: 9... Handwheel, 10... coupling rod, 11... padlock

7.2.1 Direction of rotation handwheel for closing the valve, Failsafe direction „CW“




Figure 6: Rotation of direction for Failsafe direction „CW“.

7.2.2 Direction of rotation handwheel for closing the valve, Failsafe direction „CCW“




Figure 7: Rotation of direction for Failsafe direction „CCW“.

7.2.3 Activate manual operation

To activate manual mode:

- the padlock has to be removed
- the coupling rod has to be pushed all the way into the actuator.

For easier clutch engagement move the hand wheel easily back and forth.

Through the engagement the actuator is automatically electrically disabled and the display shows „manual operation“.

7.2.4 Deactivate manual operation

To exit the manual mode and enable the actuator again for the automatic mode must:

- the actuator be driven in the failsafe position by handwheel.
- the coupling rod be pulled up to the stop of the actuator.
- the coupling rod again secured with the padlock.

7.2.5 Required force on the handwheel

The following table shows the maximum force applied to the handwheel for the different actuator sizes.

Type	Max. handwheel torque [Nm]		Handwheel diameter [mm]
	In failsafe direction	Counter failsafe direction	
CM03FSQT30	4	8,5	140
CM03FSQT60	4	14,5	140
CM06FSQT100	8	32	200
CM06FSQT200	8	28,5	200
CM06FSQT300	8	31	200
CM06FSQT500	8	32	200



The force on the handwheel was calculated for one-handed operation. With two-hand operation, the value per hand is halved. The maximum force may be exceeded by 20% in manual mode.

The direction of rotation and the maximal handwheel torque are written on the handwheel label, as shown on figure above.

7.3 Mechanical default setting, preparation

See operating manual ACTUSMART CM.V1.2, section 5.3, page 33

7.4 Setting the end positions

See operating manual ACTUSMART CM.V1.2, section 5.4, page 33

7.5 Setting the mechanical end stop

The 90° fail-safe actuator only has one limited mechanical end stop that limits the travel at the fail-safe end position. The end stop is at the end of the spring cup.




Figure 8: 1... Locknut, 2... End stop




Figure 9: 1... Locknut, 2... End stop

To adjust the end stop, first undo the locknuts.
To lengthen the stroke by means of the end stop, unscrew the end stop out of the cover flange.

Note: Upon delivery, the end stop is set to the maximum possible stroke. Further unscrewing causes no further extension of stroke; the end stop becomes ineffective. This must be ruled out no matter what.



Check:

- In failsafe operation, let the actuator run against the stop.
- Despite the locknut being undone, it must not be possible to screw the end stop further into the cover flange.

NOTICE: If the stroke is to be shortened by means of the end stop, the actuator must not be in the fail-safe position. Before adjusting, it is necessary to move the actuator electrically at least 10% away from the end position.

After undoing the locknut, screw the end stop into the cover flange, and check the adjustment of the end stop by triggering a fail-safe stroke



NOTICE: In electrical operation, it is not permissible for the mechanical end stop to be run into. After adjusting the mechanical end stop, check the setting of the travel end position and correct it if necessary.



After completing the adjustment work, fix the locknuts back in place!

7.6 Adjusting of Failsafe speed

General:

Schiebel CM Failsafe actuators are equipped with an adjustable passive eddy current brake, by which it is possible to change the failsafe speed. When delivered the failsafe speed is set to minimum.

After mounting the actuator to valve and test run, failsafe speed can be increased if necessary.

ATTENTION: Valve or piping may be damaged due to high actuating speed!



Setting procedure:

All adjustment work may only be performed with the actuator disconnected from the power supply.
Due to this requirement, the actuator has to be in the fail-safe position!
Any powering up must be ruled out during maintenance!



When working in potentially explosive areas, heed European Standards EN 60079-14
“Installing Electrical Systems in Explosion Endangered Areas” and EN 60079-17
“Inspection and Maintenance of Electrical Installations in Explosion Endangered Areas”






Figure 10: Cover removing

1. Remove cover according Figure 10, page 18
Attention: In the version with handwheel there is a cable connection which has to be unplugged.
2. Loosen but do not remove 4pcs of screws according Figure 11, page 19
3. Insert 3mm allen key into radial borehole of flange.
4. Turn flange by use of allen key in direction according Figure 11, page 19
 Half of possible rotating angle will approximately double failsafe speed of actuator.
 While holding flange with key in desired position retighten screws.
5. In the version with handwheel reconnect the cable to the cover
6. Remount the cover while be aware of correct position of O-ring sealing
7. Retest actuator to check for correct failsafespeed




Figure 11: Adjusting speed

7.7 Final work

See operating manual ACTUSMART CM.V1.2, section 5.5, page 36

8 The control unit

See operating manual ACTUSMART CM.V1.2, section 6, page 36

9 Maintenance

All maintenance work may only be performed with the actuator disconnected from the power supply.

Due to this requirement, the actuator has to be in the fail-safe position!

If this is not the case, it may be because of a fault in the fitting (stuck valve stem).



WARNING

The actuator has a pre-loaded coil spring or a disk spring assembly! When loosening the flange mounting bolts, the spring force against the valve can cause the actuator to come loose from the valve. Adequate safety measures must be taken



WARNING

Any powering up must be ruled out during maintenance! Work on the electrical systems or components may only be carried out by electricians or by individuals who have been instructed how to do so, working under the guidance and supervision of an electrician in accordance with electro technical regulations. After completing their commissioning, the actuators are ready for use. The actuator is filled with oil as standard when shipped.



Routine checks:

- Be mindful of increased running noises. In cases of long down times, operate the actuator at least every three months.
- Check the fail-safe function (check the operating time and smoothness of running in fail-safe operation). Lengthening in the running time may also be caused by an increased torque requirement for the fitting after long down times.

WARNING

The actuator has a pre-stressed coil spring or disk spring assembly. Improper dismounting may lead to both damage to the actuator as well as serious injuries! If maintenance work is needed requiring the actuator to be dismantled, contact SCHIEBEL Antriebstechnik GesmbH regarding detailed instructions and/or any special-purpose tools for relaxing the spring assembly!



The actuators are designed for any mounting position (See section 4.3, page 10), which is why there is neither a filling level indicator nor a drain plug on the main casing.

Depending on the stressing subjected to, do the following approx. every 10,000 to 20,000 hours (about 5 years; see section 12, page 21):

- Oil change
- Replace seals
- Check all the roller bearings and the worm gear assembly and replace if necessary.

Take the types of oils and greases to be used from our Lubricant Table. (See section 12, page 21)

Check the cable glands at regular intervals (annually) for tightness of the cables and retighten if necessary.



If the visual inspection (eg. dust or water penetration) indicates that the effectiveness of the Sealing elements of the cable entry has suffered damage or aging, such elements have to be replaced preferably by using the original spare parts from the manufacturer of the equipment or through cable entries of comparable quality as well as the same ex- or IP protection class.

10 Technical data failsafe brake

10.1 CM03FSQT

Torque: 15 Nm
 Power: 16 W
 Voltage: 24 V
 Current: 0,67 A

10.2 CM06FSQT

Torque: 30 Nm
 Power: 21 W
 Voltage: 24 V
 Current: 0,875 A

11 Spare parts

When ordering spare parts, let us know the serial number of the actuator.
 A separate exploded diagram and a spare parts list is available for selecting spare parts.

12 Lubricant recommendation / Lubricant requirements

See operating manual ACTUSMART CM.V1.2, section 15, page 69

12.1 Lubricant points FSQT

The table values given apply to relubrication in accordance with the relubrication intervals in the operating instructions. After relubrication has been carried out, 2-3 full strokes must be performed. If torque switch off occur, the grease nipples must be removed and the strokes repeated.

ATTENTION: Lubricant can leak out of the lubrication points.

After that the grease fittings should be installed .

At initial assembly or upon complete disassembly of the spindle nut is filled, all gears and bearings pocketed filling. All moving parts as well as internal surfaces are coated to cover them.

→ Lubricant quantity according to expenditure

→ Lubricant specification according to the operating instructions depending on the temperature range

Type	Lubrication point [Quantity]		
	1	2	3
	Main gear	Bearing spindle drive	Intermediate gear
	[cm ³]	[cm ³]	[cm ³]
CM03FSQT30	8	-	-
CM03FSQT60	18	-	-
CM06FSQT100	20	42	-
CM06FSQT200	20	68	29
CM06FSQT300	20	90	59
CM06FSQT500	20	80	90




Figure 12: Lubrication points

For more information, see manual ACTUSMART CM.V1.2, section 15, page 69.

12.2 Basic lubricant service interval

See operating manual ACTUSMART CM.V1.2, section 15, page 69

13 Training

NOTICE: Should you experience any problems during installation or in doing the adjustment work on site, please contact SCHIEBEL, Vienna, either by telephone on +43 (1) 66 108 or via Internet at www.schiebel-actuators.com so as to avoid any possible faulty operation or damage to the actuators. Schiebel recommends only using qualified personnel to do the installation work for Schiebel actuators. On special request by SCHIEBEL customers, training courses can be conducted at SCHIEBEL's plant for the work listed in this Operating Manual.



14 Mode of operation FSQT

14.1 CM03 FSQT

ON-OFF & INCHING operation	
CM03 FSQT 30	CM06 FSQT 60
S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034
2,5 - 72 RPM	2,5 - 72 RPM
$M_{max} = 300 \text{ Nm}$	$M_{max} = 600 \text{ Nm}$
$M_{avg} = 150 \text{ Nm}$	$M_{avg} = 300 \text{ Nm}$
Life time*	
10.000 cycles	10.000 cycles

MODULATING operation	
CM03 FSQT 30	CM06 FSQT 60
S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034
2,5 - 36 RPM	2,5 - 36 RPM
$M_{max} = 300 \text{ Nm}$	$M_{max} = 600 \text{ Nm}$
$M_{avg} = 150 \text{ Nm}$	$M_{avg} = 300 \text{ Nm}$
Life time*	
1.200.000 starts	1.200.000 starts

CONTINUOUS MODULATING operation	
CM03 FSQT 30	CM06 FSQT 60
S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034
2,5 - 20 RPM	2,5 - 20 RPM
$M_{max} = 300 \text{ Nm}$	$M_{max} = 600 \text{ Nm}$
$M_{avg} = 100 \text{ Nm}$	$M_{avg} = 200 \text{ Nm}$
Life time*	
1.200.000 starts	1.200.000 starts

*ATTENTION: life time is based on proper operation and maintenance according to SCHIEBEL operating manual

CYCLE = movement of 90° in both directions with at least 30% of nominal force and the ability to accept 100% of nominal torque for at least 5% of the stroke

START = movement of at least 1° of stroke in both directions with a load of minimum 30% of nominal torque

14.2 CM06 FSQT

ON-OFF & INCHING operation			
CM06 FSQT 100	CM06 FSQT 200	CM06 FSQT 300	CM06 FSQT 500
S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034
2,5 - 60 RPM	2,5 - 60 RPM	2,5 - 60 RPM	2,5 - 60 RPM
$M_{max} = 1.000 \text{ Nm}$	$M_{max} = 2.000 \text{ Nm}$	$M_{max} = 3.000 \text{ Nm}$	$M_{max} = 5.000 \text{ Nm}$
$M_{avg} = 300 \text{ Nm}$	$M_{avg} = 600 \text{ Nm}$	$M_{avg} = 900 \text{ Nm}$	$M_{avg} = 1.500 \text{ Nm}$
Life time*			
10.000 cycles	5.000 cycles	5.000 cycles	2.500 cycles

MODULATING operation			
CM06 FSQT 100	CM06 FSQT 200	CM06 FSQT 300	CM06 FSQT 500
S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034
2,5 - 30 RPM	2,5 - 30 RPM	2,5 - 30 RPM	2,5 - 30 RPM
$M_{max} = 1.000 \text{ Nm}$	$M_{max} = 2.000 \text{ Nm}$	$M_{max} = 3.000 \text{ Nm}$	$M_{max} = 5.000 \text{ Nm}$
$M_{avg} = 500 \text{ Nm}$	$M_{avg} = 1.000 \text{ Nm}$	$M_{avg} = 1.500 \text{ Nm}$	$M_{avg} = 2.500 \text{ Nm}$
Life time*			
1.200.000 starts	500.000 starts	500.000 starts	250.000 starts

CONTINUOUS MODULATING operation			
CM06 FSQT 100	CM06 FSQT 200	CM06 FSQT 300	CM06 FSQT 500
S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034
2,5 - 20 RPM	2,5 - 20 RPM	2,5 - 20 RPM	2,5 - 20 RPM
$M_{max} = 1.000 \text{ Nm}$	$M_{max} = 2.000 \text{ Nm}$	$M_{max} = 3.000 \text{ Nm}$	$M_{max} = 5.000 \text{ Nm}$
$M_{avg} = 300 \text{ Nm}$	$M_{avg} = 600 \text{ Nm}$	$M_{avg} = 900 \text{ Nm}$	$M_{avg} = 1.500 \text{ Nm}$
Life time*			
1.200.000 starts	500.000 starts	500.000 starts	250.000 starts

***ATTENTION: life time is based on proper operation and maintenance according to SCHIEBEL operating manual**

CYCLE = movement of 90° in both directions with at least 30% of nominal force and the ability to accept 100% of nominal torque for at least 5% of the stroke

START = movement of at least 1° of stroke in both directions with a load of minimum 30% of nominal torque

Operating Manual ACTUSMART CM.V1.2

1 Introduction/Notes

These operating instructions apply to SCHIEBEL actuators of the ACTUSMART CM series.

The scope of application covers the operation of industrial valves, e.g., globe valves, gate valves, butterfly valves and ball valves. For other applications please consult with the factory.

The manufacturer shall not be liable for incorrect use and possible damage arising thereof. The risk shall be borne solely by the user.

Using the unit as intended also entails the observance of these operating instructions!



When operating electrical equipment, certain parts inevitably carry hazardous voltage levels. Work on the electrical system or equipment must be carried out only in accordance with electrical regulations by a qualified electrician himself or by specially instructed personnel under the control and supervision of a qualified electrician.

Maintenance instructions must be observed as otherwise the safe operation of the actuator cannot be guaranteed.

Failure to follow the warning information may result in serious bodily injury or property damage. Qualified personnel must be thoroughly familiar with all warnings contained in this operating manual.

Proper transport, storage, installation, assembly and careful commissioning are essential to proper and safe operation.

When working in potentially explosive areas, observe the European Standards EN 60079-14 "Electrical Installations in Hazardous Areas" and EN 60079-17 "Inspection and Maintenance of Electrical Installations in Hazardous Areas".



Maintenance work on open actuators may only be conducted if these are de-energized. Reconnection during maintenance is strictly prohibited.



2 General

The actuator of the ACTUSMART CM series is a compact rotary actuator with integrated controller for valve operation. The integral multi-turn sensor allows setting the travel up to 105 revolutions without opening the housing.

2.1 Overview




Figure 13: 1... Handwheel, 2... Control unit (operating unit), 3... Connection compartment 4... Gear component

2.2 Serial number and type label

Each actuator of the ACTUSMART CM series carries a serial number. The serial number is a 10-digit number that begins with the year and that can be read from the type label (see Figure 14) of the actuator (the type label is located next to the handwheel – see Figure 15).

Using this serial number, SCHIEBEL can uniquely identify the actuator (type, size, design, options, technical data and test report).

Type: CM06.V1.2 E
 No.: 20114 00885
 Close: 16,0-64Nm (64Nm)
 Open: 16,0-64Nm (64Nm)
 300revs. 300-7200sec
 2,5-60rpm IP67
 I_N: 2,85A/230VAC
 1x110V-240V ±10% AC/DC

SCHIEBEL 
 2020

Josef Benc Gasse 4, 1230 Vienna, Austria 200352/3 

Figure 14: Type label



Figure 15: 1... Type label

Actuators which are suitable for operation in explosive atmosphere (see EU Directive 94/9/EG and EN 60079-0 Standard) are separately designated by a special type label (EEx, TÜV Standard, Figure 16).




Type: exCM06.V1.2	SCHIEBEL 
No.: 19114 01051	1026 2019
Close: 16,0-64Nm (16,0Nm)	
Open: 16,0-64Nm (64Nm)	Tamb-40...+60°C
61revs. 61-1462sec	 II 2 G Ex db eb IIC T4 Gb
2,5-60rpm IP67	TÜV-A 13ATEX0006X
I _N : 0,84-0,67A	
3x380-480V 50/60Hz	
S2-15min	
Josef Benc Gasse 4, 1230 Vienna, Austria 191190/1	

Figure 16: Type label of the actuator for operation in explosive atmosphere

2.3 Operating mode

ACTUSMART CM actuators are suitable for open-loop control (S2 operating mode – on/off duty) and closed-loop control (S4 operating mode – modulating duty) according to EN 60034-1.

2.4 Protection class

ACTUSMART CM actuators come by default with IP 67 (EN 50629) protection.

CAUTION: The protection class specified on the type label is only effective when the cable glands also provide the required protection class, the cover of the connection compartment is carefully screwed closed, and the mounting position (see section 2.5, page 26) is observed.



We recommend metallic screwed cable glands with a metrical thread. Furthermore, cable inlets that are not needed must be closed with screw plugs. On explosion-proof actuators, cable glands with protection class **EEx e acc. EN 60079-7** must be used. **After removing covers** for assembly purposes or adjustment work, take special care upon reassembly so that seals are not damaged and remain properly fastened. Improper assembly may lead to water ingress and to failures of the actuator.



The cover of the control unit – the operating unit (see Figure 13, page 25) – must not be opened!

Allow a certain sag in the connector cables before reaching the screwed cable glands so that water can drip off from the connector cables without running to the screwed cable glands. This way, forces acting on the screwed cable glands are also reduced (see section 2.5).



2.5 Mounting position

Generally, the installation position is irrelevant. However, based on practical experience, it is advisable to consider the following for outdoors use or in splash zones:

- Mount actuators with cable inlet facing downwards.
- Ensure that sufficient cable slack is available.

2.6 Direction of rotation

Unless specifically ordered otherwise, the standard direction is (see Figure 17 and Figure 18):

- **right turning (clockwise) = CLOSING**
- **left turning (counter-clockwise) = OPENING**



Clockwise rotation of the actuator is given when the output shaft turns counter clockwise when looking at the output shaft.




Figure 17: clockwise = close




Figure 18: counter-clockwise = close

CAUTION: All specifications in this operating manual refer to the standard direction of rotation.



2.7 Protection devices

2.7.1 Torque

ACTUSMART actuators provide electronic torque monitoring.

The switch-off torque can be modified in the controller menu for each direction separately. By default, switch-off torque is set to the ordered value. If no torque was specified with the order, the actuator is supplied from the factory with the maximum configurable torque.

For more information, see section 7.2, page 46.

2.7.2 Motor temperature

All ACTUSMART CM actuators are normally equipped with motor winding temperature sensors, which protect the motor against excessive winding temperature.

The display will show the corresponding error upon exceeding the permissible motor temperature (see section 12.1, page 67).

2.7.3 Input fuse, thermal fuse

The frequency inverter is protected by an input fuse and the explosion-proof version also has a thermal fuse. If one of these fuses releases, a serious defect occurs and the frequency inverter will be disconnected permanent from the power supply. Then the frequency inverter must be changed.

2.8 Ambient temperature

Unless otherwise specified upon ordering, the following operating temperatures apply:

- On/off duty (open-loop control) -25 ... +60 °C
- Modulating duty (closed-loop control) -25 ... +60 °C
- explosion-proof version -20 ... +40 °C (acc. EN 60079-0)
- explosion-proof version with extended temperature range -40 ... +60 °C

CAUTION: The maximum operating temperature can also depend on further order-specific components. Please refer to the technical data sheets to confirm the as-delivered product specifications.



2.9 Delivery condition of the actuators

For each actuator, an inspection report is generated upon final inspection. In particular, this comprises a full visual inspection, calibration of the torque measurement in connection with an extensive run examination and a functional test of the micro controllers.

These inspections are conducted and documented according to the quality system and can be made available if necessary. The basic setting of the end position must be performed after assembly on the actuator.

CAUTION: Commissioning instructions (see section 5, page 33) must be strictly observed!

During assembly of the supplied valves at the factory, end positions are set and documented by attaching a label (see Figure 19). During commissioning at the plant, these settings must be verified.




Figure 19: Label

2.10 Information notice (tag)

Each actuator is provided with a bilingual tag containing key information, which is attached to the handwheel after final inspection. This tag also shows the internal commission registration number (see Figure 20, page 28).




Figure 20: Tag

3 Packaging, transport and storage

Depending on the order, actuators may be delivered packed or unpacked. Special packaging requirements must be specified when ordering. Please use extreme care when removing or repackaging equipment

CAUTION: Use soft straps to hoist the equipment; do not attach straps to the handwheel. If the actuator is mounted on a valve, attach the hoist to the valve and not to the actuator.



3.1 General

The connection compartment of ACTUSMART CM actuators contains 5 g of factory supplied silica gel.

CAUTION: Please remove the silica gel before commissioning the actuator (see section 5, page 33).



3.2 Storage

CAUTION: Please observe the following measures to avoid damage during the storage of actuators:

- Store actuators in well-ventilated, dry premises.
- Protect against floor dampness by storing actuators on wooden grating, pallets, mesh boxes or shelves.
- Protect the actuators against dust and dirt with plastic foil.
- Actuators must be protected against mechanical damage.
- The storage temperature must be between -20°C and +40°C.

It is not necessary to open the controller of the actuator for servicing batteries or similar operations.

3.3 Long-term storage

CAUTION: If you intend to store the actuator for more than 6 months, additionally follow the instructions below:



- **CAUTION:** The silica gel in the connection compartment must be replaced after 6 months of storage (from date of delivery from SCHIEBEL's factory in Vienna).
- After replacing the silica gel, brush the connection cover seal with glycerine. Then, carefully close the connection compartment again.
- Coat screw heads and bare spots with neutral grease or long-term corrosion protection.
- Renovate damaged paintwork arising from transport, improper storage, or mechanical influences.

CAUTION: For explosion-proof actuators, it is not allowed to extensively overpaint the actuator. According to the standard, in order to avoid electrostatical charge, the maximal thickness of the varnish is limited to 200 µm.



- Every 6 months, all measures and precautions for long-term storage must be checked for effectiveness, and corrosion protection and silica gel must be renewed.
- Failure to follow the above instructions may lead to condensation which can damage the actuator.



4 Installation instructions



Figure 21: 1... mounting flange, 2... bore pattern G0/F10, 3... centring ring, 4... bore pattern F07, 5... shaft connection, 6... ground connection

Installation work of any kind on the actuator may only be performed by qualified personnel.

4.1 Mechanical connection

see Figure 21, page 30

Check whether the valve flange, actuator flange and valve shaft correspond to the shaft connector of the actuator. For output type "Am" (threaded bushing with bore), check whether the thread of the valve matches the thread of the actuator. In general, proceed as follows:

- Clean the bare parts of the actuator uncoated with corrosion protection.
- Thoroughly clean the screw mounting surfaces of the valve.
- In the actuator, appropriately lubricate the output shaft and the valve of the driven shaft.
- In the "Am" version, ensure that the valve bushing is amply lubricated.
- Attach the actuator to the valve or gearbox.
- Tighten fastening screws (torque according to table below).
- By means of the handwheel, check the ease of movement of the actuator-valve connection.

Thread	Tightening [Nm] for screws with strength class	
	8.8	A2-70 / A4-70
M6	11	8
M8	25	18
M10	51	36
M12	87	61
M16	214	150
M20	431	294
M30	1489	564

For output type A (unbored threaded bushing), you must sufficiently lubricate both needle bearings in the output form after processing and cleaning the spindle nut.

For this purpose, use the optional SCHIEBEL grease lubricant or a grease lubricant according to our recommendation (see section 15.3, page 70).

4.2 Mounting position of the operating unit

The mounting position of the operating unit can be rotated in 90° steps.

Attention: During installation, the position of the control unit in relation to direct sunlight must be observed. It is recommended to protect the unit from direct sunlight (roof, installation position) to avoid possible malfunctions.




Figure 22

- Disconnect the actuator and control system from the power supply.
- To prevent damage to the electronic components, both the control system and the person have to be earthed!
- Unscrew the bolts for the interface surface and carefully remove the service cover.
- Turn service cover to new position and put back on.
 - Ensure correct position of the O-ring.
 - Turn service cover by max. of 180°.
 - Put service cover on carefully so that no cables get wedged in.
- Screw the bolts shut evenly in a crosswise sequence. IMPORTANT: max. torque 5 Nm



4.3 Electrical connection

Electrical connections may only be carried out by qualified personnel.
Please observe all relevant national security requirements, guidelines, and regulations.
The equipment should be de-energized before working on electrical connections.
Furthermore, confirm the absence of electrostatic discharges during the connection.
First of all, connect the ground screw.



The line and short circuit protection must be done on the system side.
The ability to unlock the actuator for maintenance purposes must be provided.
For the dimensioning, the rated current is to be used (see Technical Data).



Check whether the power supply (voltage, frequency) is consistent with the connection data (see type label – Figure 14, page 26)
The connection of electrical wiring must follow the circuit diagram. This can be found in the appendix of the documentation. The circuit diagram can be ordered from SCHIEBEL by specifying the serial number.
When using options, such as a Profibus connection, the relevant guidelines must be followed.



4.3.1 Power supply connection

ACTUSMART CM actuators feature an integrated motor controller, i.e. only a connection to the power supply is required. In **non explosion-proof actuators**, the wiring uses a connector independent from control signals (see Figure 23, page 32).




Figure 23: 1... Metric screw M32x1,5, 2... M40x1,5, 3... M25x1,5, 4... Plug insert Han6E (for power supply), 5... Plug insert Han24E (for control cables), 6... Connector for options, 7... Connector plate, 8... Connecting housing

The connection on **explosion-proof actuators** or, on special request also on non explosion-proof actuators) will be made via terminals (see Figure 24).




Figure 24: Terminal box: 1... Metric screw M40x1,5, 2... 2 pcs. M20x1,5, 3... Terminals for the control signals, 4... Terminals for the power supply, 5... Terminal for ground connection, 6... Outside ground connection

If, during outdoor installation, commissioning is not carried out immediately after electrical connection, the power supply must be connected at a minimum to achieve a heating effect. In this case, the silica gel may remain in the connection compartment until commissioning.

CAUTION: see section 3.3, page 29



5 Commissioning

Before commissioning, ensure that the actuator is correctly assembled and electrically connected (see section 4, page 30).

CAUTION: Remove silica gel from the connection compartment.

5.1 General

CAUTION: During commissioning and after every disassembly of the actuator, the electric end positions (see section 5.4, page 33) must be reset.



5.2 Manual operation

The use of a differential gearbox in the handwheel assembly makes mechanical switching unnecessary during manual operation.

CAUTION: Manual operation with mechanical or electromechanical equipment (such as: lever, drilling machine, etc.) is NOT ALLOWED, as this may damage the product.



5.3 Mechanical default settings, preparation

The use of multi-turn sensors makes mechanical settings unnecessary.

CAUTION: Before the motorised operation of the valve, it is essential to check and eventually adjust torque settings.



5.4 End limit setting

A detailed description of the operation of the ACTUSMART CM controller can be found in section 6.3, page 39.

5.4.1 End limit OPEN

Set the selector switch and control switch to the center position.




Figure 25: 1... Selector switch (red), 2... Control switch (black)

Scroll through the menu with the control switch. Move the control switch towards the first menu item \ominus "P 1.1 End limit – Open".




Figure 26




Figure 27

Afterwards, flip up the selector switch slightly and let it snap back to its neutral position (⊙).




Figure 28




Figure 29



Figure 30

This changes the bottom line of the display from "EDIT?" to "SAVE?"




Figure 31




Figure 32

Then, push down the selector switch until it snaps into place. In doing so, the bottom right now on the display will show "TEACHIN" (⊗)

CAUTION: Once the display shows "TEACHIN", use the operating switch (black switch) to start the motorised operation of the actuator. In this mode, no travel-dependent switch off occurs in the end position.



CAUTION: Please note that, during motor operation, only torque monitoring remains active, as travel adjustment will happen subsequently. Therefore, please check beforehand whether the maximum torque has been already parameterised.



Absolute and relative values on the display will change continuously along with position changes.




Figure 33




Figure 34

Manually move the actuator with the handwheel (see section 2.1, page 25, or section 2.6, page 26) or by motor via the operating switch (black switch) to the end position OPEN of the valve.

- Absolute value: Absolute value of the position feedback
- Relative value: The value to the other end position




Figure 35: 1... Absolute value, 2... Relative value

When the desired end position OPEN of the valve is reached, move the selector switch back to the middle position. Thus, the line "TEACHIN" disappears.




Figure 36




Figure 37

In order to confirm the end position (save), slightly flip up the selector switch towards ☑ and let it snap back to its neutral position.




Figure 38




Figure 39




Figure 40

This changes the bottom line of the display for "SAVE?" to "EDIT?" and the end position is stored.




Figure 41




Figure 42

5.4.2 End limit CLOSE

Use menu item "P 1.2 End limit - End limit CLOSE" as for End limit OPEN

5.5 Final works

Following commissioning, check for proper sealing the covers to be closed and cable inlets (see section 2.4, page 26). Check actuator for paint damage (by transport or installation) and repair if necessary.

6 Control Unit

The controller is intended to monitor and control the actuator and provides the interface between the operator, the control system and the actuator.

6.1 Operating unit

Operation relies on two switches: the control switch and a padlock-protected selector switch. Information visualization is provided by 4 integrated indicator lights, as well as the graphic display. For better visibility, switch symbols (✓, ✗, ⊕, ⊖) are on the cover.




Figure 43: 1... Selector switch, 2... Control switch, 3... Graphic display, 4... LED display

The controller switches serve on the one hand for electric-motor operation of the actuator and, on the other hand, to configure and view various menu items.

The controller cover may be wiped clean with a damp cloth.

The mounting position of the control unit can be turned in 90° steps (see section 4.2, page 31).

6.2 Display elements

6.2.1 Graphic display

The graphic display used in the controller allows text display in different languages.




Figure 44

During operation, the displays shows the position of the actuator as a percentage, operation mode and status. When using the option "identification", a customer-specific label is shown at the bottom of the display (e.g., PPS Number).




Figure 45: 1... Status, 2... Operation mode, 3... Position

CAUTION: The display should not be exposed to direct sunlight over a long period - risk of a defect in combination with very high temperatures.



6.2.2 LED Display

To provide users with better status information, basic status data is displayed using 4-colour LEDs. As the device powers up, it undertakes a self-test whereby all 4 LEDs briefly lit up simultaneously.




Figure 46

Description	Colour	Lits up	Flashes quickly	Flashes slowly	Does not light up
L1	Yellow	No torque error	Torque fault	—	¹⁾
L2	Yellow	Ready (operational readiness)	Travel fault (no operational readiness!)	—	Error (no operational readiness) motor temperature, supply voltage absent, internal error ¹⁾
L3	Green ²⁾	CLOSE ³⁾	Moving to CLOSE position	Applies upon torque-dependent closing: Occurs when the end position CLOSE is reached but the cut-out torque has not yet been reached	Actuator is not in the CLOSE position.
L4	Red ²⁾	OPEN ³⁾	Moving to OPEN position	Applies upon torque-dependent opening: Occurs when the end position OPEN is reached but the cut-out torque has not yet been reached	Actuator is not in the OPEN position.
L5	Blue	Bluetooth connected	Bluetooth data transmission	Bluetooth ON, not connected	Bluetooth/Infrared OFF
	Red	Infrared connected	Infrared data transmission	Infrared ON, not connected	

6.3 Operation

The actuator is operated via the switches located on the controller (selection- and control switch). All actuator settings can be entered with these switches. Furthermore, configuration is also possible via the IR interface or the Bluetooth Interface (see section 9, page 64). Flip the switch up or down to regulate the parameter menu scrolling speed.

¹⁾ LED L1 and L2 are turned off as long as an infrared connection is active.

²⁾ Colour of LED L3 and L4 can be changed by parameter P1.7 - see section 7.1, page 44.

³⁾ A travel fault is indicated by a lit L3 and L4




Figure 47: Neutral position




Figure 48: Slight switch flip (it will move to the next parameter)




Figure 49: halfway switch flip (it will jump to the next parameter category)






Figure 50: Full switch flip (it will jump to the end of the menu)

6.3.1 Operation mode



Use the selector switch (red) to determine the various operating states of the actuator. In each of these positions, it is possible to block the switch by means of a padlock and thus protect the actuator against unauthorized access.

The selector switch has the following positions:

OFF	The actuator can be neither operated via the remote control nor via the control switches of the controller.
Local 	It is possible to operate the actuator by motor via the control switch. Control via the remote inputs may be possible with appropriate configuration (superimposed control commands, emergency commands)
Remote 	The actuator is ready to process control commands via input signals. The control switch for the motor operation of the actuator is not enabled.

Besides defining the operational status, the selector switch is used in configuration mode to confirm or cancel parameter inputs.

Depending on the selector switch position, the control switch performs different functions:

Selector switch in the OFF position:	The control switch is used to scroll up or down the menu according to internal symbolism. From the neutral position towards \oplus you reach the status and history data areas. Towards the \ominus symbols you reach the parameter menu. Here, the selection switch either confirms \checkmark or rejects \otimes the current input according to associated symbolism.
Selector switch in the REMOTE position 	The control switch gives you access to status, history data and parameter area.
Selector switch in the LOCAL position 	With the control switch, the actuator can be operated by motor. You may also operate the actuator in inching and self-hold mode. Switches are spring-loaded to snap back automatically into their neutral position. (To confirm a control command, the control switch must be pushed all the way into its mechanical locking position.)

6.3.2 Configuration

NOTE: Please make sure, that the set user level has permission to read/write the parameters.

In principle, all parameters are shown as numbers in the corresponding parameter point. From the actuator menu, use the control switch to access different menu points. The lower left corner of the display shows the "EDIT" option.




Figure 51

Confirm the selector switch (with a slight flip towards \checkmark , (see Figure 38, page 36 to Figure 40, page 36) to change the selected parameter. To confirm this input readiness, the display changes from "EDIT" to "SAVE".




Figure 52

Use the control switch towards to the characters to change the parameter. ⊕ or ⊖ (see Figure 47 til Figure 50, page 40) After reaching the desired parameter value, confirm the value with the selector switch (again, flip it slightly towards ✓, (see Figure 38, page 36 til Figure 40, page 36).

6.3.3 Configuration example

By way of example, we will change parameter P20.6 (wireless) from 0 (wireless off) to 2 (Bluetooth communication on). Thus, the Bluetooth connection is activated for a short time and then deactivated again automatically: The operating and control switch must be in the neutral position




Figure 53: 1... Selector switch (red) , 2... Control switch (black)

Now, move the control switch down (towards) until the menu item "P 20.6 Miscellaneous - Wireless" is displayed.



Figure 54




Figure 55

Afterwards, flip up slightly the selector switch (towards) and let it snap back to its neutral position




Figure 56




Figure 57




Figure 58

This changes the bottom line of the display from "EDIT?" to "SAVE?"




Figure 59




Figure 60

Thereafter, flip up the control switch (toward) to change the value from 0 (off) to 2 (Bluetooth)



Figure 61




Figure 62

If the value changes to 1, confirm the selection by flipping halfway up the selector switch (towards) and letting it snap back to its neutral position (see Figure 56 til Figure 58).




Figure 63




Figure 64

This changes the bottom line of the display from "SAVE?" to "EDIT?" and the parameter is stored.

6.3.4 „TEACHIN“

Furthermore, certain parameters (end positions, intermediate positions).can be set using "TEACHIN". Thus, their configuration is greatly simplified.

After selecting the appropriate menu item (for example: End position) and changing the the input type from "EDIT?" to "SAVE?", move the selector switch (red) to "manual mode" and lock it into place. As you do so, the display will show the message "TEACHIN" and the current position value will be applied continuously to the parameter value. In this mode, further to manual operation by hand wheel, the actuator can be motor-driven with the control switch to the desired position. (see section 34, Figure 34, page 35)




Figure 65

CAUTION: Please note that, during motor operation, only torque monitoring remains active, as travel adjustment will happen subsequently. Therefore, please check beforehand whether the maximum torque has been already set.



After reaching the desired, to-be-defined position, move the selector switch back to the neutral position. Finally, the parameter value must still be saved by flipping the selector switch halfway up and letting it snap back to the neutral position (see Figure 56 til Figure 58, page 43).

7 Parameter menu

For each parameter group, you can find a description, tabular overview of the menu items and possible configurations. The parameter list below also includes all possible options per menu item. Please note that some of the menu items listed and described may not be delivered with your configuration.

7.1 Parameter group: End limit

These parameters are used to configure the end position and switch off behavior of the actuator. In this regards, it is important to ensure that the basic mechanical configuration described in section 5.4, page 33 has already been made.

Ensure that these parameters are set during commissioning before operating the actuator. In addition, the settings in the "Torque" menu (see section 7.2, page 46 must be compared with the permissible values of the valve and corrected as appropriate)



CAUTION: Generally, 100% stands for fully open and 0% for fully closed. Please note that these values cannot be changed. The end position range is reached as soon as 0% or 100% is shown on display.



	Menu item	Sub-menu item	poss. setting	Notes / comments
P1.1	End limit	Open	TEACHIN; 0...100 U ¹⁾	The parameter value can be set using TEACHIN. With a known travel, the second end position can be entered after setting the first end position.
P1.2	End limit	Close	TEACHIN; 0...100 U ¹⁾	The parameter value can be set using TEACHIN. With a known travel, the second end position can be entered after setting the first end position.

continued on next page

¹⁾representative for CM03; U...number of revolutions

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / Comments
P1.3	End limit	Switch-off Open	0: travel	The actuator uses end-position signals to switch off and report the end position. Attention: For failsafe-actuators in failsafe-direction not applicable. End limit by travel in failsafe-position only possible by changing the mechanical connection to the valve. The actuator signals the end position or stops the motor only after reaching the specified torque in the end position. If the torque is reached and end position signal not, the actuator reports an error. If the end position is reached and the control command drops off during the build-up of the torque, the motor stops and the required torque is not reached. Attention: For failsafe-actuators in failsafe-direction not applicable. Torque/Force in failsafe-position depends on residual spring torque/force
			1: torque	
			2: torque1	Like „torque“, but in the end position range, the torque is also increased when the control command drops off during the build-up of the torque, until the required torque is reached. Attention: For failsafe-actuators in failsafe-direction not applicable. Torque/Force in failsafe-position depends on residual spring torque/force
			3: torque2	Like „torque1“, but in the end position range automatically an additional control command is generated to reach and hold the torque. If the torque decrease and the actuator is in the end position it will be restored automatically. e.g.: Changes due to temperature differences, settlement. Attention: For failsafe-actuators in failsafe-direction not applicable. Torque/Force in failsafe-position depends on residual spring torque/force
			4: travel1	Like „travel“, however, the actuator still continues to drive the set Overrun time after reaching the end position, even when the positioning command is released. Only relevant if Overrun time (P1.10, P1.11) is greater than 0. Attention: For failsafe-actuators in failsafe-direction not applicable.
P1.4	End limit	Switch-off Close	1: travel	see P1.3
			1: torque	see P1.3
			2: torque1	see P1.3
			3: torque2	see P1.3
			4: travel1	see P1.3
P1.5	End limit	Closing direction	right (0)	Actuator is designed for clockwise = closing.
			left (1)	Reverse direction of rotation! Counterclockwise = closing. The crossing of all signals and commands is performed by the controller.
P1.6	End limit	Rot. sense pos.	0	Rotation sense of the Potentiometer. No function in ACTUSMART CM series.
			1	
P1.7	End limit	LED function	Close = green (0)	Definition of the LED colour of the CLOSED or OPEN end position signalization.
			Close = red (1)	
P1.8	End limit	End limit hyst.	0.1... 10.0%	Hysteresis range for end position signals: Example: End position hysteresis 1% means that the End position OFF is reached when closing 0%, and will be left when opening only at 1%, i.e., a re-closing can only take place after leaving this hysteresis.
P1.9	End limit	Ramp	0.1... 100%	When approaching the end position, the speed is reduced.

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / Comments
P1.10	End limit	Range	0... 100%	End position range for torque (P1.3, P1.4). Permissible range in which the torque is to be achieved. If the actuator comes to the end of the end position range, the motor shuts off even if the torque has not been reached.
P1.11	End limit	Overrun Open	0... 60 s	Switch-off delay after reaching the end position see travel1 (P1.3, P1.4)
P1.12	End limit	Overrun Close	0... 60 s	Switch-off delay after reaching the end position travel1 (P1.3, P1.4)

CAUTION: When installing the actuator on a gear or a thrust unit, please take into account the limits and factors of the gear / thrust unit at parametrization.



When using end-limit switch-off by torque, the end position limit must be set before reaching the torque limit. Accordingly, the actuator will only signal the final end position if the configured torque and the associated end position are reached. If the end position is not reached, a torque error is reported (see section 6.2.2, page 38).

7.2 Parameter group: Torque

If no torque was specified with the order, the actuator is supplied from the factory with the maximum configurable torque.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P2.1	Torque	Open	8... 32 Nm ²⁾	Switch-off torque in OPEN direction CAUTION: The range can be restricted via menu item P2.3.
P2.2	Torque	Close	8... 32 Nm ²⁾	As P2.1, but in CLOSED direction.
P2.3	Torque	Torque limit	8... 32 Nm ²⁾	Torque to protect the valve, the transmission, or the thrust unit. This value limits the setting of parameters P2.1 and P2.2 to prevent an erroneous increase above the allowed value of these two parameters.
P2.4	Torque	Latching	0: Off	Unassigned in ACTUSMART CM series

When installing the actuator on an additional gear, please take into account the corresponding values of the gear / thrust unit as you enter the actuator parameters. To achieve an effective output torque (incl. gear) / output power (including thrust unit) ratio, the factor gear/thrust unit must be considered.



7.3 Parameter group: Speed

	Menu item	Sub-menu item	Poss. setting ²⁾	Notes / comments
P4.1	Speed	Local Open	2.5... 72.2 rpm	Output speed for local operation in direction OPEN.
P4.2	Speed	Local Close	2.5... 72.2 rpm	As P4.1, but in direction CLOSE.
P4.3	Speed	Remote Open	2.5... 72.2 rpm	Output speed for remote operation in direction OPEN.
P4.4	Speed	Remote Close	2.5... 72.2 rpm	As P4.3, but in direction CLOSE.
P4.5	Speed	Emergency Open	2.5... 72.2 rpm	Output speed for emergency operation in direction OPEN.
P4.6	Speed	Emergency Close	2.5... 72.2 rpm	As P4.5, but in direction CLOSE.
P4.7	Speed	Torque-dependent	2.5... 72.2 rpm	Seal-tight speed. Speed at which the actuator runs near the end position at torque-dependent switch-off (see P1.3 and P1.4).
P4.8	Speed	Minimum	2.5... 72.2 rpm	Minimum speed.

²⁾representative for CM03

CAUTION: The max. speed for the 24 VDC actuator version is reduced to 20 rpm.



7.4 Parameter group: Ramp (optional)

The start ramp can be set separately for each operation mode. Thus, a 100% start ramp means that the motor attains its maximum speed in about a second. Higher speeds (see section 7.3) lead to shorter runtimes. If the ramp is set below 100%, the starting time increases in an inversely proportional fashion.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P5.1	Ramp	Local	1...100%	Start ramp for local operation
P5.2	Ramp	Remote	1...100%	Start ramp for remote operation
P5.3	Ramp	Emergency	1...100%	Start ramp for emergency operation

7.5 Parameter group: Control

	Menu item	Sub-menu item	poss. setting	Notes / comments
P6.2	Control	Ready delay	0...10 sec	Drop-out delay for the ready signal (bin. outputs)
P6.5 ³⁾	Control	24 V output	0	24 V auxiliary output is deactivated (section 20.5, page 77). The function of the auxiliary input is still activated.
			1	24 V auxiliary output is activated (section 20.5, page 77).
P6.6	Control	Min. impuls	0.1...2.0 sec	Minimum switch-on time of the motor.

7.6 Parameter group: Password

The actuator control can be password-protected to prevent access at different levels. It is possible to prevent entry by unauthorized personnel or to entirely lock motor operation.

Default password is set to "000" and thus deactivated.

You can use both numbers and capital letters in your password. After entering a password, password protection is activated. To remove password protection, enter an empty password (000).

When accessing a password-protected parameter, the user is automatically prompted for its introduction. Only after correctly entering the password, it is possible to change the corresponding parameters.

	Menu item	Sub-menu item	poss. setting	Notes / Comments
P7.1	Password	Reading PWD	3-digit	Status display and history data are still viewable; access to the parameter menu is locked until this password is introduced. Parameter menu scrolling is only enabled after entering the password. Electric motor operation is unlocked.
P7.2	Password	Writing PWD	3-digit	Status display, history data and parameter menu can be viewed. However, parameters become read-only.
P7.3	Password	Bluetooth PWD	15-digit	password for the Bluetooth connection, empty password deactivates the password request.

7.7 Parameter group: Position

In addition to OPEN and CLOSED end positions, you may define intermediate positions. These can be used as feedback signals for the binary outputs or as target value for fix position approach.

CAUTION: If you change the end positions (see section 7.1, page 44), intermediate positions are retained percentage-wise, i.e., the absolute positions of the intermediate positions change.



³⁾since firmware 1.303

7 Parameter menu

	Menu item	Sub-menu item	Poss. setting	Notes / comments
P8.1	Position	Intermed.pos.1	TEACHIN 0...100%	Position value of intermediate position 1
P8.2	Position	Intermed.pos.2	TEACHIN 0...100%	see above
P8.3	Position	Intermed.pos.3	TEACHIN 0...100%	see above
P8.4	Position	Intermed.pos.4	TEACHIN 0...100%	see above
P8.5	Position	Emerg.position	TEACHIN 0...100%	Position value of the emergency position.
P8.6	Position	Hysteresis	0.1...10.0%	Hysteresis range of intermediate positions. Within this hysteresis, no repositioning occurs upon reaching the intermediate positions (option: fix position approach). Furthermore, the output functions for position = intermediate position are active within this range (see P10.1 ...).

7.8 Parameter group: Binary inputs

The controller is equipped with 5 freely configurable binary inputs. Please find further information on technical data of the binary inputs in section 20.2, page 74. Binary inputs are also effective during actuator control via Profibus (option).

Default binary inputs are as follows:

Input 1: OPEN

Input 2: CLOSED

Input 3: STOP

Input 4: EMERGENCY OPEN

Input 5: EMERGENCY Closed

	Menu item	Sub-menu item	poss. setting	Notes / comments
P9.1	Bin. Input	Input 1	0: no function	this input has no function
			1: Open	OPEN command in REMOTE mode (selector switch in position REMOTE).
			2: Closed	CLOSED command in REMOTE mode (selector switch in position REMOTE).
			3: Stop	STOP command in REMOTE mode (selector switch in position REMOTE).
			4: Open Self-hold	Self-hold for OPEN, i.e., a short pulse is sufficient and the actuator moves then into the end position. Use the STOP command to stop the actuator.
			5: Closed Self hold	Self-hold for CLOSED, see OPEN SELF-HOLD
			6: Emergency Open	Superimposed run command; run the actuator in direction OPEN regardless of whether the selection switch is set to REMOTE or LOCAL operation
			7: Emergency Closed	Superimposed run command; run the actuator in direction CLOSED regardless of whether the selection switch is set to REMOTE or LOCAL
			8: Release	The actuator may be operated only with a switched signal. Both in local and remote operation
			9: Open/Closed	The actuator moves towards OPEN if input is active and towards CLOSED otherwise
			10: Close/Open	The actuator moves towards CLOSED if input is active and towards OPEN otherwise
			11: Positioner	Release of the positioner
			12: Open inv.	As open but active low
			13: Close inv.	As CLOSED but active low
			14: Stop inv.	As STOP but active low
15: Open Self-Hold.inv	As Open Self-Hold but active low			

continued on next page

continued from previous page

Menu item	Sub-menu item	poss. setting	Notes / comments
		16: Closed Self-Hold inv	As Closed Self-Hold. but active low
		17: Emergency-Open inv.	As Emergency-Open but active low
		18: Emergency-Closed inv.	As Emergency-Closed but active low
		19: Block	with activated (switched) signal, the actuator is locked for operation also in local mode
		20: Contoller lock	Positioner lock
		21: Release Local	The actuator may be operated only with a switched signal.
		22: Block Local	as Release Local but active low
		23: Lock Open	Trigger lock OPEN (in LOCAL and REMOTE mode). Actuator moves with the highest priority to OPEN; command continues internally active after reaching the end position OPEN. Dropping only with LOCK OFF, Supply OFF or operating mode OFF.
		24: Lock Closed	Trigger lock CLOSED (in LOCAL and REMOTE mode). Actuator moves with the highest priority to CLOSED; command continues internally active after reaching the end position CLOSED. Dropping only with LOCK OFF, Supply OFF or operating mode OFF.
		25: Lock Off	Drop the lock
		26: Failsafe	Trigger the failsafe function in all operating modes (only functional in Failsafe actuators).
		27: Failsafe inv.	As Failsafe, but active low
		28: Lock Open inv.	As Lock Open, but active low
		29: Lock Closed inv	As Lock Closed, but active low
		30: Lock Off inv.	As Lock Off, but active low
		31: Intermediate position1	Approach intermediate position 1 (P8.1) in REMOTE mode (fix position approach). There is no repositioning upon reaching the intermediate position within the hysteresis (see P8.6). Higher priority than intermediate position 2, 3 and 4
		32: Intermediate position2	As intermediate position 1, but with higher priority than intermediate positions 3 and 4
		33: Intermediate position3	As intermediate position 1, but with higher priority than intermediate position 4
		34: Intermediate position4	As intermediate position 1, but with lowest priority.
		35: Emergency position	Approach emergency position (P 8.5). As intermediate position 1, but with higher priority than intermediate positions 1, 2
		36: Intermediate position1 inv.	As Intermediate position 1, but active low
		37: Intermediate position2 inv.	As Intermediate position 2, but active low
		38: Intermediate position3 inv.	As Intermediate position 3, but active low
		39: Intermediate position4 inv.	As Intermediate position 4, but active low
		40: Emergency position inv.	As Emergency position, but active low
		41: Travel Open	reserved for future use
		42: Travel Close	reserved for future use

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			43: Travel Open inv.	reserved for future use
			44: Travel Close inv.	reserved for future use
			45: Failsafe lock	reserved for future use (only for Failsafe actuators)
			46: Failsafe lock inv.	reserved for future use (only for Failsafe actuators)
P9.2	Bin. Input	Input 2	see Input 1	
P9.3	Bin. Input	Input 3	see Input 1	
P9.4	Bin. Input	Input 4	see Input 1	
P9.5	Bin. Input	Input 5	see Input 1	

7.9 Parameter group: Binary outputs

The controller is equipped with 8 freely configurable binary outputs. Please find further information on technical data of the binary outputs in section 20.1, page 74. Provided with external supply, binary outputs are optically isolated from the rest of the controller.

Default binary outputs are as follows:

Output 1: Ready	Output 2: End position OPEN
Output 3: End position CLOSED	Output 4: Run OPEN
Output 5: Run CLOSED	Output 6: Torque
Output 7: LOCAL	Output 8: REMOTE

	Menu item	Sub-menu item	poss. setting	Notes / comments
P10.1	Bin. Output	Output 1	0: User defined	Optional
			1: Ready	Actuator is ready
			2: Fault	General fault; actuator is not ready
			3: Open	Actuator is in open position
			4: Closed	Actuator is in closed position
			5: Running Open	Actuator runs in direction Open
			6: Running Closed	Actuator runs in direction Closed
			7: Running	Actuator is running in either Open or Closed
			8: Torque Open	Switch-off torque was reached in Open direction, actuator has been switched off
			9: Torque Closed	Switch-off torque was reached in Closed direction, actuator has been switched off
			10: Torque	Switch-off torque was reached in either Closed or Open direction
			11: Travel Open	The Open end position has been reached
			12: Travel Closed	The Closed end position has been reached
			13: Pos. > Int.1	Position > Intermediate position 1
			14: Pos. < Int.1	Position < Intermediate position 1
			15: Pos. > Int.2	Position > Intermediate position 2
			16: Pos. < Int.2	Position < Intermediate position 2
			17: Pos. > Int.3	Position > Intermediate position 3
			18: Pos. < Int.3	Position < Intermediate position 3
			19: Pos. > Int.4	Position > Intermediate position 4
			20: Pos. < Int.4	Position < Intermediate position 4
			21: Local	Local operating mode (selector switch in position)
			22: Remote	Remote operating mode (selector switch in position Remote)
23: Off	Off operating mode (selector switch in the Off position)			

continued on next page

continued from previous page

Menu item	Sub-menu item	poss. setting	Notes / comments
		24: no function	no function
		25: motor error	The motor temperature sensor has reported an error
		26: Always	Signal is always on
		27: Never	Signal is always off
		28: Bin. Input 1	Forwarding of binary input to output
		29: Bin. Input 2	Forwarding of binary input to output
		30: Bin. Input 3	Forwarding of binary input to output
		31: Bin. Input 4	Forwarding of binary input to output
		32: Bin. Input 5	Forwarding of binary input to output
		33: Torque Open ma.	As Torque OPEN, but it will suppress (mask) this signal in the end position upon torque-dependent switch-off.
		34: Torque Closed ma.	As Torque CLOSED, but it will suppress (mask) this signal in the end position upon torque-dependent switch-off.
		35: Ready Remote	Ready and Remote operating mode
		36: Ready Local	Ready and Local operating mode
		37: Ready Local/remote	Ready and Local or Remote mode
		38: Lock Open	Lock OPEN is enabled. OPEN command is internally queued with the highest priority and will not be dropped even in the end position.
		39: Lock Closed	Lock CLOSED is enabled. CLOSED command is internally queued with the highest priority and will not be dropped even in the end position.
		40: Failsafe OK1	Failsafe OK (only for Failsafe actuators)
		41: Failsafe OK2	Failsafe OK and Ready (only for Failsafe actuators)
		42: Failsafe OK3	Failsafe OK, Ready and Remote (only for Failsafe actuators)
		43: Lock	Lock Open or Lock Closed is enabled.
		44: Ready/TorqueOK	Actuator is ready and no torque switch-off
		45: Ready / Remote / TorqueOK	Actuator is ready for operation in REMOTE mode and no torque switch-off
		46: Pos.=Int1	Position = Intermediate position 1. The width of the interval is set with the parameter P8.6.
		47: Pos.=Int2	Position = Intermediate position 2. The width of the interval is set in parameter P8.6.
		48: Pos.=Int3	Position = Intermediate position 3. The width of the interval is set in parameter P8.6.
		49: Pos.=Int4	Position = Intermediate position 4. The width of the interval is set in parameter P8.6.
		50: Pos.=EmergPos	Position = emergency position. The width of the interval is set in parameter P8.6.
		51: Bus Bit 1	In existing bus interface (hardware option), the output is set according to the selected bit bus. ⁴⁾
		52: Bus Bit 2	
		53: Bus Bit 3	
		54: Bus Bit 4	
		55: Bus Bit 5	
		56: Bus Bit 6	
		57: Bus Bit 7	
		58: Bus Bit 8	
		59: Virtual 1	Configurable output function
		60: Virtual 2	
		61: Virtual 3	
		62: Virtual 4	

continued on next page

⁴⁾from Firmware 1.323

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			63: Control OK	The SMARTCON control is operational.
			64: Control voltage OK	The auxiliary voltage for the SMARTCON control is OK. This function is only available if the auxiliary voltage output is not switched on (P6.5 to 0).
			65: PVST OK	The PVST was successful.
			66: PVST Error	The PVST was not successful.
			67: PVST active	A PVST was triggered. The actuator is running a PVST.
			68: Emerg. OPEN	Emergency OPEN command is active. The signal remains active, as long as the emergency command is active, even if the end limit is reached. ⁵⁾
			69: Emerg. CLOSE	Emergency CLOSE command is active. The signal remains active, as long as the emergency command is active, even if the end limit is reached. ⁶⁾
			70: Analog In. 1 Fault	There is no or a faulty signal on the analog input 1. ⁷⁾
			71: Analog In. 2 Fault	There is no or a faulty signal on the analog input 2. ⁸⁾
P10.2	Bin. Output	Output conf. 1	0: normal	Output 1 is set to normal, i.e. if the condition in point P10.1 is met, Output 1 is set to HIGH (active HIGH).
			1: inverted	If the condition in point P10.1 is met, Output 1 is set to LOW (active LOW).
			2: norm. flashing	If the condition in point P10.1 is met, Output 1 starts blinking (active HIGH).
			3: inv. flashing	If the condition in point P10.1 is not met, Output 1 starts blinking (otherwise it is set to HIGH).
P10.3	Bin. Output	Output 2	see Output 1	
P10.4	Bin. Output	Output 2 Konf.	see Output 1 conf.	
P10.5	Bin. Output	Output 3	see Output 1	
P10.6	Bin. Output	Output 3 Konf.	see Output 1 conf.	
P10.7	Bin. Output	Output 4	see Output 1	
P10.8	Bin. Output	Output 4 Konf.	see Output 1 conf.	
P10.9	Bin. Output	Output 5	see Output 1	
P10.10	Bin. Output	Output 5 Konf.	see Output 1 conf.	
P10.11	Bin. Output	Output 6	see Output 1	
P10.12	Bin. Output	Output 6 Konf.	see Output 1 conf.	
P10.13	Bin. Output	Output 7	see Output 1	
P10.14	Bin. Output	Output 7 Konf.	see Output 1 conf.	
P10.15	Bin. Output	Output 8	see Output 1	
P10.16	Bin. Output	Output 8 Konf.	see Output 1 conf.	

CAUTION: When using the parameters torque-dependent OPEN or torque-dependent CLOSED (see section 7.1, page 44, items P1.3 and P1.4), the actuator will only be open or closed when the set torque and the associated end position is reached. If the end position is not reached, a torque error is reported (see section 6.2.2, page 38).



7.10 Parameter group: Position output (optional)

Position output is used to indicate the current position of the actuator using 0/4...20 mA; it can be retrofitted using a Smart-code.

If this option is not enabled, the menu point shows the message "inactive".

No adjustment to the end positions or the travel is required. Adjustment is automatically performed during the configuration of travel limit positions (see section 7.1, page 44).

⁵⁾Firmware 1.521 or higher

⁶⁾Firmware 1.521 or higher

⁷⁾Firmware 1.525 or higher

⁸⁾Firmware 1.525 or higher

No further settings are necessary for torque-dependent switch-off, because the controller exclusively uses travel limit positions for the calculation, regardless of whether this is defined by the torque or the travel limit positions.

The factory default setting is:

4 mA at 0% position 20 mA at 100% position

	Menu item	Sub-menu item	poss. setting	Notes / comments
P11.1	PositionOutput	Function 1	0: off	mA output disabled
			1: Position	mA output corresponds to the actual position value.
			2: Pos. Valvechar.	mA output corresponds to the actual position value taking into account the valve characteristic.
			3: Torque 1	mA output corresponds to the actual torque value.
				torque = 100% Close: mA output = start
				torque = 0%: mA output = center
				torque = 100% Open: mA output = end
			4: Torque 2	mA output corresponds to the actual torque value.
				torque = 100% Close: mA output = end
				torque = 0%: mA output = start
				torque = 100% Open: mA output = end
			5: Torque 3	mA output corresponds to the actual torque value.
				torque = 150% Close: mA output = start
				torque = 0%: mA output = center
	torque = 150% Open: mA output = end			
	6: Torque 4	mA output corresponds to the actual torque value.		
		torque = 150% Close: mA output = end		
		torque = 0%: mA output = start		
		torque = 150% Open: mA output = end		
P11.2	Position output	Begin 1 (at 0%)	0...20.5 mA {4 mA}	mA value for the Closed (0%) position
P11.3	Position output	End 1 (at 100%)	0...20.5 mA {20 mA}	mA value for the On (100%) position
P11.4	Position output	Calib. 20 mA 1	-10%...+10%	Calibrating the output position during the setting of this parameter will output a 20 mA (100%) signal. Use this parameter to calibrate accurately the 20 mA output signal (e.g., if you measure 19.8 mA at the output, just add 1% (0.2 mA... 1% of 20 mA) to the displayed value).
P11.5	Analog output	Function 2	see Function 1	
P11.6	Analog output	Begin 2 (at 0%)	see Begin 1	
P11.7	Analog output	End 2 (at 100%)	see End 1	
P11.8	Analog output	Calib. 20 mA 2	see Calib. 20 mA 1	

7.11 Parameter group: Step mode

Step mode operation can be used to extend the operating time in certain ranges or for the whole travel; it is available in local, remote and emergency mode.

Step mode operation can be activated individually for the directions OPEN and CLOSED.

Cycle start, cycle end, cycle duration and interval time can be set separately for both directions (see Figure 66, page 54).

	Menu item	Sub-menu item	poss. setting	Notes / comments
P12.1	Step mode function	Mode	0: disabled	Step mode operation is disabled
			1: enabled	Step mode operation is enabled in LOCAL, REMOTE and EMERGENCY operation

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			2: Local only	Step mode mode is only enabled in LOCAL mode
			3: Remote only	Step mode mode is only enabled in REMOTE mode
			4: Local + Remote only	Step mode mode is enabled in REMOTE and LOCAL mode
P12.2	Step mode function	Start Open	0 ... 100%	In OPEN direction, position in % from which the step mode operation should start.
P12.3	Step mode function	End Open	0 ... 100%	In OPEN direction, position in % of which the step mode operation should end.
P12.4	Step mode function	Runtime Open	0.1 ... 60	Runtime in OPEN direction
P12.5	Step mode function	Pause time Open	0.2 ... 60	Pause time in OPEN direction
P12.6	Step mode function	Start Closed	0 ... 100%	In CLOSED direction, position in % from which the step mode operation should start.
P12.7	Step mode function	End Closed	0 ... 100%	In CLOSED direction, position in % of which the step mode operation should end.
P12.8	Step mode function	Run time Closed	0.1 ... 60	Runtime in Closed direction
P12.9	Step mode function	Pause time	0.2 ... 60	Pause time in Closed direction
P12.10	Step mode function	Timebase	0: Seconds	Time basis for run and pause times
			1: Minutes	
P12.11	Step mode function	Speed adaption	0:	Speed adaption not activated. Normal step mode function.
			1:	Speed adaption is activated. The speed is reduced according to the runtime and pause time in the step mode range. (Example: Running time 1 sec and pause time 1 sec results in half the speed). If the minimum speed is undershot, the actuator clocks in the converted ratio with the minimum speed. The speed adjustment is only applicable to actuators of the type CM and AB CSC.




Figure 66

NOTE: It is important to ensure that the mode of operation is not exceeded!
The running info on the actuator (see section 6.2.2, page 38) only flashes while the drive is running, i.e. during the break, no flash!



7.12 Parameter group: Positioner (optional)

The positioner SR option is used to control the electric actuator by means of a set point input 0/4...20 mA signal. The SR helps control the position of the actuator, i.e. the positioner ensures that the actual value and thus the position of the actuator matches the desired set point.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P13.1	Positioner	Function	off	Positioner disabled
			1: Position	mA input for the position setpoint
			2: Pos. valvechar.	mA input for the position setpoint, taking into account the valve characteristic
P13.2	Positioner	Begin (at 0%)	0...20.5 mA {4.0 mA}	mA value of the setpoint for the CLOSED (0%) position
P13.3	Positioner	End (at 100%)	0...20.5 mA {20.0 mA}	mA value of the setpoint for the OPEN (100%) position
P13.4	Positioner	Dead band	0.1...10.0% {1.0%}	Tolerance range for the control deviation (set point position – actual position) where no adjustment occurs. The deadband should not be set too low to prevent actuator oscillation.
P13.5	Positioner	Gain	1...100% {100%}	The gain (gradient) affects the positioning close to the target position. The smaller the gain selected (e.g. 20%), the earlier the actuator starts reducing its speed in case of speed variable actuators on approaching the target position. In case of actuators with fixed speed (reversing starters), the speed reduction is done by pulsing (also see params P13.9 and P13.10). This leads to better positioning (smaller reachable deadband). A 100% setting disables this gradient.
P13.6	Positioner	Live zero detect.	Ignore	The setpoint monitoring (monitoring the setpoint to below approximately 2 mA = loss of signal) is disabled.
			1: Stop	Actuator stops on signal failure.
			2: Open	On signal failure, actuator moves the OPEN position.
			3: Close	Actuator moves on signal failure to the CLOSED position.
			4: Emerg.pos.	On signal failure, the actuator moves the defined emergency position (see parameter P13.7).
			5: Emerg. PID	reserved for future use
P13.7	Positioner	Emergency pos.	0...100% {50,0%}	Determination of the emergency position (Can also be set in the menu P8.5)
P13.8	Positioner	Calib.Setpoint 20mA	-10%...+10%	Calibration value for the 20mA setpoint. 1% = approx. 0.2mA. Calibration process: By applying 20mA on the setpoint input, this parameter is corrected until the readout matches 20mA.
P13.9	Positioner	Min. impulse	{0,2 s}	Variable speed actuators (Actusmart CM and Smartcon CSC FU): Without function Fixed speed actuators (Smartcon CSC): Minimum activation time of the reversing contactors. For very small activation times (<0.3...0.5 s), the motor will be switched off during start-up process, which significantly increases mechanical wear on reversing contactors. With frequent periods of very small activation times (restless loop, small dead zone, clocking near to the target value), we therefore recommend electronic reversing contactors.
P13.10	Positioner	Period	{2.0 s}	Variable speed actuators (Actusmart CM and Smartcon CSC FU): Without function Fixed speed actuators (Smartcon CSC): This parameter is only relevant in Step mode when approaching the target position (parameter gain smaller than 100%) and determines the period of a run / pause cycle.

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P13.11	Positioner	Begin pos. (a0)	0.0... 25.0% {2.0%}	Smallest controllable position other than the end position CLOSED. The range 0% ... a0 will be just passed through. Use the parameter a0 to define the beginning of the allowable control range of the valve (e.g., blind spot for ball segment valves, etc.).
P13.12	Positioner	End pos. (e0)	75.0... 100.0% {98.0%}	Largest controllable position other than the end position OPEN. The area e0 ... 100% is just passed through. Use the parameter e0 to define the end of the allowable control range of the valve.
P13.13	Positioner	Begin setp. (a1)	0.0... 25.0% {2.0%}	Below this value, the end position CLOSED is controlled. In the range 0% ... a1 cannot be controlled (end position tolerance). The initial setpoint a1 is associated with a small hysteresis (1/4 of the deadband).
P13.14	Positioner	End setp. (e1)	75.0... 100.0% {98.0%}	Above this value, the end position OPEN is controlled. The range e1 ... 100% cannot be controlled (end position tolerance). The final setpoint e1 is associated with a small hysteresis (1/4 of the deadband).
P13.15	Positioner	Calib. Setpoint 0mA	-10% ... +10%	Calibration of 0mA for the input setpoint. 1% = approx. 0.2mA. Calibration process: By applying 0mA on the setpoint input, this parameter is corrected until the readout matches 0mA.




Figure 67: Assigning the position to the setpoint

7.13 Parameter group: PID controller (optional)

The optional PID controller is used for controlling an external actual value (process variable) to a setpoint using 0/4...20 mA signal by readjusting the actuator.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P14.1	PID-controller	Function	0: disabled	PID controller disabled
			1: Position	The output of the PID controller corresponds to the position setpoint of the actuator. The positioning (tracking of the actual position to the setpoint) is done by the positioner (see section 7.12).

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			2: Speed	The output of the PID controller corresponds to the speed of the actuator (speed mode is only possible for Actusmart CM and Smartcon CSC FU!). There is no adjustment with the positioner. ⁹⁾
			3: Speed	The output of the PID controller corresponds to the change of the position setpoint (speed) of the actuator. The positioning (tracking of the actual position to the setpoint) is done by the positioner (see section 7.12). Hence a control mode similar to the Speed mode (see Setting 2, above) is possible also for actuators with constant speed. ¹⁰⁾
P14.2	PID-controller	External setpoint	0: fixed	The PID controller uses an internal, fixed setpoint (see param P14.3).
			1: external	The PID controller uses the external setpoint. Adjust this setpoint with the params P13.2 and P13.3 (see section 7.12).
P14.3	PID-controller	Fixed setpoint	0...100%	Specification of the internal fixed setpoint
P14.4	PID-controller	Start (at 0%)	0...20.5 mA	mA value at 0% of the external actual value
P14.5	PID-controller	End (at 100%)	0...20.5 mA	mA value at 100% of the external actual value
P14.6	PID-controller	Gain (P)	-50.0...+50.0	Gain (proportional value) of the PID-controller. A negative value reverses the effective direction of the PID-controller, e.g.: Positive gain: The actuator opens when the desired value is greater than the external actual value. Negative gain: The actuator closes when the desired value is greater than the external actual value.
P14.7	PID-controller	Reset time (I)	0...100.0 s	The shorter the reset time (integral time, integral value), the stronger the effect of the integral component of the PID-controller. Values below 1.0 will disable the integral component.
P14.8	PID-controller	Lead time (D)	0...100.0 s	The larger the lead time (differential/derivative value), the stronger the effect of the derivative component of the PID-controller. To reduce the influence of noise, a first-order lag element with 1 sec time constant is added (DT ₁).
P14.9	PID-controller	Offset	-200...+200%	The offset value will be added to the output value of the PID controller.
P14.12	PID-controller	Live zero detect.	0: Ignore	The monitoring of the external actual value is disabled.
			1: Stop	Actuator stops on signal failure of external. actual value
			2: Open	On signal failure of external actual values, actuator moves to the OPEN position.
			3: Closed	On signal failure of external actual values, actuator moves to the CLOSED position.
			4: Emergency position	On signal failure of external actual values, actuator moves to the EMERGENCY position (see param P13.7).
			5: Emergency PID	reserved for future use
P14.13	PID-controller	Calibration of ext. actual value	-10.0...+10.0%	Calibration process: By applying 20 mA to the external actual value input, this parameter is corrected until the readout matches 20 mA.
P14.14	PID-controller	Process begin	-32768...+32767	Mantissa of the real process variable (begin of external actual value)
P14.15	PID-controller	Process end	-32768...+32767	Mantissa of the real process variable (end of external actual value)
P14.16	PID-controller	Process comma shift	-3...+3	Position of the comma for process begin/end (P14.14, P14.15), e.g.: mantissa = 200, comma shift = -2/2, process value = 2.00/20000

continued on next page

⁹⁾from firmware 1.338

¹⁰⁾from firmware 1.338

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P14.17	PID-controller	Process unit	—	Unit of the real process variable
P14.18	PID-controller	Dead band	0.1... 10.0% {1.0%}	Tolerance range for the control deviation (set point – external actual value) where no adjustment occurs. ¹¹⁾

7.14 Parameter group: Bus systems (optional)

The manuals for the Bus systems are available in the download area on our homepage www.schiebel-actuators.com under the tab **Quality & Service**.

7.15 Parameter group: Characteristic curves (optional)

With this option, customers can enable travel-dependent torque, speed and valve characteristic curves.

7.15.1 Torque characteristic

With this characteristic curve, torque limits already set under menu item **P2-torque** (see section 7.2, page 46) can be further **reduced** depending on travel. Characteristics can be configured via the SMARTTOOL software (see Figure 68, page 58).




Figure 68: Torque characteristic

¹¹⁾from firmware 1.340

	Menu item	Sub-menu item	poss. setting	Notes / comments
P17.1	Characteristic	Torque Open	0: Off	The torque characteristic curve is disabled for the OPEN direction.
			1: On	The torque characteristic curve is enabled for the OPEN direction.
			2: Local + Remote only	The torque characteristic curve is enabled for the OPEN direction only in LOCAL and REMOTE mode (while disabled in the EMERGENCY mode).
P17.2	Characteristic	Torque Closed	0: Off	The torque characteristic curve is disabled for the CLOSED direction.
			1: On	The torque characteristic curve is enabled for the CLOSED direction.
			2: Local + Remote only	The torque characteristic curve is enabled for the CLOSED direction only in LOCAL and REMOTE mode (while disabled in the EMERGENCY mode).

7.15.2 Speed characteristic

With this characteristic curve, speed limits already set under menu item **P4-speed** (see section 7.3, page 46) can be further **reduced** depending on travel. Characteristics can be configured via the SMARTTOOL software (see Figure 69, page 59).




Figure 69: Speed characteristic

7 Parameter menu

	Menu item	Sub-menu item	poss. setting	Notes / comments
P17.3	Characteristic	Speed Open	0: Off	The speed characteristic curve is disabled for the OPEN direction.
			1: On	The speed characteristic curve is enabled for the OPEN direction.
P17.4	Characteristic	Speed Closed	0: Off	The speed characteristic curve is disabled for the CLOSED direction.
			1: On	The speed characteristic curve is enabled for the CLOSED direction.

7.15.3 Valve characteristic

With this characteristic curve the mapping between the actuator position and the setpoint of the valve can be adjusted. Hence it is possible to compensate and linearize the general nonlinear characteristic curves of valves. Characteristics can be configured via the SMARTTOOL software (see Figure 70, page 60).




Figure 70: Valve characteristic

	Menu item	Sub-menu item	poss. setting	Notes / comments
P17.5	Characteristic	Valve	0: Off	The valve characteristic curve is disabled.
			1: user defined	The valve characteristic curve is enabled as configured in the SMARTTOOL.

7.16 Parameter group: Identification (optional)

This option allows entering further custom-identification parameters.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P18.1	Identification	PPS number	15 digits	Used to enter a PPS number. This is displayed in the bottom line. CAUTION: Param P20.5 must be set to 0.

7.17 Parameter group: System parameters (locked)

Used for actuator configuration and not available for customers.

7.18 Parameter group: Miscellaneous

	Menu item	Sub-menu item	poss. setting	Notes / comment
P20.1	Miscellaneous	Language	0: German	Defines the menu language
			1: English	
			2: Russian	
			3: Czech	
			4: Spanish	
			5: French	
			6: Italian	
			7: Danish	
			8: Hungarian	
			9: Turkish	
			10: Greek	
			11: Polish	
			12: Serbian	
13: Croatian				
P20.2	Miscellaneous	Smartcode		Enables additional features by entering a Smartcode
P20.3	Miscellaneous	Restore para	0:	no action
			1: Custpara -	By saving this setting, all parameters except the end positions are reset to the customer parameters.
			2: Custpara +	By saving this setting, all parameters are reset to the customer parameters.
			3: Backuppara -	By saving this setting, all parameters except the end positions are reset to the factory settings.
			4: Backuppara +	By saving this setting, all parameters are reset to the factory settings.
P20.4	Miscellaneous	Backup para	0:	no action
			1: Custpara	By saving this setting, the currently set parameters are adopted as customer parameters.
P20.5	Miscellaneous	Info line	0...31	The fourth line of the display shows various diagnostic values.
P20.6	Miscellaneous	Infrared	0: Off	The infrared connection is disabled.
			1: Infrarot	The infrared connection is active for about 3 minutes unless communication is detected.
			2: Bluetooth	The Bluetooth connection is active for about 3 minutes unless communication is detected.
			3: Infrarot+	The infrared connection is activated.
			4: Bluetooth+	The Bluetooth connection is activated.
P20.7	Miscellaneous	Menu style	0...2	different menu styles
P20.11	Miscellaneous	Daylight saving time	0: off	Normal time is activated
			1: on	Daylight saving time is activated.
			2: auto	The actuator switches automatically between Daylight saving time and Normal time.

8 Status area

The status area presents current process and diagnostic data. In this area, data is read-only. To access the status area, move the control switch in the direction where the selector switch should be in the neutral position or in the remote position. The status area is divided into 2 sub-areas:

- Status
- History

8.1 Status

8.1.1 Status – binary outputs

Display of binary outputs: The display shows output control as opposed to output status, i.e. the supply of the binary outputs is ignored. A switched output is represented by 1.




Figure 71: 1... Output Number, 2... Signal (0 = LOW; 1 = HIGH)

8.1.2 Status – binary inputs

Display of binary inputs: A set input is represented by 1.




Figure 72: 1... Input number, 2... Signal (0 = LOW; 1 = HIGH)

8.1.3 Status – analog values

Display of analogue values: Input 1 (In1) is used by the positioner as the setpoint; Input 2 (In2) serves as an external value for the optional PID controller. In the analogue output (out), only the control signal is shown, regardless of whether the output current actually flows or not (interruption of the current loop).




Figure 73: 1... Input 1, 2... Input 2, 3... Output, 4... All values in mA

8.1.4 Status – absolute values

This status displays the absolute position of the actuator.




Figure 74: 1... Absolute value of the position unit, 2... Relative value of the position unit 3 and 4... Absolute and relative value for the torque unit (calibrated in factory)

8.1.5 Status – firmware




Figure 75: 1... Firmware, 2... Firmware date

8.1.6 Status – serial number




Figure 76: 1... Serial number of the control unit, 2... Serial number of the actuator, 3... Serial number of electronics

8.1.7 Status – meter readings




Figure 77: 1... Power-on cycles, 2... Operating hours, 3... Engine duration

8.2 History

History shows the last 20 history entries. In addition to the plain text entry, the time since the last history entry is also provided.

Please note that the actuator can only calculate time if energised. For error analysis, please refer to section 12, page 67.

9 Infrared connection

For easier communication and better visualization of the menu options, the unit provides an infrared port for connection to a PC.

The required hardware (connection cable to the PC's RS-232 or USB connectors) and the corresponding software are available as options.

The SMARTTOOL software, in addition to communication with the actuator, allows the management of multiple actuators to transfer the configuration to different actuators.

This approach can greatly simplify operation.

Please refer to the SMARTTOOL software operating instructions manual for further information.

During operation, it must be ensured that the IR interface surface is protected from strong disturbances which may otherwise compromise the communication.

Before mounting the infrared adapter, clean the surface of the infrared interface with a damp cloth.

When the infrared interface is enabled, it is indicated by LED L5 (see section 6.2.2, Figure 78, page 38). The infrared interface can be enabled in the menu item P20.6.




Figure 78: 1... Infrared connection

10 Bluetooth connection

In addition to the infrared interface, it is also possible to configure the Control System using a Bluetooth interface. Software required for Android equipment is available as an option. In addition to communication with the actuator, the Android software also enables management of multiple actuators, allowing easy transfer of parameter sets to various actuators. This approach can significantly simplify commissioning.

When the Bluetooth interface is enabled, this is indicated by LED L5 (see Figure 78 resp. section 6.2.2, page 38). The Bluetooth interface can be enabled in menu item P20.6.

11 Maintenance

Maintenance work on open actuators may only be conducted if these are de-energized. Reconnection during maintenance is strictly prohibited.



Work on the electrical system or equipment must be carried out only in accordance with electrical regulations by a qualified electrician himself or by specially instructed personnel under the control and supervision of a qualified electrician.

For explosion-proof actuators, it is necessary before opening the cover to wait a certain time after switching off, see explosion protection sticker (Picture 79). Following times are specified for the actuators.



- CM03: 5 min
- CM06: 10 min



Figure 79: 1... Explosion protection sticker

Actuators are ready for use after installation. By default, the actuator is delivered filled with oil.
On-going monitoring:

- Beware of increased running noise. During long downtime periods, operate the actuator at least every 3 months.
- For actuators with output types A, B and C according to DIN 3210-A, B1, B2 and C according to DIN ISO 5210, re-lubricate at least every 6 months on existing grease fittings (see section 15.3, page 70).

Actuators are designed for installation in any position (see section 2.5, page 26). Therefore, the main body is not equipped with a level indication or a drain plug.

The replacement of the lubricant from the main body must be performed via the handwheel.

Every approx. 10,000 to 20,000 hours (about 5 years, see section 15, page 69), depending on the workload, you must:

- change oil, and
- replace seals.

Check all roller bearings and the worm-wheel assembly and replace if necessary.

Check our lubricants table for recommended oils and greases (see section 15, page 69).

Check the cable glands at regular intervals (annually) for tightness of the cables and retighten if necessary.



If the visual inspection (eg. dust or water penetration) indicates that the effectiveness of the sealing elements of the cable entry has suffered damage or aging, such elements have to be replaced preferably by using the original spare parts from the manufacturer of the equipment or through cable entries of comparable quality as well as the same ex- or IP protection class.

If screws need to be replaced, it is preferable to use original replacement parts. The tensile strength of the screws must be at least 400 N/mm² !

12 Troubleshooting

Upon warning or error, the bottom line of the display will show the corresponding plain text description. This event will also be entered into the history (see section 8.2, page 64).

12.1 History Entries

Listed below are all possible history entries. In case of a warning, the alarm will be visualized on the left side of the main display. If an alarm occurs, the display background light will be red, and the main display will show, that the actuator is not ready.

NOTE: Each error has a unique error number. Each error also has its separate “OK” message in the history after the fault has gone.

History Entry	Type	Description
#3: Mot. temp. warn. #19: Mot. temp. warn. OK	Warning	The motor temperature is in the critical range although the actuator remains fully functional.
#4: Mot. temp. switchoff #20: Mot. temp. switchoff OK	Alarm	Overtemp in motor, fault on Basis or BLDC, On Basis: loss of main power (3x400V) or cable break between CSC and motor; on BLDC: cable break between BLDC and motor.
#5: Phase sequ. fault #6: Phase sequ. OK	n.a.	Cause on Basis: Active phase sequence detection on single phase actuators, loss of main power while connected to external 24 VDC auxiliary voltage, or loss of phase L2.
#7: Ready	Information	Written to the history after all errors are gone.
#8: Power On	Information	Is written to the history after power on the actuator, even if there are some errors.
#9: Power supply Fault #21: Power supply OK	Alarm	No power supply to the power electronics (when the controller is powered from the auxiliary power input). Defect of power electronics – please contact the manufacturer.
#11: Failsafe Fault #12: Failsafe OK	Alarm	Communication error between Failsafe board and Logic, loss of external 24 V Failsafe Voltage, or overtemp. on Failsafe brake.
#13: Manual override #14: Manual override Off	Alarm	Manual override on Failsafe active (visible in status S4), cable/switch broken.
#17: Travel Sensor Fault #18: Travel Sensor OK	Alarm	The travel unit is outside the permitted range (potentiometer fault on Basis), cable broken, or multiturnsensor calibration lost on CM – please contact the manufacturer.
#22: Torque Sensor Fault #23: Torque Sensor OK	n.a.	Potentiometer fault on Basis, or cable broken.
#24: Bus Fault #25: Bus OK	Warning	No communication with the optional bus system.
#26: Bus Watchdog #27: Bus Watchdog OK	Warning	Watchdog for bus communication has reacted.
#28: Undervoltage> Warning #29: Voltage OK	Warning	The input voltage is below the regular voltage range, but motor operation is still possible.
#32: Internal Comm. Fault L>Error #33 Internal Comm. Fault L>OK	Alarm	Communication error between Logik and Basis/BLDC, cable broken between boards, or board defect.
#34: Internal Comm. Fault D>Error #35: Internal Comm. Fault D>OK	Alarm	Communication error between Display and Logik, cable broken between boards, boards defect, or firmware update on Logik not properly done.
#36: Failsafe not ready #37: Failsafe ready	n.a.	Failsafe voltage OK and Failsafe not initialized (LUS not tensioned).
#38: RTC Battery low #39: RTC Battery OK	Warning	Battery on Display board is empty, loss of time/date or counter values possible.
#44: Inverter Fault #45 Inverter OK	Alarm	BLDC parameter error or defective BLDC. Please contact the manufacturer.

continued on next page

continued from previous page

History Entry	Type	Description
#46: Analog Input 1 Signal Loss #47: Analog Input 1 OK	Warning	SRG active, Positioner live zero detection activated, no setpoint value recognized.
#48: Analog Input 2 Signal Loss #49: Analog Input 2 OK	Warning	Ext. setpoint active, Ext. setpoint live zero detection activated, no Ext. setpoint value recognized
#50: End Limits Are The Same #51: End Limits OK	Alarm	The End limits for OPEN and CLOSE are the same values.
#52: User Input Switches Error #53: User Input Switches OK	Alarm	The selector switches are not calibrated. Please use the the calibration function in the wizard in the SmartTool2.
#54: PVST Error #55: PVST OK	Information	The last PVST was not successful
#56: Internal Comm. Fault E>Error #57: Internal Comm. Fault E>OK	Warning	Communication error between remote display and main display. Cable to from remote display to EB2_2, EB2_2 to EB2_1, or EB2_1 to main display broken. Also, one of the boards may be faulty.
#58: Undervoltage Error	Alarm	The input voltage is below the minimum threshold voltage; motor operation is not given. May appear in the history, if the actuator was turned off, in which case no #29: Voltage OK entry will be registered.
#59: Undervoltage Switch.Off	Alarm	The input voltage line caused the actuator to turn off 6 times, indicating an unstable power supply.
#60: Overvoltage Warning	Warning	The input voltage is over the regular supply voltage range. Motor operation is possible.
#61: PVST Start	Information	A PVST procedure was started
#62: Parameter Write Access	Information	Shows information about, which value was written on a parameter. The values for N, L and S are internal values and useful for diagnosing.
#63: Restore	Information	A restore procedure via P20.3 was undertaken.
#64: Password Change	Information	A password change has been undertaken.
#65: History Cleared	Information	The complete history entry memory was cleared by the manufacturer.

13 Fuses

The Logik board of the controller cover (see Figure 80, page 69) features two miniature fuses for the control lines.




Figure 80: FL1... fuse for auxiliary supply, FL2... fuse for the binary outputs

Fuses on the logic board

Fuse	Value	Manufacturer	No. of spare parts
FL1	1AT	Littelfuse 454 NANO ² Slo-Blo [®] slow	FUSE-F1
FL2	4AT	Littelfuse 454 NANO ² Slo-Blo [®] slow	FUSE-F2

The frequency inverter is protected by an input fuse and the explosion-proof version also has a thermal fuse (see section 2.7.3, page 27).



14 Spare parts

When ordering spare parts, please provide us with the serial number of the actuator (see section 2.2, page 25). Check the separate break-down image and separate list of spare parts.

15 Lubricant recommendation, lubricant requirements

Please note, that safety precautions such as the use of personal protective equipment (PPA) may have to be followed! Please consult the safety datasheet (in section 8) of the product in question.



15.1 Main body: -25 to +60°C

Operating oil: DIN 51 517-CLP-HC

i.e. fully synthetic high-performance gear oils based on poly-alpha-olefins (PAO)

Viscosity class:	320 ISO VG
Pourpoint:	< -39°C (according DIN ISO 3016)
Lubricant requirement CM03:	200... 250 ml
Lubricant requirement CM06:	300... 350 ml
Lubricant requirement CM12:	600... 650 ml

15.2 Main body: -40 to +60°C

Operating oil: DIN 51 517-CLP-HC

i.e. fully synthetic high-performance gear oils based on poly-alpha-olefins (PAO)

Viscosity class:	68 ISO VG
Pourpoint:	< -54°C (according DIN ISO 3016)
Lubricant requirement CM03:	200... 250 ml
Lubricant requirement CM06:	300... 350 ml
Lubricant requirement CM12:	600... 650 ml

15.3 Output type A and spindle drives (linear actuators) -40 to +60 °C

Grease DIN 51825-K(P) R -40

i.e. water repellent complex grease on Al-soap base with high resistance to acids and alkalis

Penetration 0.1 mm:	310 -340
Dropping point:	about 260 °C
NLGI No.:	1
acid-free, little or not water-reactive	

15.4 Basic lubricant service interval

Schiebel actuators must be serviced 10 years after delivery by SCHIEBEL Antriebstechnik GmbH, A-1230 Vienna. The functionality and durability of the lubricant is however contingent upon the operating conditions. Where applicable, reduction factors must be considered.



Operating condition (s)	Definition	Reduction factor (multiplier)
Duty time DT	(Total engine running time)	
Extremely high DT	over 1250 hours/year	0.5
High DT	over 500 hours/year	0.7
Extremely low DT	less than 0.5 hours/year	0.8
Ambient temperature	(permanent or long-term)	
Extremely changeable	between -10 and +50 °C	0.5
Extremely high	above +50 °C	0.7
Extremely low	below -25 °C	0.9
Output speed	(on actuator main shaft)	
High speed	over 80 rpm	0.8
Utilisation	(relative to rated power)	
Very high	over 90%	0.8
High	between 80 and 90%	0.9

Application example:

Extremely low DT + extremely low ambient temperature + high speed + 87% utilization

*⇒ 0.8 * 0.9 * 0.8 * 0.9 = 0.51 reduction factor*

*Lubrication maintenance interval ⇒ 10 years * 0.51 = 5.1 years (62 months).*

CAUTION: This calculated maintenance interval does neither apply to the maintenance of output type A (threated bushing) units nor to the maintenance of linear and spindle drive units. These units must be periodically lubricated (at least every 6 months) via the grease nipples (see section 15.3)!



During maintenance of our actuators, remove and replace old grease with new one. **Mixing of different lubricant types is NOT permitted.**

Quantities needed for lubricant service are listed in section 15, page 69.

16 Training

CAUTION: If you experience problems during installation or upon adjustments on site, please contact SCHIEBEL, Vienna at +43 (1) 66 108 or via the Internet at www.schiebel-actuators.com to prevent any operational errors or damage to the actuators. Schiebel recommends engaging only qualified personnel for installation of Schiebel actuators. Upon special request of the client, SCHIEBEL can conduct training on the activities listed in this operating manual at the factory of SCHIEBEL.



17 Original Declaration of Incorporation of Partly Completed Machinery

According Machinery Directive 2006/42/EC (Annex II, sub. B)

The manufacturer, the company:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Vienna

hereby declares that for the partly completed machinery described below:

Electric actuators series:

CM	rCM	exCM	exrCM
----	-----	------	-------

the following basic requirements of the Machinery Directive (2006/42/EC) are applied and fulfilled:

Annex I,	articles	1.1.2, 1.1.3, 1.1.5; 1.2.1, 1.2.1, 1.2.2, 1.2.6; 1.3.1, 1.3.2, 1.3.7; 1.5.1; 1.6.3; 1.7.1, 1.7.3, 1.7.4
----------	----------	--

The following European harmonized standards have been applied:

EN 12100:2010		
EN ISO 5210:1996	EN ISO 5211:2001	DIN 3358:1982

The relevant technical documentation for partly completed machinery referred to in Annex VII, Part B has been prepared. The manufacturer commits to electronically submitting the documents for the incomplete machine to the competent national authority upon request.

For the preparation of the technical documents is authorized:

Head of mechanical Engineering
Schiebel Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Vienna

This partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC, where appropriate.

The electric actuators as partly completed machinery are in conformity with the relevant regulations of the EU directives:

Directive 2014/30/EU ("EMV-Directive")
Directive 2014/35/EU ("Low voltage directive")
Directive 2014/34/EU ("ATEX-Directive") for correspondingly marked devices

The corresponding separate EC Declarations of Conformity are valid.

Vienna,
(location)

13th March 2018
(date)



.....
(Klaus Schiebel, general manager)

18 Declaration of Conformity

(EMV directive and Low voltage directive)

The producer:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Wien

herewith confirms that the equipment

electric actuators with integrated control unit model Actusmart and following types

- (r) CM03
- (r) CM03 FS
- (r) CM06
- (r) CM06 FS

meets the requirement of the EC directive:

2014/30/EU („EMV directive“)

and complies with the following harmonised standards in the version valid at signature date:

EN 61000-6-2:2005 EN 61000-6-4:2014

and are also consistent with the EC directive:

2014/35/EU („Low voltage directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

IEC 60204-1:2005 + A1:2008 EN 60529:1991 + A1:2000

Vienna,
(location)

14.2.2018
(date)



.....
(Klaus Schiebel, general manager)

19 Declaration of Conformity

(Ex directive, EMV directive and Low voltage directive)

The producer:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Wien

herewith confirms that the equipment

electric actuators with integrated control unit model Actusmart and following types

Type ex (r) CM03	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X
Type ex (r) CM03 FS	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X
Type ex (r) CM06	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X
Type ex (r) CM06 FS	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X

meets the requirement of the EC directive:

2014/34/EU

EC Directive for Operation of Equipment in Potentially Explosive Atmospheres

and complies with the following harmonised standards in the version valid at signature date:

EN 60079-0:2012	EN 60079-1:2014	EN 60079-7:2015
EN ISO 80079-36:2016	EN ISO 80079-37:2016	

For the above listed actuators, a type examination certificate TUV A13ATEX0006X, issued by TÜV Austria Services GMBH, is available.

TÜV Austria Services GmbH	A-1230 Wien	NB 0408: Type examination certification
FTZU	CZ-716 07 Ostrava Radvanice	NB 1026: Quality system FTZU03ATEXQ019

Furthermore, they are consistent with the EC directive

2014/30/EU („EMV directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

EN 61000-6-2:2005	EN 61000-6-4:2014
--------------------------	--------------------------

and are also consistent with the EC-directive:

2014/35/EU („Low voltage directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

IEC 60204-1:2005 + A1:2008	EN 60529:1991 + A1:2000
-----------------------------------	--------------------------------

Vienna,
(location)

14.2.2018
(date)



.....
(Klaus Schiebel, general manager)

20 Technical data




Figure 81: Control unit




Figure 82: Logik board

20.1 Binary outputs

Count:	8
Power supply:	24 VDC nominal range: 11... 35 VDC (either from internal or external)
Max voltage drop at set output:	1 V
Output voltage at non-set output:	<1 V
Maximum current per output:	500 mA (short circuit proof)
Maximum permissible total current for all outputs:	4 A
Fuse (Fuse FL2, see Figure 82, page 74):	4 A slow (Littelfuse 454 NANO ² Slo-Blo [®])


Binary outputs with external supply are separated from other controllers via optocouplers.

It is allowed to connect binary outputs in parallel. If the outputs have the same setting (see chapter 7.9), the current of each output may be added together. If the settings of the outputs are different, a hardwired logical OR is realized.

20.2 Binary inputs

Count:	5
Nominal voltage:	24 VDC towards common ground
Voltage for input set:	>10 V (8.5 V typ.)
Voltage for input not set:	<7 V (8.5 V typ.)
Maximum voltage:	30 VDC
Current consumption at 24 VDC:	10.5 mA typ.

Binary inputs are separated from other controllers via optocouplers.



U_i ... Input voltage
 i_i ... Input current

Figure 83: Binary inputs, input characteristic

Jumpers JP1 ... JP3 can be used to interconnect the binary inputs to groups with separate earths:




Figure 84: 5 inputs with same common




Figure 85: 2 separated groups of 2 inputs with same ground
 Input IN3 is disabled.




Figure 86: 3 separated inputs
 Inputs IN2 and IN4 are disabled.




Figure 87: 3 inputs with same common and 1 separated input.
 Input IN4 is disabled.




Figure 88: 1 separated input and 3 inputs with same common.
Input IN2 is disabled.

Examples:




Figure 89: 5 inputs with common = "-" using external 24V




Figure 90: 5 inputs with common = "-" using internal 24V (e.g. for dry contacts)




Figure 91: 3 separated inputs using 3 separated external 24V




Figure 92: 3 separated inputs with common = "+" using external 24V

20.3 Analog inputs

Input 1: setpoint value

- Current range:0... 25 mA
- Resolution: 14 bit
- Accuracy: 0.5%
- Input resistance: 60 Ω

Analog input 1 is electrically isolated from the rest of the electronic system.

Input 2: External actual value (only in combination with PID controller)

- Current range:0... 20.8 mA
- Resolution: 12 bit
- Accuracy: 0.5%
- Input resistance: 120 Ω

Jumper JP6 can be used to switch analog input 2 from a passive input (default) to an input with internal 24 V power supply (for 4...20 mA, two-wire transmitters).




Figure 93: Passive input (default)




Figure 94: Input with internal supply (active input)

NOTE: The analog input 2 is referenced to common of the electronic system and the auxiliary power supply (see section 20.5).

20.4 Analog output

Current range: 0...20.8 mA
 Resolution: 12 bit
 Accuracy: 0.5%
 Max load: 600 Ω

The analog output is galvanically isolated from the rest of the electronic system.

Jumper JP4 can be used to switch the analog output from an active power source (default) to a current sink, allowing the output to simulate a 4...20 mA, two-wire transmitter.




Figure 95: Current source




Figure 96: Current sink

Ground potential is the potential of the control unit and the auxiliary supply (see chapter 20.5).

20.5 Auxiliary voltage input and output

Input voltage range (auxiliary voltage input): 20...30 VDC
 Maximum current consumption (auxiliary voltage input): 500 mA
 Maximum current consumption in power-save mode 120 mA
 (auxiliary voltage input):
 Output voltage (auxiliary voltage output): typ. 23 V
 Maximum output current (auxiliary voltage output): 200 mA
 Resistance of common ground vs. earth: typ. 500 kΩ
 Resistance of common ground vs. earth (floating version): > 10 MΩ
 Capacitance of common ground vs. earth: typ. 100 nF
 Maximum allowed voltage of common ground vs. earth: max. 40 Vs
 Fuse (Fuse FL1, see picture 82, page 74): 1 A slow
 (Littelfuse 454 NANO² Slo-Blo[®])

Ground potential is the common ground of the controller and the analog inputs and outputs.
 The auxiliary voltage output can be set in menu P6.5 (see section 7.5, page 47).

The power-save mode is defined as follows:

- No power supply (the controller is powered exclusively through the 24 V auxiliary voltage input).
- The backlight of the LCD display switches off automatically.
- No additional hardware options included (Profibus Interface, DeviceNet interface, relay board, etc. . .).
- Binary outputs and the mA output are not enabled; when activating, the respective currents must be added to the total current consumption.

20.6 Connections

20.6.1 Connections for non explosion-proof version

Power/motor: Industrial plug with 6 pins
Screw connection 16 A,
max. 2.5 mm² , AWG14

Control signals: Industrial plug with 24 pins
Screw connection
16 A, max. 2.5 mm², AWG14

Optionally, contacts are available in crimp or cage clamp designs.

20.6.2 Connections for explosion-proof version

Power/motor: terminals with screw connection
16 A, 0.5... 4 mm², AWG20... AWG12

Control signals: terminals with screw connection
4 A, 0.5... 2.5 mm², AWG20... AWG14

20.7 Mode of operation CM

ON-OFF & INCHING operation	
CM03	CM06
S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034
2,5 - 72 RPM	2,5 - 60 RPM
$M_{max} = 32$ Nm	$M_{max} = 64$ Nm
$M_{avg} = 16$ Nm	$M_{avg} = 20$ Nm
Life time*	
10.000 cycles	10.000 cycles
MODULATING operation	
CM03	CM06
S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034
2,5 - 36 RPM	2,5 - 30 RPM
$M_{max} = 32$ Nm	$M_{max} = 64$ Nm
$M_{avg} = 16$ Nm	$M_{avg} = 32$ Nm
Life time*	
1.800.000 starts	1.800.000 starts
CONTINUOUS MODULATING operation	
CM03	CM06
S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034
2,5 - 20 RPM	2,5 - 20 RPM
$M_{max} = 32$ Nm	$M_{max} = 64$ Nm
$M_{avg} = 10$ Nm	$M_{avg} = 20$ Nm
Life time*	
1.800.000 starts	1.800.000 starts

***ATTENTION: life time is based on proper operation and maintenance according to SCHIEBEL operating manual**

CYCLE = 25 turns in both directions with at least 30% of nominal torque and the ability to accept 100% of nominal torque for at least 10% of the stroke

START = movement of at least 1% of stroke in both directions with a load of minimum 30% of nominal torque

20.8 Mode of operation CM03 + QT

ON-OFF & INCHING operation		
CM03 + QT12	CM03 + QT25	CM06 + QT50
S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034
2,5 - 10 RPM	2,5 - 20 RPM	2,5 - 20 RPM
$M_{max} = 120 \text{ Nm}$	$M_{max} = 250 \text{ Nm}$	$M_{max} = 500 \text{ Nm}$
$M_{avg} = 60 \text{ Nm}$	$M_{avg} = 125 \text{ Nm}$	$M_{avg} = 160 \text{ Nm}$
Life time*		
10.000 cycles	10.000 cycles	10.000 cycles

MODULATING operation		
CM03 + QT12	CM03 + QT25	CM06 + QT50
S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034
2,5 - 10 RPM	2,5 - 20 RPM	2,5 - 20 RPM
$M_{max} = 120 \text{ Nm}$	$M_{max} = 250 \text{ Nm}$	$M_{max} = 500 \text{ Nm}$
$M_{avg} = 60 \text{ Nm}$	$M_{avg} = 125 \text{ Nm}$	$M_{avg} = 250 \text{ Nm}$
Life time*		
1.800.000 starts	1.200.000 starts	1.200.000 starts

CONTINUOUS MODULATING operation		
CM03 FS 30/5	CM03 FS 50/8	CM03 FS 100/12
S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034
2,5 - 10 RPM	2,5 - 20 RPM	2,5 - 20 RPM
$M_{max} = 120 \text{ Nm}$	$M_{max} = 250 \text{ Nm}$	$M_{max} = 500 \text{ Nm}$
$M_{avg} = 40 \text{ Nm}$	$M_{avg} = 80 \text{ Nm}$	$M_{avg} = 160 \text{ Nm}$
Life time*		
1.800.000 starts	1.200.000 starts	1.200.000 starts

*ATTENTION: life time is based on proper operation and maintenance according to SCHIEBEL operating manual

CYCLE = movement of 90° in both directions with at least 30% of nominal torque and the ability to accept 100% of nominal torque for at least 5% of the stroke

START = movement of at least 1° of stroke in both directions with a load of minimum 30% of nominal torque

20.9 Mode of operation CM03 + L

ON-OFF & INCHING operation		
CM03 + L50	CM03 + L100	CM03 + L350
S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034
2,5 - 72 RPM	2,5 - 60 RPM	2,5 - 60 RPM
$F_{max} = 15 \text{ kN}$	$F_{max} = 25 \text{ kN}$	$F_{max} = 26 \text{ kN}$
$F_{avg} = 7,5 \text{ kN}$	$F_{avg} = 10 \text{ kN}$	$F_{avg} = 10 \text{ kN}$
Life time*		
10.000 cycles	10.000 cycles	10.000 cycles

MODULATING operation		
CM03 + L50	CM03 + L100	CM03 + L350
S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034
2,5 - 36 RPM	2,5 - 30 RPM	2,5 - 30 RPM
$F_{max} = 15 \text{ kN}$	$F_{max} = 25 \text{ kN}$	$F_{max} = 26 \text{ kN}$
$F_{avg} = 7,5 \text{ kN}$	$F_{avg} = 12,5 \text{ kN}$	$F_{avg} = 13 \text{ kN}$
Life time*		
1.800.000 starts	1.200.000 starts	1.200.000 starts

CONTINUOUS MODULATING operation		
CM03 + L50	CM03 + L100	CM03 + L350
NOT AVAILABLE	NOT AVAILABLE	NOT AVAILABLE

*ATTENTION: life time is based on proper operation and maintenance according to SCHIEBEL operating manual

CYCLE = stroke of 40 mm in both directions with at least 30% of nominal torque and the ability to accept 100% of nominal torque for at least 5% of the stroke

START = movement of at least 1% of stroke in both directions with a load of minimum 30% of nominal torque

20.10 Mode of operation CM03 + LK

ON-OFF & INCHING operation		
CM03 + LK50	CM03+ LK100	CM03 + LK120
S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034	S2 - 15 minutes according to IEC 60034
2,5 - 72 RPM	2,5 - 72 RPM	2,5 - 60 RPM
$F_{max} = 15$ kN	$F_{max} = 30$ kN	$F_{max} = 60$ kN
$F_{avg} = 15$ kN	$F_{avg} = 15$ kN	$F_{avg} = 20$ kN
Life time*		
10.000 cycles	10.000 cycles	10.000 cycles

MODULATING operation		
CM03 + LK50	CM03+ LK100	CM03 + LK120
S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034	S4 - 1.200 c/h - max. 50% DC according to IEC 60034
2,5 - 36 RPM	2,5 - 36 RPM	2,5 - 30 RPM
$F_{max} = 15$ kN	$F_{max} = 30$ kN	$F_{max} = 60$ kN
$F_{avg} = 15$ kN	$F_{avg} = 15$ kN	$F_{avg} = 30$ kN
Life time*		
1.800.000 starts	1.200.000 starts	1.200.000 starts

CONTINUOUS MODULATING operation		
CM03 + LK50	CM03+ LK100	CM03 + LK120
S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034	S9 - 1.800 c/h according to IEC 60034
2,5 - 20 RPM	2,5 - 20 RPM	2,5 - 20 RPM
$F_{max} = 15$ kN	$F_{max} = 30$ kN	$F_{max} = 60$ kN
$F_{avg} = 10$ kN	$F_{avg} = 10$ kN	$F_{avg} = 20$ kN
Life time*		
1.800.000 starts	1.200.000 starts	1.200.000 starts

*ATTENTION: life time is based on proper operation and maintenance according to SCHIEBEL operating manual

CYCLE = stroke of 40 mm in both directions with at least 30% of nominal torque and the ability to accept 100% of nominal torque for at least 5% of the stroke

START = movement of at least 1% of stroke in both directions with a load of minimum 30% of nominal torque

20.11 Miscellaneous

Ambient temperature:

non explosion-proof version: -25 ... +60 °C

explosion-proof version: -20 ... +40 °C (according EN 60079-0)

ex version with extended temperature range: -40 ... +60 °C

Protection according to EN 60529: IP67

Standard colour: RAL7024

CAUTION: If the actuator is exposed to excessive UV-light, colour deviations of the painting might occur.

21 Technical data CM03

The motor (brushless DC motor) is controlled via integrated power electronics, which also provide the supply voltage for the controller.

21.1 Standard version CM03

Output torque:	max. 32 Nm
Average permissible output torque:	max. 16 Nm
Setting range of tripping torque:	8 ... 32 Nm
Setting range of output speed:	2.5 ... 72.2 min ⁻¹
Travel range:	max. 100 revs
Reduction ratio handwheel:	2,5
Output resolution:	about 0.25°
Supply voltage range AC:	90 ... 240 Vrms +/-10%, 50/60 Hz
Supply voltage range DC:	100 ... 220 V +/-10%
Nominal current (16 Nm / 72,2 min ⁻¹):	1.47 A / 230 VAC
Idle power consumption:	12 W typ., 24 W max.
Weight:	11.5 daN

21.2 24 VDC version CM03

Output torque:	max. 32 Nm (output speed 5 min ⁻¹) max. 10 Nm (output speed 20 min ⁻¹)
Average permissible output torque:	max. 16 Nm
Setting range of tripping torque:	8 ... 32 Nm
Setting range of output speed:	2.5 ... 20 min ⁻¹
Supply voltage range:	24 VDC +/-10%
Nominal current (10Nm / 20U/min):	4.6 A
Idle power consumption:	6 W typ., 18 W max.
all other dates see output data - standard version	

21.3 400 V version CM03

Output torque:	max. 32 Nm
Average permissible output torque:	max. 16 Nm
Setting range of tripping torque:	8 ... 32 Nm
Setting range of output speed:	2.5 ... 72.2 min ⁻¹
Travel range:	max. 100 revs
Output resolution:	about 0.25°
Supply voltage range AC:	3 x 380... 480 VAC +/-10%, 50/60 Hz
Nominal current (16 Nm / 72.2 rpm):	0.46 A / 3 x 400 VAC
Weight:	11.5 daN

Idle power consumption is measured with an idle motor and is dependent on the existing hardware options.

22 Technical data CM06

The motor (brushless DC motor) is controlled via integrated power electronics, which also provide the supply voltage for the controller.

22.1 Standard version CM06

Output torque:	max. 64 Nm
Average permissible output torque:	max. 20 Nm
Setting range of tripping torque:	16 ... 64 Nm
Setting range of output speed:	2.5 ... 64 min ⁻¹
Travel range:	max. 100 revs / 300 revs
Reduction ratio handwheel:	2,5
Output resolution:	about 0.25° / 0.75°
Supply voltage range AC:	90 ... 240 Vrms +/-10%, 50/60 Hz
Supply voltage range DC:	100 ... 220 V +/-10%
Nominal current (20 Nm / 60min ⁻¹):	2.17 A / 230 VAC

23 Technical data CM12

Idle power consumption:	12 W typ., 24 W max.
Weight:	15.5 daN

22.2 400V version CM06

Output torque:	max. 64 Nm
Average permissible output torque:	max. 20 Nm
Setting range of tripping torque:	16 ... 64 Nm
Setting range of output speed:	2.5 ... 64 min ⁻¹
Travel range:	max. 100 revs / 300 revs
Output resolution:	about 0.25° / 0.75°
Supply voltage range AC:	3 x 380... 480 VAC +/-10%, 50/60 Hz
Nominal current (32 Nm / 60min ⁻¹):	0.9 A / 3 x 400 VAC
Weight:	15.5 daN

Idle power consumption is measured with an idle motor and is dependent on the existing hardware options.

23 Technical data CM12

The motor (brushless DC motor) is controlled via integrated power electronics, which also provide the supply voltage for the controller.

23.1 Standard version CM12

Output torque:	max. 125 Nm
Average permissible output torque:	max. 40 Nm
Setting range of tripping torque:	32 ... 125 Nm
Setting range of output speed:	2.5 ... 70 min ⁻¹
Travel range:	max. 100 revs / 300 revs
Reduction ratio handwheel:	2,5
Output resolution:	about 0.25° / 0.75°
Supply voltage range AC:	90 ... 240 Vrms +/-10%, 50/60 Hz
Supply voltage range DC:	110 ... 220 V +/-10%
Nominal current (40 Nm / 70min ⁻¹):	3,8 A / 230 VAC
Idle power consumption:	12 W typ., 24 W max.
Weight:	22 daN

24 Characteristic curves

24.1 Characteristic curves - CM03




Figure 97: Current draw of the standard version




Figure 98: Current draw of the 24 VDC version

24.2 Characteristic curves - CM06




Figure 99: Current draw of the standard version

24.3 Characteristic curves - CM12





Figure 100: Current draw of the standard version

Spare parts ACTUSMART (ex)(r)CM03 F(S)QT



CAUTION: When ordering spare parts, you **must** provide the **serial number** (look type shield or status menu S6).


Use only original spare parts supplied by SCHIEBEL. Using other parts will render the warranty void. Illustrations may differ from actual spare parts.



Asm.	No.	Description
1		E-case
	1-1	Control unit cover
	1-2	Display circuit board
	1-3	Logic circuit board
	Fuse-F1	Micro fuse 1A
	Fuse-F2	Micro fuse 4A
	1-4	Expansion board (bus, relay)
	1-5	Multiturn sensor assembly
	1-5-1	Multiturn sensor
	1-5-2	24VDC Step-Down Converter
	1-6	BLDC Power Electronics
	Fuse-F3	Fuse 5AT (16AT for 24V actuators with BLDC version 200)
	1-7	Motor
	1-8-1	Sensor shaft
	1-8-2	Gear
2		Mech. case
	2-1	Worm gear
	2-2	Output shaft
	2-3	Helical cut pinion gear
3		Failsafe Brake Assembly
	3-1	Failsafe PCB
4		Plug cover
	4-1	Plug frame customer side (socket)
	4-2	Plug frame actuator side (pins)
5		Terminal box cover
	5-1	Terminal block
6		Entire bus plug cover with plugs & circuit board
	6-1	Bus plug frame customer side (socket)
	6-2	Bus plug frame actuator side (pins)
	6-3	Bus connection board
7		Additional ring bus (Ex)
8		400V module
TS		Type plate

Asm.	No.	Description
9		Handwheel Cover
	9-1	Switch for Manual Mode
	9-2	Handwheel
	9-3	Padlock
10		Failsafe Brake Cover
11		Failsafe Unit
	11-1	Mechanical Position Indicator
	11-2	Output Flange
	11-3	Drive bushing
TS-FSQT		Type plate Failsafe Unit

Spare parts ACTUSMART (ex)(r)CM06 F(S)QT



CAUTION: When ordering spare parts, you **must** provide the **serial number** (look type shield or status menu S6).

Use only original spare parts supplied by SCHIEBEL. Using other parts will render the warranty void. Illustrations may differ from actual spare parts.



Asm.	No.	Description
1		E-case
	1-1	Control unit cover
	1-2	Display circuit board
	1-3	Logic circuit board
	Fuse-F1	Micro fuse 1A
	Fuse-F2	Micro fuse 4A
	1-4	Expansion board (bus, relay)
	1-5	Multiturn sensor assembly
	1-5-1	Multiturn sensor
	1-5-2	24VDC Step-Down Converter
	1-6	BLDC Power Electronics
	Fuse-F3	Fuse 5A
	1-7	Motor
	1-8-1	Sensor shaft
	1-8-2	Gear
2		Mech. case
	2-1	Worm gear
	2-2	Output shaft
	2-3	Helical cut pinion gear
3		Failsafe Brake Assembly
	3-1	Failsafe PCB
4		Plug cover
	4-1	Plug frame customer side (socket)
	4-2	Plug frame actuator side (pins)
5		Terminal box cover
	5-1	Terminal block
6		Entire bus plug cover with plugs & circuit board
	6-1	Bus plug frame customer side (socket)
	6-2	Bus plug frame actuator side (pins)
	6-3	Bus connection board
7		Additional ring bus (Ex)
8		400V module
TS		Type plate

Asm.	No.	Description
9		Handwheel Cover
	9-1	Switch for Manual Mode
	9-2	Handwheel
	9-3	Padlock
10		Failsafe Brake Cover
11		Failsafe Unit
	11-1	Mechanical Position Indicator
	11-2	Output Flange
	11-3	Drive bushing
TS-FSQT		Type plate Failsafe Unit

**schiebel
-actuators
.com**

SCHIEBEL

SCHIEBEL Antriebstechnik
Gesellschaft m.b.H.
Josef Benc Gasse 4
A 1230 Wien
Tel.: +43 1 66 108 - 0
Fax: +43 1 66 108 - 4
info@schiebel-actuators.com
www.schiebel-actuators.com