

Operating Manual ACTUSMART CM, control unit version 1.2



Contents

Contents	2
Operating Manual ACTUSMART CM.V1.2	5
1 Introduction/Notes	5
2 General	6
2.1 Overview	6
2.2 Serial number and type label	6
2.3 Operating mode	7
2.4 Protection class	7
2.5 Mounting position	7
2.6 Direction of rotation	7
2.7 Protection devices	8
2.7.1 Torque	8
2.7.2 Motor temperature	8
2.7.3 Input fuse, thermal fuse	8
2.8 Ambient temperature	8
2.9 Delivery condition of the actuators	8
2.10 Information notice (tag)	9
3 Packaging, transport and storage	9
3.1 General	9
3.2 Storage	9
3.3 Long-term storage	10
4 Installation instructions	10
4.1 Mechanical connection	10
4.2 Mounting position of the operating unit	11
4.3 Electrical connection	13
4.3.1 Power supply connection	13
5 Commissioning	14
5.1 General	14
5.2 Manual operation	14
5.3 Mechanical default settings, preparation	14
5.4 User Level and Permissions	15
5.5 End limit setting	15
5.5.1 End limit OPEN	15
5.5.2 End limit CLOSE	17
5.6 Final works	18
6 Control Unit	18
6.1 Operating unit	18
6.2 Display elements	19
6.2.1 Graphic display	19
6.2.2 LED Display	19
6.3 Operation	20
6.4 Welcome Menu	20
6.4.1 Operation mode	22
6.4.2 Configuration	22
6.4.3 Configuration example	23
6.4.4 „TEACHIN“	24
7 Parameter menu	26
7.1 Parameter group: End limit	26
7.2 Parameter group: Torque	27
7.3 Parameter group: Speed	28
7.4 Parameter group: Ramp (optional)	28
7.5 Parameter group: Control	28
7.6 Parameter group: User Level	29
7.7 Parameter group: Position	31
7.8 Parameter group: Binary inputs	32
7.8.1 Optional: Virtual Input	35
7.9 Parameter group: Binary outputs	37
7.9.1 Optional: Virtual Output	40

7.10	Parameter group: Position output (optional)	43
7.11	Parameter group: Step mode	43
7.12	Parameter group: Positioner (optional)	45
7.13	Parameter group: PID controller (optional)	47
7.14	Parameter group: Bus systems (optional)	48
7.15	Parameter group: Stroketest (optional)	49
7.15.1	Operating Manual Partial-Valve-Stroke-Test (PVST)	49
7.16	Parameter group: Characteristic curves (optional)	52
7.16.1	Torque characteristic	52
7.16.2	Speed characteristic	52
7.16.3	Valve characteristic	53
7.17	Parameter group: Identification (optional)	54
7.18	Parameter group: System parameters	54
7.19	Parameter group: Miscellaneous	55
7.20	Default User Level Settings	57
8	Status area	60
8.1	Status	60
8.1.1	Status – binary outputs	60
8.1.2	Status – binary inputs	60
8.1.3	Status – analog values	61
8.1.4	Status – absolute values	61
8.1.5	Status – firmware	62
8.1.6	Status – serial number	62
8.1.7	Status – meter readings	62
8.2	History	62
9	Infrared connection	63
10	Bluetooth connection	63
11	Maintenance	64
12	Battery Replacement	65
13	Troubleshooting	65
13.1	History Entries	65
14	Fuses	68
15	Spare parts	68
16	Lubricant recommendation, lubricant requirements	68
16.1	Main body: -25 to +60 °C	68
16.2	Main body: -40 to +60 °C	68
16.3	Output type A and spindle drives (linear actuators) -40 to +60 °C	69
16.4	Basic lubricant service interval	69
17	Training	69
18	Original Declaration of Incorporation of Partly Completed Machinery	70
19	Declaration of Conformity	71
20	Declaration of Conformity	72
21	Technical data	73
21.1	Binary outputs	73
21.2	Binary inputs	73
21.3	Analog inputs	75
21.4	Analog output	76
21.5	Auxiliary voltage input and output	76
21.6	Connections	77
21.6.1	Connections for non explosion-proof version	77
21.6.2	Connections for explosion-proof version	77
21.7	Mode of operation CM	78
21.8	Miscellaneous	79
22	Technical data CM03	79
22.1	Standard version CM03	79
22.2	24 VDC version CM03	79
22.3	400 V version CM03	79

CONTENTS

23 Technical data CM06	79
23.1 Standard version CM06	80
23.2 400V version CM06	80
24 Technical data CM12	80
24.1 Standard version CM12	80
25 Characteristic curves	81
25.1 Characteristic curves - CM03	81
25.2 Characteristic curves - CM06	82
25.3 Characteristic curves - CM12	83
Spare parts ACTUSMART (ex)(r)CM03.V1.2	84
Spare parts ACTUSMART (ex)(r)CM06.V1.2	86
Spare parts ACTUSMART (ex)(r)CM12.V1.2	88

Operating Manual ACTUSMART CM.V1.2

1 Introduction/Notes

NOTE: This IOM applies to ACTUSMART CM series actuators with a firmware version of 1600 or newer.

These operating instructions apply to SCHIEBEL actuators of the ACTUSMART CM series.

The scope of application covers the operation of industrial valves, e.g., globe valves, gate valves, butterfly valves and ball valves. For other applications please consult with the factory.

The manufacturer shall not be liable for incorrect use and possible damage arising thereof. The risk shall be borne solely by the user.

NOTE: Using the unit as intended also entails the observance of these operating instructions!

WARNING: When operating electrical equipment, certain parts inevitably carry hazardous voltage levels. Work on the electrical system or equipment must be carried out only in accordance with electrical regulations by a qualified electrician himself or by specially instructed personnel under the control and supervision of a qualified electrician.



CAUTION: Maintenance instructions must be observed as otherwise the safe operation of the actuator cannot be guaranteed.



WARNING: Failure to follow the warning information may result in serious bodily injury or property damage. Qualified personnel must be thoroughly familiar with all warnings contained in this operating manual.



CAUTION: Proper transport, storage, installation, assembly and careful commissioning are essential for proper and safe operation.



WARNING: When working in potentially explosive areas, observe the European Standards EN 60079-14 "Electrical Installations in Hazardous Areas" and EN 60079-17 "Inspection and Maintenance of Electrical Installations in Hazardous Areas".



WARNING: Maintenance work on open actuators may only be conducted if these are de-energized. Re-connection during maintenance is strictly prohibited.



2 General

The actuator of the ACTUSMART CM series is a compact rotary actuator with integrated controller for valve operation. The integral multi-turn sensor allows setting the travel up to 108¹⁾ revolutions without opening the housing.

2.1 Overview



Figure 1: 1... Handwheel, 2... Control unit (operating unit), 3... Connection compartment 4... Gear component

2.2 Serial number and type label

Each actuator of the ACTUSMART CM series carries a serial number. The serial number is a 10-digit number that begins with the year and that can be read from the type label (see Figure 2) of the actuator (the type label is located next to the handwheel – see Figure 3).

Using this serial number, SCHIEBEL can uniquely identify the actuator (type, size, design, options, technical data and test report).




Figure 2: Type label



Figure 3: 1... Type label

Actuators which are suitable for operation in explosive atmosphere (see EU Directive 94/9/EG and EN 60079-0 Standard) are separately designated by a special type label (Ex, TÜV Standard, Figure 4).




Figure 4: Type label of the actuator for operation in explosive atmosphere

¹⁾Optional: Up to 1600 revs.

2.3 Operating mode

ACTUSMART CM actuators are suitable for open-loop control (S2 operating mode – on/off duty), closed-loop control (S4 operating mode – modulating duty) and continuous mode (S9 operating mode) according to EN 60034-1.

2.4 Protection class

ACTUSMART CM actuators by default meet IP 67 (EN 50629) protection.

CAUTION: The protection class specified on the type label is only effective when the cable glands also provide the required protection class, the cover of the connection compartment is carefully screwed closed, and the mounting position (see section 2.5, page 7) is observed.



We recommend metallic screwed cable glands with a metrical thread. Furthermore, cable inlets that are not needed must be closed with screw plugs.

CAUTION: On explosion-proof actuators, cable glands with protection class **EEx e acc. EN 60079-7** must be used. **After removing covers** for assembly purposes or adjustment work, take special care upon reassembly so that seals are not damaged and remain properly fastened. Improper assembly may lead to water ingress and to failures of the actuator.



CAUTION: The cover of the control unit – the operating unit (see Figure 1, page 6) – must not be opened!



NOTE: Allow a certain sag in the connector cables before reaching the screwed cable glands so that water can drip off from the connector cables without running to the screwed cable glands. This way, forces acting on the screwed cable glands are also reduced (see section 2.5).

2.5 Mounting position

Generally, the installation position is irrelevant. However, based on practical experience, it is advisable to consider the following for outdoors use or in splash zones:

- Mount actuators with cable inlet facing downwards.
- Ensure that sufficient cable slack is available.

2.6 Direction of rotation

Unless specifically ordered otherwise, the standard direction is (see Figure 5 and Figure 6):

- **right turning (clockwise) = CLOSING**
- **left turning (counter-clockwise) = OPENING**

Clockwise rotation of the actuator is given when the output shaft turns counter clockwise when looking at the output shaft.




Figure 5: clockwise = close




Figure 6: counter-clockwise = close

NOTE: All specifications in this operating manual refer to the standard direction of rotation.

2.7 Protection devices

2.7.1 Torque

ACTUSMART actuators provide electronic torque monitoring.

The switch-off torque can be modified in the controller menu for each direction separately. By default, switch-off torque is set to the ordered value. If no torque was specified with the order, the actuator is supplied from the factory with the maximum configurable torque.

For more information, see section 7.2, page 27.

2.7.2 Motor temperature

All ACTUSMART CM actuators are normally equipped with motor winding temperature sensors, which protect the motor against excessive winding temperature.

The display will show the corresponding error upon exceeding the permissible motor temperature (see section 13.1, page 65).

2.7.3 Input fuse, thermal fuse

The frequency inverter has an input fuse and, in the case of explosion-proof versions, also a thermal fuse. If one of these fuses trips, there is a serious fault. The frequency converter is permanently disconnected from the supply and must be replaced.

Depending on the actuator type, the following input fuses are used:

Actuator Type	Supply Voltage	Current Rating
(ex)CM03	1x110...240VAC	5AT
(ex)CM03	24VDC (BLDC version < 200)	5AT
(ex)CM03	24VDC (BLDC version ≥ 200)	16AT
exCM03	3x380...480VAC	5AT
(ex)CM06	1x110...240VAC	5AT
(ex)CM06	24VDC	16AT
exCM06	3x380...480VAC	5AT
(ex)CM12	1x110...240VAC	10AT
exCM12	3x380...480VAC	10AT

NOTE: Ceramic tube, 5mm x 20mm time-delay fuses acc. to IEC 60127-2 shall be used for replacement.

2.8 Ambient temperature

Unless otherwise specified upon ordering, the following operating temperatures apply:

- On/off duty (open-loop control) -25 ... +60 °C
- Modulating duty (closed-loop control) -25 ... +60 °C
- explosion-proof version -20 ... +40 °C (acc. EN 60079-0)
- explosion-proof version with extended temperature range -40 ... +60 °C

CAUTION: The maximum operating temperature can also depend on further order-specific components. Please refer to the technical data sheets to confirm the as-delivered product specifications.



2.9 Delivery condition of the actuators

For each actuator, an inspection report is generated upon final inspection. In particular, this comprises a full visual inspection, calibration of the torque measurement in connection with an extensive run examination and a functional test of the micro controllers.

These inspections are conducted and documented according to the quality system and can be made available if necessary. The basic setting of the end position must be performed after assembly on the actuator.

CAUTION: Commissioning instructions (see section 5, page 14) must be strictly observed!

During assembly of the supplied valves at the factory, end positions are set and documented by attaching a label (see Figure 7). During commissioning at the plant, these settings must be verified.






Figure 7: Label

2.10 Information notice (tag)

Each actuator is provided with a bilingual tag containing key information, which is attached to the handwheel after final inspection. This tag also shows the internal commission registration number (see Figure 8, page 9).




Figure 8: Tag

3 Packaging, transport and storage

Depending on the order, actuators may be delivered packed or unpacked. Special packaging requirements must be specified when ordering. Please use extreme care when removing or repackaging equipment.

CAUTION: Use soft straps to hoist the equipment; do not attach straps to the handwheel. If the actuator is mounted on a valve, attach the hoist to the valve and not to the actuator.



3.1 General

The connection compartment of ACTUSMART CM actuators contains 5 g of factory supplied silica gel.

NOTE: Please remove the silica gel before commissioning the actuator (see section 5, page 14).

3.2 Storage

NOTE: Please observe the following measures to avoid damage during the storage of actuators:

- Store actuators in well-ventilated, dry premises.
- Protect against floor dampness by storing actuators on wooden grating, pallets, mesh boxes or shelves.
- Protect the actuators against dust and dirt with plastic foil.
- Actuators must be protected against mechanical damage.

- The storage temperature must be between -20 °C and +40 °C.

It is not necessary to open the controller of the actuator for servicing batteries or similar operations.

3.3 Long-term storage

NOTE: If you intend to store the actuator for more than 6 months, additionally follow the instructions below:

- The silica gel in the connection compartment must be **replaced after 6 months** of storage (from date of delivery from SCHIEBEL's factory in Vienna).
- After replacing the silica gel, brush the connection cover seal with glycerine. Then, carefully close the connection compartment again.
- Coat screw heads and bare spots with neutral grease or long-term corrosion protection.
- Amend damaged paintwork arising from transport, improper storage, or mechanical influences.

WARNING: For explosion-proof actuators, it is not allowed to extensively overpaint the actuator. According to the standard, in order to avoid electrostatical charge, the maximum thickness of the varnish is limited to 200 µm.



- Every 6 months, all measures and precautions for long-term storage must be checked for effectiveness, and corrosion protection and silica gel must be renewed.

NOTE: Failure to follow the instructions above may lead to condensation which can damage the actuator.

4 Installation instructions



Figure 9: 1... mounting flange, 2... bore pattern G0/F10, 3... centring ring, 4... bore pattern F07, 5... shaft connection, 6... ground connection

Installation work of any kind on the actuator may only be performed by qualified personnel.

4.1 Mechanical connection

see Figure 9, page 10

Check whether the valve flange, actuator flange and valve shaft correspond to the shaft connector of the actuator. For output type "Am" (threaded bushing with bore), check whether the thread of the valve matches the thread of the actuator. In general, proceed as follows:

- Clean the bare parts of the actuator uncoated with corrosion protection.
- Thoroughly clean the screw mounting surfaces of the valve.
- In the actuator, appropriately lubricate the output shaft and the valve of the driven shaft.
- In the "Am" version, ensure that the valve bushing is amply lubricated.
- Attach the actuator to the valve or gearbox.
- Tighten fastening screws (torque according to table below).
- By means of the handwheel, check the ease of movement of the actuator-valve connection.

Thread	Tightening [Nm] for screws with strength class	
	8.8	A2-70 / A4-70
M6	11	8
M8	25	18
M10	51	36
M12	87	61
M16	214	150
M20	431	294
M30	1489	564

NOTE: For output type A (unbored threaded bushing), you must sufficiently lubricate both needle bearings in the output form after processing and cleaning the spindle nut.

For this purpose, use the optional SCHIEBEL grease lubricant or a grease lubricant according to our recommendation (see section 16.3, page 69).

4.2 Mounting position of the operating unit

The mounting position of the operating unit can be rotated in 90° steps.

CAUTION: During installation, the position of the control unit in relation to direct sunlight must be observed. It is recommended to protect the unit from direct sunlight (roof, installation position) to avoid possible malfunctions.




Figure 10

- Disconnect the actuator and control system from the power supply.
- To prevent damage to the electronic components, both the control system and the person have to be earthed!
- Unscrew the bolts for the interface surface and carefully remove the service cover.
- Turn service cover to new position and put back on.
 - Ensure correct position of the O-ring.

4 Installation instructions

- Turn service cover by max. of 180°.
 - Put service cover on carefully so that no cables get wedged in.
- Screw the bolts shut evenly in a crosswise sequence. **IMPORTANT:** max. torque 5 Nm

4.3 Electrical connection

WARNING: Electrical connections may only be carried out by qualified personnel. Please observe all relevant national security requirements, guidelines, and regulations.



Please check the steps below upon connecting the actuator.

- The equipment should be de-energized before working on electrical connections.
- Confirm the absence of electrostatic discharges during the connection.
- Connect the ground screw first.
- The line and short circuit protection must be done on the system side.
- The ability to unlock the actuator for maintenance purposes must be provided.
- For the dimensioning, the rated current is to be used (see Technical Data).
- Check whether the power supply (voltage, frequency) is consistent with the connection data (see type label – Figure 2, page 6)
- The connection of electrical wiring must follow the circuit diagram. This can be found in the appendix of the documentation. The circuit diagram can be ordered from SCHIEBEL by specifying the serial number.

NOTE: When using options, such as a Profibus connection, the relevant guidelines must be followed.

4.3.1 Power supply connection

ACTUSMART CM actuators feature an integrated motor controller, i.e. only a connection to the power supply is required. In **non explosion-proof actuators**, the wiring uses a connector independent from control signals (see Figure 11, page 13).




Figure 11: 1... Metric screw M32x1,5, 2... M40x1,5, 3... M25x1,5, 4... Plug insert Han6E (for power supply), 5... Plug insert Han24E (for control cables), 6... Connector for options, 7... Connector plate, 8... Connecting housing

The connection on **explosion-proof actuators** or, on special request also on non explosion-proof actuators) will be made via terminals (see Figure 12).




Figure 12: Terminal box: 1...Metric screw M40x1,5, 2...2 pcs. M20x1,5, 3...Terminals for the control signals, 4... Terminals for the power supply, 5... Terminal for ground connection, 6... Outside ground connection

CAUTION: If, during outdoor installation, commissioning is not carried out immediately after electrical connection, the power supply must be connected at a minimum to achieve a heating effect. In this case, the silica gel may remain in the connection compartment until commissioning. See section 3.3, page 10.



5 Commissioning

Before commissioning, ensure that the actuator is correctly assembled and electrically connected (see section 4, page 10).

NOTE: Remove silica gel from the connection compartment.

5.1 General

CAUTION: During commissioning and after every disassembly of the actuator, the electric end positions (see section 5.5, page 15) must be reset.



5.2 Manual operation

The use of a differential gearbox in the handwheel assembly makes mechanical switching unnecessary during manual operation.

CAUTION: Manual operation with mechanical or electromechanical equipment (such as: lever, drilling machine, etc.) is NOT ALLOWED, as this may damage the product.



5.3 Mechanical default settings, preparation

The use of multi-turn sensors makes mechanical settings unnecessary.

CAUTION: Before the motorised operation of the valve, it is essential to check and eventually adjust torque settings.



5.4 User Level and Permissions

In order to edit and/or show certain parameters, a user level with the necessary permissions has to be set as current user level. The current user level may be set temporarily in the "U User Level" menu item. It is also possible to set the default user level, which will be set as the current user level until set otherwise ("U User Level" or default user level). Please refer to section 7.6 for more information about the user levels.

5.5 End limit setting

A detailed description of the operation of the ACTUSMART CM controller can be found in section 6.3, page 20.

NOTE: Please make sure, that the current user level has the permission to edit the end limits.

5.5.1 End limit OPEN

Set the selector switch and control switch to the center position.




Figure 13: 1... Selector switch (red), 2... Control switch (black)

Scroll through the menu with the control switch. Move the control switch towards the first menu item \ominus "P 1.1 End limit – Open".




Figure 14




Figure 15

Afterwards, flip up the selector switch slightly and let it snap back to its neutral position \checkmark .




Figure 16




Figure 17




Figure 18

This changes the bottom line of the display from "EDIT?" to "SAVE?"




Figure 19




Figure 20

Then, push down the selector switch until it snaps into place. In doing so, the bottom right now on the display will show "TEACHIN" (⊗)

CAUTION: Once the display shows "TEACHIN", use the operating switch (black switch) to start the motorised operation of the actuator. In this mode, no travel-dependent switch off occurs in the end position.



CAUTION: Please note that, during motor operation, only torque monitoring remains active, as travel adjustment will happen subsequently. Therefore, please check beforehand whether the maximum torque has been already parameterised.



Absolute and relative values on the display will change continuously along with position changes.




Figure 21




Figure 22

Manually move the actuator with the handwheel (see section 2.1, page 6, or section 2.6, page 7) or by motor via the operating switch (black switch) to the end position OPEN of the valve.

- Absolute value: Absolute value of the position feedback
- Relative value: The value to the other end position




Figure 23: 1... Absolute value

When the desired end position OPEN of the valve is reached, move the selector switch back to the middle position. Thus, the line "TEACHIN" disappears.




Figure 24




Figure 25

In order to confirm the end position (save), slightly flip up the selector switch towards ☑ and let it snap back to its neutral position.




Figure 26



Figure 27




Figure 28

This changes the bottom line of the display for "SAVE?" to "EDIT?" and the end position is stored.




Figure 29




Figure 30

5.5.2 End limit CLOSE

Use menu item "P 1.2 End limit - End limit CLOSE" as for End limit OPEN

5.6 Final works

Following commissioning, check for proper sealing the covers to be closed and cable inlets (see section 2.4, page 7). Check actuator for paint damage (by transport or installation) and repair if necessary.

6 Control Unit

The controller is intended to monitor and control the actuator and provides the interface between the operator, the control system and the actuator.

6.1 Operating unit

Operation relies on two switches: the control switch and a padlock-protected selector switch. Information visualization is provided by 4 integrated indicator lights, as well as the graphic display. For better visibility, switch symbols (✓, ✗, ⊕, ⊖) are on the cover.




Figure 31: 1... Selector switch, 2... Control switch, 3... Graphic display, 4... LED display

The controller switches serve on the one hand for electric-motor operation of the actuator and, on the other hand, to configure and view various menu items.

The controller cover may be wiped clean with a damp cloth.

The mounting position of the control unit can be turned in 90° steps (see section 4.2, page 11).

6.2 Display elements

6.2.1 Graphic display

The graphic display used in the controller allows text display in different languages.




Figure 32

During operation, the displays shows the position of the actuator as a percentage, operation mode and status. When using the option "identification", a customer-specific label is shown at the bottom of the display (e.g., PPS Number).




Figure 33: 1... Status, 2... Operation mode, 3... Position

CAUTION: The display should not be exposed to direct sunlight over a long period - risk of a defect in combination with very high temperatures.



6.2.2 LED Display

To provide users with better status information, basic status data is displayed using 4-colour LEDs. As the device powers up, it undertakes a self-test whereby all 4 LEDs briefly lit up simultaneously.



Figure 34

Description	Colour	Lits up	Flashes quickly	Flashes slowly	Does not light up
L1	Yellow	No torque error	Torque fault	—	1)
L2	Yellow	Ready (operational readiness)	Travel fault (no operational readiness!)	Warning	Error (no operational readiness) motor temperature, supply voltage absent, internal error 1)
L3	Green ²⁾	CLOSE ³⁾	Moving to CLOSE position	Applies upon torque-dependent closing: Occurs when the end position CLOSE is reached but the cut-out torque has not yet been reached	Actuator is not in the CLOSE position.
L4	Red ²⁾	OPEN ³⁾	Moving to OPEN position	Applies upon torque-dependent opening: Occurs when the end position OPEN is reached but the cut-out torque has not yet been reached	Actuator is not in the OPEN position.
L5	Blue	Bluetooth connected	Bluetooth data transmission	Bluetooth ON, not connected	Bluetooth/Infrared OFF
	Red	Infrared connected	Infrared data transmission	Infrared ON, not connected	

6.3 Operation

The actuator is operated via the switches located on the controller (selection- and control switch). All actuator settings can be entered with these switches. Furthermore, configuration is also possible via the IR interface or the Bluetooth Interface (see section 9, page 63). Flip the switch up or down to regulate the parameter menu scrolling speed.




Figure 35: Neutral position




Figure 36: Slight switch flip (it will move to the next parameter)




Figure 37: halfway switch flip (it will jump to the next parameter category)



Figure 38: Full switch flip (it will jump to the end of the menu)

6.4 Welcome Menu

The welcome menu presents the user a welcome message, and guides the user through some basic settings. Some basic settings include the language and the timezone. Please follow the instructions shown on the display.

¹⁾ LED L1 and L2 are turned off as long as an infrared connection is active.
²⁾ Colour of LED L3 and L4 can be changed by parameter P1.7 - see section 7.1, page 26.
³⁾ A travel fault is indicated by a lit L3 and L4




Figure 39: Welcome menu (1/2)






Figure 40: Welcome menu (2/2)

6.4.1 Operation mode



Use the selector switch (red) to determine the various operating states of the actuator. In each of these positions, it is possible to block the switch by means of a padlock and thus protect the actuator against unauthorized access.

The selector switch has the following positions:

OFF	The actuator can be neither operated via the remote control nor via the control switches of the controller.
Local 	It is possible to operate the actuator by motor via the control switch. Control via the remote inputs may be possible with appropriate configuration (superimposed control commands, emergency commands)
Remote 	The actuator is ready to process control commands via input signals. The control switch for the motor operation of the actuator is not enabled.

Besides defining the operational status, the selector switch is used in configuration mode to confirm or cancel parameter inputs.

Depending on the selector switch position, the control switch performs different functions:

Selector switch in the OFF position:	The control switch is used to scroll up or down the menu according to internal symbolism. From the neutral position towards \oplus you reach the status and history data areas. Towards the \ominus symbols you reach the parameter menu. Here, the selection switch either confirms \checkmark or rejects \otimes the current input according to associated symbolism.
Selector switch in the REMOTE position  :	The control switch gives you access to status, history data and parameter area.
Selector switch in the LOCAL position  :	With the control switch, the actuator can be operated by motor. You may also operate the actuator in inching and self-hold mode. Switches are spring-loaded to snap back automatically into their neutral position. (To confirm a control command, the control switch must be pushed all the way into its mechanical locking position.)

6.4.2 Configuration

NOTE: Please make sure, that the set user level has permission to read/write the parameters.

In principle, all parameters are shown as numbers in the corresponding parameter point. From the actuator menu, use the control switch to access different menu points. The lower left corner of the display shows the "EDIT" option.




Figure 41

Confirm the selector switch (with a slight flip towards \checkmark , (see Figure 26, page 17 to Figure 28, page 17) to change the selected parameter. To confirm this input readiness, the display changes from "EDIT" to "SAVE".




Figure 42

Use the control switch towards to the characters to change the parameter. ⊕ or ⊖ (see Figure 35 til Figure 38, page 20) After reaching the desired parameter value, confirm the value with the selector switch (again, flip it slightly towards ✓, (see Figure 26, page 17 til Figure 28, page 17).

6.4.3 Configuration example

By way of example, we will change parameter P20.6 (wireless) from 0 (wireless off) to 2 (Bluetooth communication on). Thus, the Bluetooth connection is activated for a short time and then deactivated again automatically:

The operating and control switch must be in the neutral position



Figure 43: 1... Selector switch (red) , 2... Control switch (black)

Now, move the control switch down (towards) until the menu item "P 20.6 Miscellaneous - Wireless" is displayed.



Figure 44




Figure 45

Afterwards, flip up slightly the selector switch (towards) and let it snap back to its neutral position




Figure 46




Figure 47




Figure 48

This changes the bottom line of the display from "EDIT?" to "SAVE?"




Figure 49




Figure 50

Thereafter, flip up the control switch (toward) to change the value from 0 (off) to 2 (Bluetooth)



Figure 51




Figure 52

If the value changes to 1, confirm the selection by flipping halfway up the selector switch (towards) and letting it snap back to its neutral position (see Figure 46 til Figure 48).




Figure 53




Figure 54

This changes the bottom line of the display from "SAVE?" to "EDIT?" and the parameter is stored.

6.4.4 „TEACHIN“

Furthermore, certain parameters (end positions, intermediate positions).can be set using "TEACHIN". Thus, their configuration is greatly simplified.

After selecting the appropriate menu item (for example: End position) and changing the the input type from "EDIT?" to "SAVE?", move the selector switch (red) to "manual mode" and lock it into place. As you do so, the display will show the message "TEACHIN" and the current position value will be applied continuously to the parameter value. In this mode, further to manual operation by hand wheel, the actuator can be motor-driven with the control switch to the desired position. (see section 22, Figure 22, page 16)



Figure 55

CAUTION: Please note that, during motor operation, only torque monitoring remains active, as travel adjustment will happen subsequently. Therefore, please check beforehand whether the maximum torque has been already set.



After reaching the desired, to-be-defined position, move the selector switch back to the neutral position. Finally, the parameter value must still be saved by flipping the selector switch halfway up and letting it snap back to the neutral position (see Figure 46 til Figure 48, page 24).

7 Parameter menu

For each parameter group, you can find a description, tabular overview of the menu items and possible configurations. The parameter list below also includes all possible options per menu item. Please note that some of the menu items listed and described may not be delivered with your configuration.

7.1 Parameter group: End limit

These parameters are used to configure the end position and switch off behavior of the actuator. In this regards, it is important to ensure that the basic mechanical configuration described in section 5.5, page 15 has already been made.

CAUTION: Ensure, that these parameters are set during commissioning before operating the actuator. In addition, the settings in the "Torque" menu (see section 7.2, page 27 must be compared with the permissible values of the valve and corrected as appropriate). Failing to oblige may damage the driven equipment.



NOTE: Generally, 100% stands for fully open and 0% for fully closed. Please note that these values cannot be changed. The end position range is reached as soon as 0% or 100% is shown on display.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P1.1	End limit	Open	TEACHIN; 0...100 U ²⁾	The parameter value can be set using TEACHIN. With a known travel, the second end position can be entered after setting the first end position.
P1.2	End limit	Close	TEACHIN; 0...100 U ²⁾	The parameter value can be set using TEACHIN. With a known travel, the second end position can be entered after setting the first end position.
P1.3	End limit	Switch off Open	0: By travel	The actuator uses end-position signals to switch off and report the end position. Attention: For failsafe-actuators in failsafe-direction not applicable. End limit by travel in failsafe-position only possible by changing the mechanical connection to the valve.
			1: By torque	The actuator signals the end position or stops the motor only after reaching the specified torque in the end position. If the torque is reached and end position signal not, the actuator reports an error. If the end position is reached and the control command drops off during the build-up of the torque, the motor stops and the required torque is not reached. Attention: For failsafe-actuators in failsafe-direction not applicable. Torque/Force in failsafe-position depends on residual spring torque/force
			2: By torque1	Like „torque“, but in the end position range, the actuator keeps moving against the end position, even when the control command drops off, whilst switch-off torque is not reached, until the required torque is reached, or a control command against the current direction is registered. Attention: For failsafe-actuators in failsafe-direction not applicable. Torque/Force in failsafe-position depends on residual spring torque/force
			3: By torque2	Like „torque1“, but in the end position range automatically an additional control command is generated to reach and hold the torque. If the torque decrease and the actuator is in the end position it will be restored automatically. e.g.: Changes due to temperature differences, settlement. Attention: For failsafe-actuators in failsafe-direction not applicable. Torque/Force in failsafe-position depends on residual spring torque/force

continued on next page

²⁾representative for CM03; U...number of revolutions

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / Comments
			4: By travel1	Like „travel“, however, the actuator still continues to drive the set Overrun time after reaching the end position, even when the positioning command is released. Only relevant if Overrun time (P1.10, P1.11) is greater than 0. Attention: For failsafe-actuators in failsafe-direction not applicable.
P1.4	End limit	Switch-off Close	1: travel	see P1.3
			1: By torque	see P1.3
			2: By torque1	see P1.3
			3: By torque2	see P1.3
			4: By travel1	see P1.3
P1.5	End limit	Closing direction	CW (0)	Actuator is designed for clockwise = closing.
			CCW (1)	Reverse direction of rotation! Counterclockwise = closing. The crossing of all signals and commands is performed by the controller.
P1.6	End limit	Rot. sense pos.	0	Rotation sense of the Potentiometer. No function in ACTUSMART CM series.
			1	
P1.7	End limit	LED function	Close = green (0)	Definition of the LED colour of the CLOSED or OPEN end position signalization.
			Close = red (1)	
			Close = green, yellow inv. (2)	Definition of the LED colour of the CLOSED or OPEN end position signalization. Yellow LEDs (1 and 2) are inverted.
			Close = red, yellow inv. (3)	
P1.8	End limit	End limit hyst.	0.1... 10.0%	Hysteresis range for end position signals: Example: End position hysteresis 1% means that the End position OFF is reached when closing 0%, and will be left when opening only at 1%, i.e., a re-closing can only take place after leaving this hysteresis.
P1.9	End limit	Ramp	0.1... 100%	When approaching the end position, the speed is reduced.
P1.11	End limit	Overrun Open	0... 60 s	Switch-off delay after reaching the end position see travel1 (P1.3, P1.4)
P1.12	End limit	Overrun Close	0... 60 s	Switch-off delay after reaching the end position travel1 (P1.3, P1.4)

CAUTION: When installing the actuator on a gear or a thrust unit, please take into account the limits and factors of the gear / thrust unit at parametrization.



NOTE: When using end-limit switch-off by torque, the end position limit must be set before reaching the torque limit. Accordingly, the actuator will only signal the final end position if the configured torque and the associated end position are reached. If the end position is not reached, a torque error is reported (see section 6.2.2, page 19).

7.2 Parameter group: Torque

If no torque was specified with the order, the actuator is supplied from the factory with the maximum configurable torque.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P2.1	Torque	Open	8... 32 Nm ³⁾	Switch-off torque in OPEN direction NOTE: The range can be restricted via menu item P2.3.
P2.2	Torque	Close	8... 32 Nm ³⁾	As P2.1, but in CLOSED direction.

NOTE: When installing the actuator on an additional gear, please take into account the corresponding values of the gear / thrust unit as you enter the actuator parameters. To achieve an effective output torque (incl. gear) / output power (including thrust unit) ratio, the factor gear/thrust unit must be considered.

³⁾representative for CM03

7.3 Parameter group: Speed

	Menu item	Sub-menu item	poss. setting	Notes / comments
P4.1	Speed	Local Open	1.0 ... 72.2 rpm ⁴⁾	Output speed for local operation in direction OPEN.
P4.2	Speed	Local Close	1.0 ... 72.2 rpm ⁴⁾	As P4.1, but in direction CLOSE.
P4.3	Speed	Remote Open	1.0 ... 72.2 rpm ⁴⁾	Output speed for remote operation in direction OPEN.
P4.4	Speed	Remote Close	1.0 ... 72.2 rpm ⁴⁾	As P4.3, but in direction CLOSE.
P4.5	Speed	Emergency Open	1.0 ... 72.2 rpm ⁴⁾	Output speed for emergency operation in direction OPEN.
P4.6	Speed	Emergency Close	1.0 ... 72.2 rpm ⁴⁾	As P4.5, but in direction CLOSE.
P4.7	Speed	Torque-dependent	1.0 ... 72.2 rpm ⁴⁾	Seal-tight speed. Speed at which the actuator runs near the end position at torque-dependent switch-off (see P1.3 and P1.4).
P4.8	Speed	Minimum	1.0 ... 72.2 rpm ⁴⁾	Minimum speed.

NOTE: The max. speed for the 24 VDC actuator version is reduced to 20 rpm.

7.4 Parameter group: Ramp (optional)

The start ramp can be set separately for each operation mode. Thus, a 100% start ramp means, that the motor attains its maximum speed in about a second. Higher speeds (see section 7.3) lead to shorter runtimes. If the ramp is set below 100%, the starting time increases in an inversely proportional fashion.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P5.1	Ramp	Local	1 ... 100%	Start ramp for local operation
P5.2	Ramp	Remote	1 ... 100%	Start ramp for remote operation
P5.3	Ramp	Emergency	1 ... 100%	Start ramp for emergency operation

7.5 Parameter group: Control

	Menu item	Sub-menu item	poss. setting	Notes / comments
P6.2	Control	Ready delay	0 ... 10 sec	Drop-out delay for the ready signal (bin. outputs)
P6.5	Control	24 V output	0	24 V auxiliary output is deactivated (section 21.5, page 76). The function of the auxiliary input is still activated.
			1	24 V auxiliary output is activated (section 21.5, page 76).
P6.6	Control	Min. impuls	0.1 ... 2.0 sec	Minimum switch-on time of the motor.
P6.17	Control	Remote Display	0: off	The remote display is deactivated.
			1: Menu	Access to parameter menu is possible on the remote display. Motor control is deactivated on the remote display, i.e., LOCAL and REMOTE operating modes are handled by the main display.
			2: Menu/Control	Access to parameter menu and motor control is possible on the remote display and the main display. In case of a communication loss with the remote display, the actuator will be in operating mode OFF.
			2: Menu/Control (Fallback)	Access to parameter menu and motor control is possible on the remote display and the main display. In case of communication loss with the remote display, the actuator will fall back to the set operating mode on the main display.

⁴⁾representative for CM03

7.6 Parameter group: User Level

From the Display firmware version 1600 and upward, the parameter group no. 7 allows to set the default user levels accessed locally or via bus.

The user levels allow access restrictions to certain parameters. Depending on the user level read/write setting per parameter, the menu items can only be seen or edited, if the current user level is equal or higher than the required user level. Parameters are assigned default user levels. These may be changed with the SmartTool2, if the set user level in the SmartTool2 is equal or higher than the current user level-setting of the parameter (-group).




Figure 56: Actuator parameters on the SmartTool2; Parameter user level can be set by clicking the button as marked above

The following table shows the default passwords for the user levels:

User Level	Password Local	Password Wireless
1	LLVL1	WLVL1
2	LLVL2	WLVL2
3	LLVL3	WLVL3
4	LLVL4	WLVL4

The default passwords can be changed with the SmartTool2 (Adjust Wizard - Access tab, see figure 57) or directly on the actuator control unit ("P7.3 - Change Password").

NOTE: Editing the parameter "P7.4 - Change Password" will change the password for the current user level.




Figure 57: SmartTool2 Adjust Wizard - Access Tab

7 Parameter menu

	Menu item	Sub-menu item	poss. setting	Notes / comments
P7.1	User Level	Local	0...6	Sets the default user level on the ACTUSMART control unit. The set user level will revert back to this user level, if the user level was changed with menu item "U - User level" after 3 minutes of inactivity or upon restarting the actuator. Password will be prompted, if the set user level is higher than the currently active user level.
P7.2	User Level	Bus	0...6	Sets the user level on access via Bus.
P7.3	User Level	Remote Display	0...6	Sets the user level on the remote display.
P7.4	User Level	Change Password	6-digit	Changes the password of the current active user level.

NOTE: The parameters have preset user level settings. The table in section 7.20 on page 57 shows an overview of the default user level settings for all parameters.

7.7 Parameter group: Position

In addition to OPEN and CLOSED end positions, you may define intermediate positions. These can be used as feedback signals for the binary outputs or as target value for fix position approach.

NOTE: If you change the end positions (see section 7.1, page 26), intermediate positions are retained percentage-wise, i.e., the absolute positions of the intermediate positions change.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P8.1	Position	Intermed.pos.1	TEACHIN 0...100%	Position value of intermediate position 1
P8.2	Position	Intermed.pos.2	TEACHIN 0...100%	see above
P8.3	Position	Intermed.pos.3	TEACHIN 0...100%	see above
P8.4	Position	Intermed.pos.4	TEACHIN 0...100%	see above
P8.5	Position	Emerg.position	TEACHIN 0...100%	Position value of the emergency position.
P8.6	Position	Hysteresis	0.1...10.0%	Hysteresis range of intermediate positions. Within this hysteresis, no repositioning occurs upon reaching the intermediate positions (option: fix position approach). Furthermore, the output functions for position = intermediate position are active within this range (see P10.1).
P8.7	Position	Intermed.pos.5	TEACHIN 0...100%	see above
P8.8	Position	Intermed.pos.6	TEACHIN 0...100%	see above
P8.9	Position	Intermed.pos.7	TEACHIN 0...100%	see above
P8.10	Position	Intermed.pos.8	TEACHIN 0...100%	see above
P8.11	Position	Dead Band	0...10%	Tolerance range for the position deviation (intermediate position - actual position), where no adjustment occurs. The deadband should not be set too low, to prevent actuator oscillation.
P8.12	Position	Gain	0...100%	The gain (gradient) affects the positioning to the target intermediate position. The smaller the gain selected (e.g. 20%), the earlier the actuator starts reducing its speed in case of speed variable actuators on approaching the target position. This leads to better positioning (smaller reachable deadband). A 100% setting disables this gradient.
P8.13	Position	Hysteresis	0...100%	This hysteresis value applies to the set value in "P8.11 - Dead Band".
P8.14	Position	Intermed.pos.9	TEACHIN 0...100%	see above
P8.15	Position	Intermed.pos.10	TEACHIN 0...100%	see above
P8.16	Position	Intermed.pos.11	TEACHIN 0...100%	see above
P8.17	Position	Intermed.pos.12	TEACHIN 0...100%	see above
P8.18	Position	Intermed.pos.13	TEACHIN 0...100%	see above
P8.19	Position	Intermed.pos.14	TEACHIN 0...100%	see above

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P8.20	Position	Intermed.pos.15	TEACHIN 0...100%	see above
P8.21	Position	Intermed.pos.16	TEACHIN 0...100%	see above




Figure 58: Function principle of the dead band and hysteresis in conjunction with intermediate positions

The figure above shows the working principle of the parameters "P8.11 - Dead Band" and "P8.13 - Hysteresis". The set dead band thresholds are added and subtracted from the intermediate positions. The hysteresis sets the threshold on the deadband thresholds. E.g. if the intermediate position is 50%, dead band is 1% and hysteresis is 50%, the dead band thresholds will be at 49% and 51%. On top of that, the hysteresis for the 49% threshold will be at 50% of the dead band value, which is $\pm 0.5\%$; thus the hysteresis on the 49% dead band threshold is at 48.5% and 49.5%. The actuator will move toward 50%, if the actual position is below 48.5% and stop, if the actual position is between 49.5% and the "outer" hysteresis mirrored on the ordinate, which is 51.5% in this case.

NOTE: Please be aware, that a 100% setting for hysteresis will cause oscillation due to overlapping thresholds.

7.8 Parameter group: Binary inputs

The controller is equipped with 5 freely configurable binary inputs. Please find further information on technical data of the binary inputs in section 21.2, page 73. Binary inputs are also effective during actuator control via Profibus (option).

Default binary inputs are as follows:

- | | |
|---------------------------|-------------------------|
| Input 1: OPEN | Input 2: CLOSED |
| Input 3: STOP | Input 4: EMERGENCY OPEN |
| Input 5: EMERGENCY Closed | |

	Menu item	Sub-menu item	poss. setting	Notes / comments
P9.1	Bin. Input	Input 1	-1: Not activated	This input is not active, i.e., it is not shown in the status "S2 - Bin. Inputs.
			0: No Function	This input has no function.
			1: Open	OPEN command in REMOTE mode (selector switch in position REMOTE).
			2: Close	CLOSE command in REMOTE mode (selector switch in position REMOTE).
			3: Stop	STOP command in REMOTE mode (selector switch in position REMOTE).
			4: Open Lock	Self-hold for OPEN, i.e., a short pulse is sufficient and the actuator moves then into the end position. Use the STOP command to stop the actuator.
			5: Close Lock	Self-hold for CLOSE, see OPEN SELF-HOLD

continued on next page

continued from previous page

Menu item	Sub-menu item	poss. setting	Notes / comments
		6: Emergency Open	Superimposed run command; run the actuator in direction OPEN regardless of whether the selection switch is set to REMOTE or LOCAL operation
		7: Emergency Close	Superimposed run command; run the actuator in direction CLOSE regardless of whether the selection switch is set to REMOTE or LOCAL
		8: Deblock	The actuator may be operated only with a switched signal. Both in local and remote operation
		9: Open/Close	The actuator moves towards OPEN if input is active and towards CLOSED otherwise
		10: Close/Open	The actuator moves towards CLOSED if input is active and towards OPEN otherwise
		11: Positioner On	Release of the positioner
		12: Open inv.	As OPEN but active low
		13: Close inv.	As CLOSE but active low
		14: Stop inv.	As STOP but active low
		15: Open Lock inv.	As Open Self-Hold but active low
		16: Close Lock inv.	As Closed Self-Hold. but active low
		17: Emergency-Open inv.	As Emergency-Open but active low
		18: Emergency-Close inv.	As Emergency-Close but active low
		19: Block	with activated (switched) signal, the actuator is locked for operation also in local mode
		20: Positioner off	Positioner lock
		21: Deblock Local	The actuator may be operated only with a switched signal.
		22: Block Local	as Release Local but active low
		23: Emerg. Open Lock	Trigger lock OPEN (in LOCAL and REMOTE mode). Actuator moves with the highest priority to OPEN; command continues internally active after reaching the end position OPEN. Dropping only with LOCK OFF, Supply OFF or operating mode OFF.
		24: Emerg. Close Lock	Trigger lock CLOSE (in LOCAL and REMOTE mode). Actuator moves with the highest priority to CLOSED; command continues internally active after reaching the end position CLOSED. Dropping only with LOCK OFF, Supply OFF or operating mode OFF.
		25: Emerg. Unlock	Drop the lock
		26: Failsafe	Trigger the failsafe function in all operating modes (only functional in Failsafe actuators).
		27: Failsafe inv.	As Failsafe, but active low
		28: Emerg. Open Lock inv.	As Emerg. Open Lock, but active low
		29: Emerg. Close Lock inv.	As Emerg. Close Lock, but active low
		30: Emerg. Unlock inv.	As Emerg. Unlock, but active low
		31: Intermediate position1	Approach intermediate position 1 (P8.1) in REMOTE mode (fix position approach). There is no repositioning upon reaching the intermediate position within the hysteresis (see P8.6). Higher priority than intermediate position 2, 3 and 4
		32: Intermediate position2	As intermediate position 1, but with higher priority than intermediate positions 3 and 4

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			33: Intermediate position3	As intermediate position 1, but with higher priority than intermediate position 4
			34: Intermediate position4	As intermediate position 1, but with lowest priority.
			35: Emergency position	Approach emergency position (P 8.5). As intermediate position 1, but with higher priority than intermediate positions 1, 2
			36: Intermediate position1 inv.	As Intermediate position 1, but active low
			37: Intermediate position2 inv.	As Intermediate position 2, but active low
			38: Intermediate position3 inv.	As Intermediate position 3, but active low
			39: Intermediate position4 inv.	As Intermediate position 4, but active low
			40: Emergency position inv.	As Emergency position, but active low
			41: Travel Open	reserved for future use
			42: Travel Close	reserved for future use
			43: Travel Open inv.	reserved for future use
			44: Travel Close inv.	reserved for future use
			45: Failsafe lock	reserved for future use (only for Failsafe actuators)
			46: Failsafe lock inv.	reserved for future use (only for Failsafe actuators)
			47: Intermed.pos.Bit0	Intermed.pos.Bit0 to Intermed.pos.Bit3 allow to signal intermediate positions 1 to 16 through a bit pattern (binary to decimal; decimal value + 1 corresponds to the Int.pos.). Bit3 is the MSB. E.g. to move to Int.pos.1, all Bits should be 0; to move to Int.pos.3, Bit 1 should be 1.
			48: Intermed.pos.Bit1	see 47: Intermed.pos.Bit0
			49: Intermed.pos.Bit2	see 47: Intermed.pos.Bit0
			50: Intermed.pos.Bit0 inv.	As 47: Intermed.pos.Bit0 but active low
			51: Intermed.pos.Bit1 inv.	see 50: Intermed.pos.Bit0 inv.
			52: Intermed.pos.Bit2 inv.	see 50: Intermed.pos.Bit0 inv.
			53: PVST Start	Start PVST (optional, see PVST section)
			54: PVST Start inv.	As 53: PVST Start, but active low.
			55: Intermed.pos.Bit3	see 47: Intermed.pos.Bit0
			56: Intermed.pos.Bit3 inv.	see 50: Intermed.pos.Bit0 inv.
P9.2	Bin. Input	Input 2	see Input 1	
P9.3	Bin. Input	Input 3	see Input 1	
P9.4	Bin. Input	Input 4	see Input 1	
P9.5	Bin. Input	Input 5	see Input 1	

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P9.9	Bin. Input	Input Channel 1	see Input 1	Function (see Input 1) for virtual input channel 1. See section 7.8.1 for more information about the virtual inputs.
P9.10	Bin. Input	Input Channel 2	see Input 1	See Input Channel 1.
P9.11	Bin. Input	AND Mask 1	-32768...+32767	See section 7.8.1 for the usage of virtual inputs.
P9.12	Bin. Input	AND Mask 2	-32768...+32767	
P9.13	Bin. Input	AND Mask 3	-32768...+32767	
P9.14	Bin. Input	AND Mask 4	-32768...+32767	
P9.15	Bin. Input	AND Mask 5	-32768...+32767	
P9.16	Bin. Input	AND Mask 6	-32768...+32767	
P9.17	Bin. Input	AND Mask 7	-32768...+32767	
P9.18	Bin. Input	AND Mask 8	-32768...+32767	
P9.19	Bin. Input	OR Mask 1	-32768...+32767	
P9.20	Bin. Input	OR Mask 2	-32768...+32767	

NOTE: For optional functions such as a relay board please refer to the corresponding IOM.

7.8.1 Optional: Virtual Input

Upon order or by unlocking via Smartcode, the virtual input functionality may be activated, to extend and/or to define a logic switching through the input signal states. This behaviour is achieved by using logic AND and OR gates.

Each AND gate is connected with all binary inputs twice, once directly and once through an inverted input. The physical binary inputs are assigned a bit of a bit field, i.e., input 1 is assigned to bit 0, input 2 is assigned to bit 1, inverted input 1 is assigned to bit 8, inverted input 2 is assigned to bit 9 and so forth (see figure 59 for a visual representation). By entering the sum of all requested bits as a decimal value for an AND Mask, the AND gate will deliver a TRUE output value, if the input signals are correct.

An AND gate will deliver a TRUE output value, if all input values are TRUE (consider inverted inputs). If a binary input is not defined, it is deemed as don't care.

The OR gates are connected to all AND gate outputs. The same bit-wise assignation as for the binary inputs applies for the designation of the AND gate outputs, i.e., AND mask 1 is bit 0, AND mask 2 is bit 1 and so forth (see figure 59 for a visual representation). By entering the sum of all requested bits as a decimal value for an OR Mask, the OR gate will deliver a TRUE output value, if the input signals are correct.

An OR gate will deliver a TRUE output value, if at least one of the input values is true (consider inverted inputs). If an AND gate is not defined, it is deemed as don't care.

The following table shows the binary input assignments in binary and their decimal value.

NOTE: There are two separate bit fields; one for the binary inputs and the other one for the AND mask outputs.

Input source	Bit location	Decimal Value
Bin. Input 1	0000 0000 0000 0001	1
Bin. Input 2	0000 0000 0000 0010	2
Bin. Input 3	0000 0000 0000 0100	4
Bin. Input 4	0000 0000 0000 1000	8
Bin. Input 5	0000 0000 0001 0000	16
Inv. bin. Input 1	0000 0001 0000 0000	256
Inv. bin. Input 2	0000 0010 0000 0000	512
Inv. bin. Input 3	0000 0100 0000 0000	1024
Inv. bin. Input 4	0000 1000 0000 0000	2048
Inv. bin. Input 5	0001 0000 0000 0000	4096
AND Mask 1 out	0000 0001	1
AND Mask 2 out	0000 0010	2
AND Mask 3 out	0000 0100	4
AND Mask 4 out	0000 1000	8
AND Mask 5 out	0001 0000	16
AND Mask 6 out	0010 0000	32
AND Mask 7 out	0100 0000	64
AND Mask 8 out	1000 0000	128




Figure 59: An example of the configuration of the AND and OR masks on the SmartTool2 parameterization software.

The example above shows, that the AND gate 0, which is AND mask 1, requires a FALSE signal on bin. input 1, a TRUE signal on bin. input 2 and a TRUE signal on bin. input 4. Summing up the decimal value of these nodes equals the value, which has to be set in P9.11 - AND Mask 1 ($\text{NOT}(\text{BinIn1}) + \text{BinIn2} + \text{BinIn4}$ corresponds to $256 + 2 + 8 = 266$). The AND gate will output TRUE, only if the BinIn1 signal is FALSE, BinIn2 is TRUE and BinIn4 is TRUE, otherwise it stays FALSE.

The same principle applies to the OR gate 0, which is OR Mask 1. The OR gate needs at least a TRUE signal from AND gate 0 or from AND gate 2. Summing up the decimal value of these nodes equals the value, which has to be set in P9.19 - OR Mask 1 (And0 + And2 corresponds to 1 + 4 = 5). The OR gate will output TRUE, if at least one of the two AND gates output a TRUE value.

7.9 Parameter group: Binary outputs

The controller is equipped with 8 freely configurable binary outputs. Please find further information on technical data of the binary outputs in section 21.1, page 73. Provided with external supply, binary outputs are optically isolated from the rest of the controller.

Default binary outputs are as follows:

- | | |
|-------------------------------|-----------------------------|
| Output 1: Ready | Output 2: End position OPEN |
| Output 3: End position CLOSED | Output 4: Run OPEN |
| Output 5: Run CLOSED | Output 6: Torque |
| Output 7: LOCAL | Output 8: REMOTE |

	Menu item	Sub-menu item	poss. setting	Notes / comments
P10.1	Bin. Output	Output 1	0: No Function	The output has no function.
			1: Ready	Actuator is ready
			2: Fault	General fault; actuator is not ready
			3: Open	Actuator is in open position
			4: Closed	Actuator is in closed position
			5: Running Open	Actuators runs in direction Open
			6: Running Closed	Actuators runs in direction Closed
			7: Running	Actuator is running in either Open or Closed direction
			8: Torque Open	Switch-off torque was reached in Open direction, actuator has been switched off
			9: Torque Closed	Switch-off torque was reached in Closed direction, actuator has been switched off
			10: Torque	Switch-off torque was reached in either Closed or Open direction
			11: Travel Open	The Open end position has been reached
			12: Travel Closed	The Closed end position has been reached
			13: Pos. > Int.1	Position > Intermediate position 1
			14: Pos. < Int.1	Position < Intermediate position 1
			15: Pos. > Int.2	Position > Intermediate position 2
			16: Pos. < Int.2	Position < Intermediate position 2
			17: Pos. > Int.3	Position > Intermediate position 3
			18: Pos. < Int.3	Position < Intermediate position 3
			19: Pos. > Int.4	Position > Intermediate position 4
			20: Pos. < Int.4	Position < Intermediate position 4
			21: Local	Local operating mode (selector switch in position Local)
			22: Remote	Remote operating mode (selector switch in position Remote)
			23: Off	Off operating mode (selector switch in the Off position)
			24: Mot.temp.Warning	The motor temperature is above the warning threshold.
			25: Mot.temp.Switchoff	The motor temperature is above the motor switchoff threshold.
			26: Always	Signal is always on
			27: Never	Signal is always off
			28: Bin. Input 1	Forwarding of binary input to output
			29: Bin. Input 2	Forwarding of binary input to output
			30: Bin. Input 3	Forwarding of binary input to output
			31: Bin. Input 4	Forwarding of binary input to output
32: Bin. Input 5	Forwarding of binary input to output			

continued on next page

continued from previous page

Menu item	Sub-menu item	poss. setting	Notes / comments
		33: Torque Open Masked	As Torque OPEN, but it will suppress (mask) this signal in the end position upon torque-dependent switch-off.
		34: Torque Closed Masked	As Torque CLOSED, but it will suppress (mask) this signal in the end position upon torque-dependent switch-off.
		35: Ready Remote	Ready and Remote operating mode
		36: Ready Local	Ready and Local operating mode
		37: Ready Local/remote	Ready and Local or Remote mode
		38: Emerg. Open Locked	Lock OPEN is enabled. OPEN command is internally queued with the highest priority and will not be dropped even in the end position.
		39: Emerg. Closed Locked	Lock CLOSED is enabled. CLOSED command is internally queued with the highest priority and will not be dropped even in the end position.
		40: Failsafe OK1	Failsafe OK (only for Failsafe actuators)
		41: Failsafe OK2	Failsafe OK and Ready (only for Failsafe actuators)
		42: Failsafe OK3	Failsafe OK, Ready and Remote (only for Failsafe actuators)
		43: Emerg. Locked	Lock Open or Lock Closed is enabled.
		44: Ready/TorqueOK	Actuator is ready and no torque switch-off
		45: Ready / Remote / TorqueOK	Actuator is ready for operation in REMOTE mode and no torque switch-off
		46: Pos.=Int1	Position = Intermediate position 1. The width of the interval is set with the parameter P8.6.
		47: Pos.=Int2	Position = Intermediate position 2. The width of the interval is set in parameter P8.6.
		48: Pos.=Int3	Position = Intermediate position 3. The width of the interval is set in parameter P8.6.
		49: Pos.=Int4	Position = Intermediate position 4. The width of the interval is set in parameter P8.6.
		50: Pos.=EmergPos	Position = emergency position. The width of the interval is set in parameter P8.6.
		51: Bus Bit 1	In existing bus interface (hardware option), the output is set according to the selected bit bus.
		52: Bus Bit 2	
		53: Bus Bit 3	
		54: Bus Bit 4	
		55: Bus Bit 5	
		56: Bus Bit 6	
		57: Bus Bit 7	
		58: Bus Bit 8	
		59: Virtual 1	Configurable output function
		60: Virtual 2	
		61: Virtual 3	
		62: Virtual 4	
		63: Control OK	The SMARTCON control is operational.
		64: Control voltage OK	The auxiliary voltage for the SMARTCON control is OK. This function is only available if the auxiliary voltage output is not switched on (P6.5 to 0).
		65: PVST OK	The PVST was successful.
		66: PVST Failure	The PVST was not successful(see chapter ??).
		67: PVST Active	A PVST was triggered. The actuator is running a PVST.
		68: Emerg. OPEN	Emergency OPEN command is active. The signal remains active, as long as the emergency command is active, even if the end limit is reached.

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			69: Emerg. CLOSE	Emergency CLOSE command is active. The signal remains active, as long as the emergency command is active, even if the end limit is reached.
			70: Analog In. 1 Fault	There is no or a faulty signal on the analog input 1.
			71: Analog In. 2 Fault	There is no or a faulty signal on the analog input 2.
			72: Phase Sequence Fault	Cause on basis: Active phase sequence detection on single phase actuators, loss of main power while connected to external 24VDC auxiliary voltage, or loss of phase 2.
			73: Power Supply Fault	No power supply to the power electronics (when the controller is powered from the auxiliary power input). Defect of power electronics.
			74: Inverter Fault	The inverter is defective or the wiring is faulty (Only for CM.V1.2 actuator series).
			75: Manual Override	Manual override is active (For FailSafe-Actuators); see the FailSafe-section for more information about the manual override.
			76: Travel Sensor Fault	The travel measurement is out of range or the wiring is defective for AB CSC.V1.2 actuators. The travel sensor is not calibrated for CM actuators.
			77: Torque Sensor Fault	Potentiometer fault on Basis, or cable is broken.
			78: Bus Fault	No communication with the optional bus.
			79: Bus Watchdog	Watchdog for bus communication has reacted.
			80: Undervoltage Warning	The input voltage is below the regular voltage range, but motor operation is still possible.
			81: Battery Low	Battery on display board is empty, loss of time/date or counter values possible.
			83: Undervoltage Fault	The input voltage is too low, The motor is switched off, until the input voltage is in the regular voltage range.
			84: Undervoltage Switchoff	The input voltage dropped below the lower threshold multiple times. The motor is turned off for 5 minutes. This error can be acknowledged by switching the selector switch to OFF or by turning the actuator off and on.
			85: Overvoltage Warning	The input voltage is over the regular voltage range, but motor operation is still possible.
			86: Internal Fault	Internal communication error between electrical components, i.e. Internal Comm.E error, or Internal Comm.L error or Internal Comm.D error.
			87: Torque Masked	Is set, if 33: Torque Open Mask or 34: Torque Close Mask is set.
P10.2	Bin. Output	Output conf. 1	0: normal	Output 1 is set to normal, i.e. if the condition in point P10.1 is met, Output 1 is set to HIGH (active HIGH).
			1: inverted	If the condition in point P10.1 is met, Output 1 is set to LOW (active LOW).
			2: norm. flashing	If the condition in point P10.1 is met, Output 1 starts blinking (active HIGH).
			3: inv. flashing	If the condition in point P10.1 is not met, Output 1 starts blinking (otherwise it is set to HIGH).
P10.3	Bin. Output	Output 2	see Output 1	
P10.4	Bin. Output	Output 2 Konf.	see Output 1 conf.	
P10.5	Bin. Output	Output 3	see Output 1	
P10.6	Bin. Output	Output 3 Konf.	see Output 1 conf.	
P10.7	Bin. Output	Output 4	see Output 1	
P10.8	Bin. Output	Output 4 Konf.	see Output 1 conf.	

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P10.9	Bin. Output	Output 5	see Output 1	
P10.10	Bin. Output	Output 5 Konf.	see Output 1 conf.	
P10.11	Bin. Output	Output 6	see Output 1	
P10.12	Bin. Output	Output 6 Konf.	see Output 1 conf.	
P10.13	Bin. Output	Output 7	see Output 1	
P10.14	Bin. Output	Output 7 Konf.	see Output 1 conf.	
P10.15	Bin. Output	Output 8	see Output 1	
P10.16	Bin. Output	Output 8 Konf.	see Output 1 conf.	
P10.29	Bin. Output	Virtual 1	see Output 1	Function (see Output 1) for virtual output 1. See section 7.9.1 for more information about the virtual inputs.
P10.30	Bin. Output	Virtual 2	see Output 1	see Virtual 1
P10.31	Bin. Output	Virtual 3	see Output 1	see Virtual 1
P10.32	Bin. Output	Virtual 4	see Output 1	see Virtual 1
P10.33	Bin. Output	Virtual 5	see Output 1	see Virtual 1
P10.34	Bin. Output	Virtual 6	see Output 1	see Virtual 1
P10.35	Bin. Output	Virtual 7	see Output 1	see Virtual 1
P10.36	Bin. Output	Virtual 8	see Output 1	see Virtual 1
P10.37	Bin. Output	AND Mask 1	-32768...+32767	See section 7.9.1 for more information about the virtual inputs.
P10.38	Bin. Output	AND Mask 2	-32768...+32767	
P10.39	Bin. Output	AND Mask 3	-32768...+32767	
P10.40	Bin. Output	AND Mask 4	-32768...+32767	
P10.41	Bin. Output	AND Mask 5	-32768...+32767	
P10.42	Bin. Output	AND Mask 6	-32768...+32767	
P10.43	Bin. Output	AND Mask 7	-32768...+32767	
P10.44	Bin. Output	AND Mask 8	-32768...+32767	
P10.45	Bin. Output	AND Mask 9	-32768...+32767	
P10.46	Bin. Output	AND Mask 10	-32768...+32767	
P10.47	Bin. Output	AND Mask 11	-32768...+32767	
P10.48	Bin. Output	AND Mask 12	-32768...+32767	
P10.49	Bin. Output	AND Mask 13	-32768...+32767	
P10.50	Bin. Output	AND Mask 14	-32768...+32767	
P10.51	Bin. Output	AND Mask 15	-32768...+32767	
P10.52	Bin. Output	AND Mask 16	-32768...+32767	
P10.53	Bin. Output	OR Mask 1	-32768...+32767	
P10.54	Bin. Output	OR Mask 2	-32768...+32767	
P10.55	Bin. Output	OR Mask 3	-32768...+32767	
P10.56	Bin. Output	OR Mask 4	-32768...+32767	

CAUTION: When using the parameters torque-dependent OPEN or torque-dependent CLOSED (see section 7.1, page 26, items P1.3 and P1.4), the actuator will only be open or closed when the set torque and the associated end position is reached. If the end position is not reached, a torque error is reported (see section 6.2.2, page 19).



NOTE: For optional functions such as a relay board please refer to the corresponding IOM.

7.9.1 Optional: Virtual Output

Upon order or by unlocking via Smartcode, the virtual output functionality may be activated, to extend and/or to define a logic switching through the output signal states. This behaviour is achieved by using logic AND and OR gates.

Each AND gate is connected with all binary outputs twice, once directly and once through an inverted input. The physical binary outputs are assigned a bit of a bit field, i.e., output 1 is assigned to bit 0, input 2 is assigned to bit 1, inverted input 1

is assigned to bit 8, inverted input 2 is assigned to bit 9 and so forth (see figure 60 for a visual representation). By entering the sum of all requested bits as a decimal value for an AND Mask, the AND gate will deliver a TRUE output value, if the signals are correct.

An AND gate will deliver a TRUE output value, if all binary output values are TRUE (consider inverted inputs). If a binary output is not defined, it is deemed as don't care.

The OR gates are connected to all AND gate outputs. The same bit-wise assignation as for the binary outputs applies for the designation of the AND gate outputs, i.e., AND mask 1 is bit 0, AND mask 2 is bit 1 and so forth (see figure 60 for a visual representation). By entering the sum of all requested bits as a decimal value for an OR Mask, the OR gate will deliver a TRUE output value, if the input signals are correct.

An OR gate will deliver a TRUE output value, if at least one of the input values is true (consider inverted inputs). If an AND gate is not defined, it is deemed as don't care.

The following table shows the binary input assignations in binary and their decimal value.

NOTE: There are two separate bit fields; one for the binary inputs and the other one for the AND mask outputs.

Input source	Bit location	Decimal Value
Bin. Output 1	0000 0000 0000 0001	1
Bin. Output 2	0000 0000 0000 0010	2
Bin. Output 3	0000 0000 0000 0100	4
Bin. Output 4	0000 0000 0000 1000	8
Bin. Output 5	0000 0000 0001 0000	16
Bin. Output 6	0000 0000 0010 0000	32
Bin. Output 7	0000 0000 0100 0000	64
Bin. Output 8	0000 0000 1000 0000	128
Inv. bin. Input 1	0000 0001 0000 0000	256
Inv. bin. Input 2	0000 0010 0000 0000	512
Inv. bin. Input 3	0000 0100 0000 0000	1024
Inv. bin. Input 4	0000 1000 0000 0000	2048
Inv. bin. Input 5	0001 0000 0000 0000	4096
Inv. bin. Input 6	0010 0000 0000 0000	8192
Inv. bin. Input 7	0100 0000 0000 0000	16384
Inv. bin. Input 8	1000 0000 0000 0000	32768
AND Mask 1 out	0000 0000 0000 0001	1
AND Mask 2 out	0000 0000 0000 0010	2
AND Mask 3 out	0000 0000 0000 0100	4
AND Mask 4 out	0000 0000 0000 1000	8
AND Mask 5 out	0000 0000 0001 0000	16
AND Mask 6 out	0000 0000 0010 0000	32
AND Mask 7 out	0000 0000 0100 0000	64
AND Mask 8 out	0000 0000 1000 0000	128
AND Mask 9 out	0000 0001 0000 0000	256
AND Mask 10 out	0000 0010 0000 0000	512
AND Mask 11 out	0000 0100 0000 0000	1024
AND Mask 12 out	0000 1000 0000 0000	2048
AND Mask 13 out	0001 0000 0000 0000	4096
AND Mask 14 out	0010 0000 0000 0000	8192
AND Mask 15 out	0100 0000 0000 0000	16384
AND Mask 16 out	1000 0000 0000 0000	32768




Figure 60: An example of the configuration of the AND and OR masks on the SmartTool2 parameterization software.

The example above shows, that the AND gate 0, which is AND mask 1, requires a FALSE signal on bin. output 1, a TRUE signal on bin. output 2 and a TRUE signal on bin. output 4. Summing up the decimal value of these nodes equals the value, which has to be set in P10.37 - AND Mask 1 (NOT(BinOut1) + BinOut2 + BinOut4 corresponds to 256 + 2 + 8 = 266). The AND gate will output TRUE, only if the BinOut1 signal is FALSE, BinOut2 is TRUE and BinOut4 is TRUE, otherwise it stays FALSE.

The same principle applies to the OR gate 0, which is OR Mask 1. The OR gate needs at least a TRUE signal from AND gate 0 or from AND gate 2. Summing up the decimal value of these nodes equals the value, which has to be set in P10.53 - OR Mask 1 (And0 + And2 corresponds to 1+4 = 5). The OR gate will output TRUE, if at least one of the two AND gates outputs a TRUE value.

7.10 Parameter group: Position output (optional)

Position output is used to indicate the current position of the actuator using 0/4...20 mA; it can be retrofitted using a Smart-code.

If this option is not enabled, the menu point shows the message "inactive".

No adjustment to the end positions or the travel is required. Adjustment is automatically performed during the configuration of travel limit positions (see section 7.1, page 26).

No further settings are necessary for torque-dependent switch-off, because the controller exclusively uses travel limit positions for the calculation, regardless of whether this is defined by the torque or the travel limit positions.

The factory default setting is:

4 mA at 0% position

20 mA at 100% position

	Menu item	Sub-menu item	poss. setting	Notes / comments
P11.1	PositionOutput	Function 1	0: off	mA output disabled
			1: Position	mA output corresponds to the actual position value.
			2: Pos. Valvechar.	mA output corresponds to the actual position value taking into account the valve characteristic.
			3: Torque 1	mA output corresponds to the actual torque value.
				torque = 100% Close: mA output = start
				torque = 0%: mA output = center
				torque = 100% Open: mA output = end
			4: Torque 2	mA output corresponds to the actual torque value.
				torque = 100% Close: mA output = end
				torque = 0%: mA output = start
				torque = 100% Open: mA output = end
			5: Torque 3	mA output corresponds to the actual torque value.
				torque = 150% Close: mA output = start
				torque = 0%: mA output = center
	torque = 150% Open: mA output = end			
	6: Torque 4	mA output corresponds to the actual torque value.		
		torque = 150% Close: mA output = end		
		torque = 0%: mA output = start		
		torque = 150% Open: mA output = end		
		7: Ext. Setpoint 1	Passes on the mA input signal on ext. setpoint input.	
		8: Ext. Setpoint 2	Passes on the raw mA input signal on ext. setpoint input.	
P11.2	Position output	Begin 1 (at 0%)	0...20.5 mA {4 mA}	mA value for the Closed (0%) position
P11.3	Position output	End 1 (at 100%)	0...20.5 mA {20 mA}	mA value for the On (100%) position
P11.4	Position output	Calib. 20 mA 1	-10%...+10%	Calibrating the output position during the setting of this parameter will output a 20 mA (100%) signal. Use this parameter to calibrate accurately the 20 mA output signal (e.g., if you measure 19.8 mA at the output, just add 1% (0.2 mA...1% of 20 mA) to the displayed value).
P11.5	Analog output	Function 2	see Function 1	
P11.6	Analog output	Begin 2 (at 0%)	see Begin 1	
P11.7	Analog output	End 2 (at 100%)	see End 1	
P11.8	Analog output	Calib. 20 mA 2	see Calib. 20 mA 1	

7.11 Parameter group: Step mode

Step mode operation can be used to extend the operating time in certain ranges or for the whole travel; it is available in local, remote and emergency mode.

Step mode operation can be activated individually for the directions OPEN and CLOSED.

Cycle start, cycle end, cycle duration and interval time can be set separately for both directions (see Figure 61, page 44).

	Menu item	Sub-menu item	poss. setting	Notes / comments
P12.1	Step mode function	Function	0: Not activated	Step mode operation is disabled
			1: Activated	Step mode operation is enabled in LOCAL, REMOTE and EMERGENCY operation
			2: Only Local	Step mode mode is only enabled in LOCAL mode
			3: Only Remote	Step mode mode is only enabled in REMOTE mode
			4: Only Local + Remote	Step mode mode is enabled in REMOTE and LOCAL mode
P12.2	Step mode function	Start Open	0...100%	In OPEN direction, position in % from which the step mode operation should start.
P12.3	Step mode function	End Open	0...100%	In OPEN direction, position in % of which the step mode operation should end.
P12.4	Step mode function	ON-Time Open	0.1...60	Runtime in OPEN direction
P12.5	Step mode function	OFF-Time Open	0.2...60	Pause time in OPEN direction
P12.6	Step mode function	Start Close	0...100%	In CLOSED direction, position in % from which the step mode operation should start.
P12.7	Step mode function	End Close	0...100%	In CLOSED direction, position in % of which the step mode operation should end.
P12.8	Step mode function	ON-Time Close	0.1...60	Runtime in Closed direction
P12.9	Step mode function	OFF-Time Close	0.2...60	Pause time in Closed direction
P12.10	Step mode function	Timebase	0: Seconds	Time basis for run and pause times
			1: Minutes	
P12.11	Step mode function	Speed adaption	0: Off	Speed adaption not activated. Normal step mode function.
			1: On	Speed adaption is activated. The speed is reduced according to the runtime and pause time in the step mode range. (Example: Running time 1 sec and pause time 1 sec results in half the speed). If the minimum speed is undershot, the actuator clocks in the converted ratio with the minimum speed. The speed adjustment is only applicable to actuators of the type CM and AB CSC.




Figure 61

CAUTION: It is important to ensure that the mode of operation is not exceeded! The running info on the actuator (see section 6.2.2, page 19) only flashes while the drive is running, i.e. during the break, no flash!



7.12 Parameter group: Positioner (optional)

The positioner SR option is used to control the electric actuator by means of a set point input 0/4...20 mA signal. The SR helps control the position of the actuator, i.e. the positioner ensures that the actual value and thus the position of the actuator matches the desired set point.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P13.1	Positioner	Function	0: Off	Positioner disabled
			1: Position	mA input for the position setpoint
			2: Pos. valvechar.	mA input for the position setpoint, taking into account the valve characteristic
P13.2	Positioner	Begin (at 0%)	0...20.5 mA {4.0 mA}	mA value of the setpoint for the CLOSED (0%) position
P13.3	Positioner	End (at 100%)	0...20.5 mA {20.0 mA}	mA value of the setpoint for the OPEN (100%) position
P13.4	Positioner	Dead band	0.05...10.0% {1.0%}	Tolerance range for the control deviation (set point position – actual position) where no adjustment occurs. The deadband should not be set too low to prevent actuator oscillation.
P13.5	Positioner	Gain	1...100% {100%}	The gain (gradient) affects the positioning close to the target position. The smaller the gain selected (e.g. 20%), the earlier the actuator starts reducing its speed in case of speed variable actuators on approaching the target position. In case of actuators with fixed speed (reversing starters), the speed reduction is done by pulsing (also see params P13.9 and P13.10). This leads to better positioning (smaller reachable deadband). A 100% setting disables this gradient.
P13.6	Positioner	Live zero detect.	0: Ignore	The setpoint monitoring (monitoring the setpoint to below approximately 2 mA = loss of signal) is disabled.
			1: Stop	Actuator stops on signal failure.
			2: Open	On signal failure, actuator moves the OPEN position.
			3: Close	Actuator moves on signal failure to the CLOSED position.
			4: Emerg.pos.	On signal failure, the actuator moves the defined emergency position (see parameter P13.7).
			5: Emerg. Open	Emergency open on signal failure.
			6: Emerg. Close	Emergency close on signal failure.
			7: Last valid value	Moves to the last valid value after signal failure; relevant for setpoints over bus. The actuator will move to the 4mA position, in case of an analog input signal failure.
8: Failsafe	Failsafe-operation on signal failure.			
P13.7	Positioner	Emergency pos.	0...100% {50,0%}	Determination of the emergency position (Can also be set in the menu P8.5)
P13.8	Positioner	Calib.Setpoint 20mA	-10%...+10%	Calibration value for the 20mA setpoint. 1% = approx. 0.2mA. Calibration process: By applying 20mA on the setpoint input, this parameter is corrected until the readout matches 20mA.
P13.9	Positioner	Min. impulse	{0,2 s}	Variable speed actuators (Actusmart CM and Smartcon CSC FU): Without function Fixed speed actuators (Smartcon CSC): Minimum activation time of the reversing contactors. For very small activation times (<0.3...0.5 s), the motor will be switched off during start-up process, which significantly increases mechanical wear on reversing contactors. With frequent periods of very small activation times (restless loop, small dead zone, clocking near to the target value), we therefore recommend electronic reversing contactors.

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P13.10	Positioner	Period	{2.0 s}	Variable speed actuators (Actusmart CM and Smartcon CSC FU): Without function Fixed speed actuators (Smartcon CSC): This parameter is only relevant in Step mode when approaching the target position (parameter gain smaller than 100%) and determines the period of a run / pause cycle.
P13.11	Positioner	Begin pos. (a0)	0.0...25.0% {2.0%}	Smallest controllable position other than the end position CLOSED. The range 0% ... a0 will be just passed through. Use the parameter a0 to define the beginning of the allowable control range of the valve (e.g., blind spot for ball segment valves, etc.).
P13.12	Positioner	End pos. (e0)	75.0...100.0% {98.0%}	Largest controllable position other than the end position OPEN. The area e0 ... 100% is just passed through. Use the parameter e0 to define the end of the allowable control range of the valve.
P13.13	Positioner	Begin setp. (a1)	0.0...25.0% {2.0%}	Below this value, the end position CLOSED is controlled. In the range 0% ... a1 cannot be controlled (end position tolerance). The initial setpoint a1 is associated with a small hysteresis (1/4 of the deadband).
P13.14	Positioner	End setp. (e1)	75.0...100.0% {98,0%}	Above this value, the end position OPEN is controlled. The range e1 ... 100% cannot be controlled (end position tolerance). The final setpoint e1 is associated with a small hysteresis (1/4 of the deadband).
P13.15	Positioner	Calib. Setpoint 0mA	-10% ... +10%	Calibration of 0mA for the input setpoint. 1% = approx. 0.2mA. Calibration process: By applying 0mA on the setpoint input, this parameter is corrected until the readout matches 0mA.
P13.16	Positioner	Hysteresis	0 ... 100%	Hysteresis range for setpoint signal, with regard to the dead band. Setting 0 equals to a hysteresis of 25%.




Figure 62: Assigning the position to the setpoint




Figure 63: Function principle of the dead band, and hysteresis in conjunction with the positioner

The figure above shows the working principle of the parameters "P13.4 - Dead Band" and "P13.16 - Hysteresis". The set dead band thresholds are added and subtracted from the setpoint. The hysteresis sets the threshold on the deadband thresholds. E.g. if the setpoint is 50%, dead band is 1% and hysteresis is 50%, the dead band thresholds will be at 49% and 51%. On top of that, the hysteresis for the 49% threshold will be at 50% of the dead band value, which is $\pm 0.5\%$; thus the hysteresis on the 49% dead band threshold is at 48.5% and 49.5%. The actuator will move toward 50%, if the actual position is below 48.5% and stop, if the actual position is between 49.5% and the "outer" hysteresis mirrored on the ordinate, which is 51.5% in this case.

NOTE: Please be aware, that a 100% setting for hysteresis will cause oscillation due to overlapping thresholds.

7.13 Parameter group: PID controller (optional)

The optional PID controller is used for controlling an external actual value (process variable) to a setpoint using 0/4-20 mA signal by readjusting the actuator.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P14.1	PID-controller	Function	0: disabled	PID controller disabled
			1: Position	The output of the PID controller corresponds to the position setpoint of the actuator. The positioning (tracking of the actual position to the setpoint) is done by the positioner (see 7.12).
			2: Speed	The output of the PID controller corresponds to the change of the position setpoint (speed) of the actuator. The positioning (tracking of the actual position to the setpoint) is done by the positioner (see 7.12).
			2: Position Change	The output of the PID controller corresponds to the change of the position setpoint (speed) of the actuator. The positioning (tracking of the actual position to the setpoint) is done by the positioner (see 7.12). Hence a control mode similar to the speed mode (see setting 2 above) is possible also for actuators with constant speed.
P14.2	PID-controller	External Setpoint	0: fixed	The PID controller uses an internal, fixed setpoint (see param P14.3).
			1: external	The PID controller uses the external setpoint. The adjustment of this setpoint is done with the params P13.2 and P13.3 (see 7.12).
P14.3	PID-controller	Fixed setpoint	0... 100%	Specification of the internal fixed setpoint
P14.4	PID-controller	Start (at 0%)	0... 20.5 mA	mA value at 0% of the external actual value
P14.5	PID-controller	End (at 100%)	0... 20.5 mA	mA value at 100% of the external actual value
P14.6	PID-controller	Gain (P)	-50.0... +50.0	Gain (proportional value) of the PID-controller
P14.7	PID-controller	Reset time (I)	0... 100.0 s	The shorter the reset time (integral time, integral value), the stronger is the effect of the integral component of the PID-controller. Values below 1.0 will disable the integral component.

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P14.8	PID-controller	Lead time (D)	0...100.0 s	The larger the lead time (differential/derivative value), the stronger is the effect of the derivative component of the PID-controller. To reduce the influence of noise, a first-order lag element with 1sec time constant is added (DT ₁).
P14.9	PID-controller	Offset	-200...+200%	The offset value will be added to the output value of the PID controller.
P14.10 ¹⁾	PID-controller	Inverse operation	0: Off	The output of the PID controller is not inverted.
			1: On	The output of the PID controller is inverted.
P14.12	PID-controller	Live zero detect.	0: Ignore	The monitoring of the external actual value is disabled
			1: Stop	Actuator stops on signal failure of external actual value
			2: Open	Actuator moves on signal failure of external actual values to the OPEN position.
			3: Close	Actuator moves on signal failure of external actual values to the CLOSED position.
			4: Emergency position	Actuator moves on signal failure of external actual values to the EMERGENCY position (see param P13.7)
P14.13	PID-controller	Calibration of ext. actual value	-10.0...+10.0%	Calibration process: By applying 20 mA to the external actual value input, this parameter is corrected until the readout matches to 20 mA.
P14.14	PID-controller	Process begin	-32768...+32767	Mantissa of the real process variable (begin of external actual value).
P14.15	PID-controller	Process end	-32768...+32767	Mantissa of the real process variable (end of external actual value).
P14.16	PID-controller	Process comma shift	-3...+3	Position of the comma for process begin/end (P14.14, P14.15), e.g.: mantissa = 200, comma shift) -2/2, process value = 2.00/20000
P14.17	PID-controller	Process unit	–	Unit of the real process variable
P14.18	PID-controller	Dead Band	-0.1...10.0%	Tolerance range for the control deviation (set point - external actual value) where no adjustment occurs.

7.14 Parameter group: Bus systems (optional)

The manuals for the Bus systems are available in the download area on our homepage www.schiebel-actuators.com under the tab **Schiebel Tech** under the tab **Documents**.

¹⁾Since firmware version 1.609

7.15 Parameter group: Stroketest (optional)

7.15.1 Operating Manual Partial-Valve-Stroke-Test (PVST)

For a PVST (Partial Valve Stroke Test) the actuator performs in regular intervals a defined movement. This also moves the connected valve.

With the PVST, only a part of the full valve stroke is passed through. If the full valve stroke is passed through, this is called FVST (Full Valve Stroke Test) or FST (Full Stroke Test).

Typically, a PVST is applied to valves that are in the open limit position for a long time (e.g., emergency shutdown valves). These valves are only used in the event of system malfunctions, maintenance or functional tests. Between these events, the plant operator has no information if the valve can still be closed if required.

Normally a short, small movement of the valve in the closing direction is not disturbing the system process. The PVST performs this movement regularly. As a result, on the one hand, a fixation of mechanical components is reduced and, on the other hand, errors are detected prematurely before any emergency shutdown is required. This procedure increases the security system metrics.

The PVST can either be triggered by the control unit on the actuator itself (internally) or by the control system (externally).

Internal trigger:

Manual trigger of the PVST via the menu of the control unit: see parameter P16.11

Time based trigger of the PVST: see parameter P16.7, P16.9 und P16.10

External trigger:

The PVST can be triggered via the binary inputs or an optional fieldbus system.

Procedure of the PVST:

1. The actuator must be in the start position which is set in parameter P16.2. The set hysteresis in parameter P1.8 is taken into account.
2. The actuator must be in the REMOTE mode and READY state.
3. Release of the PVST (internal or external)
4. The status of PVST is set as **PVST-Active**.
5. The actuator moves from the start position to the test range which is defined in parameter P16.3.
6. After reaching the final test position the actuator remains in this position for a specific time, defined in parameter P16.4.
7. Then the actuator moves back to the start position.
8. If the PVST was successful the status will be set to **PVST-OK** otherwise to **PVST-Error**.

The status of the PVST can be monitored continuously via the binary outputs or via the optional fieldbus.

Result of the PVST:

For a successful PVST the following terms must be fulfilled:

1. The actuator must be in the tolerance range of the set hysteresis in the starting position.
2. The actuator must be in the REMOTE mode and READY state during the whole PVST (no error).
3. The PVST must not be interrupted by an other command (binary inputs, commands from optional fieldbus).
4. The switch-off torque must not be exceeded during the PVST.
5. The total time of the PVST must be lower than the maximum time, set in parameter P16.8.

If one or more of the above terms are violated the PVST is not successful.

Parameters: PVST

	Menu Item	Subitem	Options	Explanation/Comments
P16.1	Stroke test	Stroke test		This parameter activates the PVST. For standard actuators (without failsafe function) the PVST is only viable electrically by motor. For failsafe actuators the PVST can additionally be executed as failsafe operation in failsafe direction by spring.
			0	No stroke test is executed.
			1	Stroke test is executed electrically.
			2	Stroke test is executed in failsafe operation by spring.
			3	Two stroke tests. 1. Test: electrically 2. Test: in failsafe operation
4	Two stroke tests. 1. Test: in failsafe operation 2. Test: electrically			
P16.2	Stroke test	Start position	0,00... 100,00%	Start position for the PVST. This value must be 0,00% or 100,00%. If the actuator is not in one of this positions in case of a PVST start the test is not executed and not successful concluded.
P16.3	Stroke test	Test range	0,00... 100,00%	In this range the actuator is moved during the PVST. e.g. Start position: 100,00%, test range: 30,00% The PVST starts at 100,00% and moves the actuator to 70,00% (100,00%-30,00%). After that the actuator moves back to 100%.
P16.4	Stroke test	Resting time	0... 10s	Amount of seconds how long the actuator remains in the end position of the PVST before moving back to the start position.
P16.5	Stroke test	Speed Open	0... 100%	With this parameter it is possible to set the speed in the Open direction for the PVST as far as the actuator has this capability.
P16.6	Stroke test	Speed Close	0... 100%	With this parameter it is possible to set the speed in the Close direction for the PVST as far as the actuator has this capability.
P16.7	Stroke test	Time trigger		If this value is set greater than 0 the PVST will be repeated cyclic according the specific set value. The start command for the PVST is set for one minute and is reseted after the test till the next caclic start.
			0	Off
			1	Every hour
			2	Every 2 hours
			3	Every 3 hours
			4	Every 4 hours
			5	Every 6 hours
			6	Every 8 hours
			7	Every 12 hours
8	Every day			

continued on next page

continued from previous page

	Menu Item	Subitem	Options	Explanation/Comments
			9	Every week
			10	Every 2 weeks
			11	Every month
			12	Every 2 months
			13	Every 3 months
			14	Every 4 months
			15	Every 6 months
			16	Every year
P16.8	Stroke test	Max. time	0... 120s	Maximum timespan for the duration of the PVST. If the test takes longer than the adjusted time it is not successful. The function is deactivated by setting the value to 0.
P16.9	Stroke test	Start date	yyyy-mm-dd	With this parameter the date for the first PVST is set. Parameter is only relevant if P16.7 Time trigger is greater 0.
P16.10	Stroke test	Start time	hh:mm:ss	With this parameter the time for the first PVST is set. The value for the seconds is not relevant. The start command is active for the whole minute independent from the adjusted seconds. Parameter is only relevant if P16.7 Time trigger is greater 0.
P16.11	Stroke test	Start test	0... 1	With this parameter the PVST function can be started from the control menu to test the adjusted values. When the parameter is set to 1, the PVST starts once the actuator is in REMOTE-mode.

7.16 Parameter group: Characteristic curves (optional)

With this option, customers can enable travel-dependent torque, speed and valve characteristic curves.

7.16.1 Torque characteristic

With this characteristic curve, torque limits already set under menu item **P2-torque** (see section 7.2, page 27) can be further **reduced** depending on travel. Characteristics can be configured via the SMARTTOOL software (see Figure 64, page 52).




Figure 64: Torque characteristic

	Menu item	Sub-menu item	poss. setting	Notes / comments
P17.1	Characteristic	Torque Open	0: Off	The torque characteristic curve is disabled for the OPEN direction.
			1: On	The torque characteristic curve is enabled for the OPEN direction.
P17.2	Characteristic	Torque Closed	0: Off	The torque characteristic curve is disabled for the CLOSED direction.
			1: On	The torque characteristic curve is enabled for the CLOSED direction.

7.16.2 Speed characteristic

With this characteristic curve, speed limits already set under menu item **P4-speed** (see section 7.3, page 28) can be further **reduced** depending on travel. Characteristics can be configured via the SMARTTOOL software (see Figure 65, page 53).




Figure 65: Speed characteristic

	Menu item	Sub-menu item	poss. setting	Notes / comments
P17.3	Characteristic	Speed Open	0: Off	The speed characteristic curve is disabled for the OPEN direction.
			1: On	The speed characteristic curve is enabled for the OPEN direction.
P17.4	Characteristic	Speed Closed	0: Off	The speed characteristic curve is disabled for the CLOSED direction.
			1: On	The speed characteristic curve is enabled for the CLOSED direction.

7.16.3 Valve characteristic

With this characteristic curve the mapping between the actuator position and the setpoint of the valve can be adjusted. Hence it is possible to compensate and linearize the general nonlinear characteristic curves of valves. Characteristics can be configured via the SMARTTOOL software (see Figure 66, page 54).




Figure 66: Valve characteristic

	Menu item	Sub-menu item	poss. setting	Notes / comments
P17.5	Characteristic	Valve	0: Off	The valve characteristic curve is disabled.
			1: user defined	The valve characteristic curve is enabled as configured in the SMARTTOOL.

7.17 Parameter group: Identification (optional)

This option allows entering further custom-identification parameters.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P18.1	Identification	PPS number	15 digits	Used to enter a PPS number. This is displayed in the bottom line. CAUTION: Param P20.5 must be set to 0.

7.18 Parameter group: System parameters

Used for actuator configuration. Most of these parameters are used to display crucial information about the actuator configuration for servicing, thus, only visible for user level service or higher.

	Menu item	Sub-menu item	poss. setting	Notes / comments
P19.6	System Parameters	Calib.IST	-10...+10%	This value is used to offset the output signal of the ACTUSMART control unit's analog output. The mA-signal may be calibrated with a current measurement device.

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
P19.7	System Parameters	Calib.Setpoint 20mA	-10...+10%	This value is used to offset the input signal on analog input 1 measured by the ACTUSMART control unit. The measured mA-signal may be calibrated with an external setpoint generator.
P19.8	System Parameters	Calib.ext.act.val. 20mA	-10...+10%	This value is used to offset the input signal on the external analog input 2 measured by the ACTUSMART control unit. The measured mA-signal may be calibrated with an external setpoint generator.
P19.12	System Parameters	LCD Contrast	80...150	The display contrast may be set with this parameter.
P19.15	System Parameters	Welcome Menu	0; 1	Starts the actuator with the welcome menu on startup, if set to 1.
P19.21	System Parameters	LED Function		See "P1.7 - LED function" in section 7.1 on page 26.
P19.33	System Parameters	MUSE- Detection	0 : -	MUSE-Detection is not executed.
			1: Execute	MUSE-Detection is executed.
P19.56	System Parameters	LCD Inverse	0; 1	Inverts the display pixels.

7.19 Parameter group: Miscellaneous

	Menu item	Sub-menu item	poss. setting	Notes / comment
P20.1	Miscellaneous	Language	0: German	Defines the menu language
			1: English	
			2: Russian	
			3: Czech	
			4: Spanish	
			5: French	
			6: Italian	
			7: Danish	
			8: Hungarian	
			9: Turkish	
			10: Greek	
			11: Polish	
			12: Serbian	
			13: Croatian	
			14: Bulgarian	
			15: Dutch	
			16: Romanian	
17: Swedish				
P20.2	Miscellaneous	Smartcode		Enables additional features by entering a Smartcode
P20.3	Miscellaneous	Restore Backup	0:	no action
			1: Customer -	Restores all parameters to the customer backup parametrization, without changing the end limits (P1.1 and P1.2) and the switch off torques and torque limit(P2.1, P2.2 and P2.3).
			2: Customer +	Restores all parameters to the customer backup parametrization, including the end limits (P1.1 and P1.2) and the switch off torques and torque limit(P2.1, P2.2 and P2.3).
			3: Service -	Restores all parameters to the service backup parametrization, without changing the end limits (P1.1 and P1.2) and the switch off torques and torque limit(P2.1, P2.2 and P2.3).

continued on next page

continued from previous page

	Menu item	Sub-menu item	poss. setting	Notes / comments
			4: Service +	Restores all parameters to the service backup parametrization, including the end limits (P1.1 and P1.2) and the switch off torques and torque limit(P2.1, P2.2 and P2.3).
			5: Workshop -	Restores all parameters to the workshop backup parametrization, without changing the end limits (P1.1 and P1.2) and the switch off torques and torque limit(P2.1, P2.2 and P2.3).
			6: Workshop +	Restores all parameters to the workshop backup parametrization, including the end limits (P1.1 and P1.2) and the switch off torques and torque limit(P2.1, P2.2 and P2.3).
P20.4	Miscellaneous	Save Backup	0:	no action
			1: Customer	By saving this setting, the current parameters are adopted as customer parameters.
			2: Service	By saving this setting, the current parameters are adopted as service parameters.
			3: Workshop	By saving this setting, the current parameters are adopted as workshop parameters.
P20.5	Miscellaneous	Info line	0...15	The bottom line of the display shows various diagnostic values.
P20.6	Miscellaneous	Wireless	0: Off	The infrared and bluetooth connection is disabled.
			1: Infrared	The infrared connection is active for about 3 minutes unless communication is detected.
			2: Bluetooth	The Bluetooth connection is active for about 3 minutes unless communication is detected.
			3: Infrared+	The infrared connection is activated.
			4: Bluetooth+	The Bluetooth connection is activated.
P20.7	Miscellaneous	Menu style	0...2	different menu styles
P20.9	Miscellaneous	Time		Sets the date and time on the actuator. Move the red selector switch to highlight the next value, and down to highlight the prior value.
P20.10	Miscellaneous	Timezone	-840...840 min.	Sets the timezone; offsets the shown time in minutes.
P20.11	Miscellaneous	Daylight saving time	0: Off	Time without daylight saving
			1: On	Turns on daylight saving time
			2: Auto	With this setting, the daylight saving time is automatically detected.

NOTE: Backups are prioritized; the higher the number, the higher the priority. For example, if parameters are backed up as service, the customer parameters will be overwritten.

7.20 Default User Level Settings

The following table shows the default user level settings for all parameters on a brand-new actuator.

Parameter	Menu item	Sub-menu item	Default UL Read	Default UL Write
P1.1	End Limit	Open	1	3
P1.2	End Limit	Close	1	3
P1.3	End Limit	Switch Off Open	2	4
P1.4	End Limit	Switch Off Close	2	4
P1.5	End Limit	Closing direction	2	4
P1.7	End Limit	LED Function	1	3
P1.8	End Limit	Hysteresis	2	4
P1.9	End Limit	Ramp	2	4
P1.11	End Limit	Overrun Open	2	4
P1.12	End Limit	Overrun Close	2	4
P2.1	Torque	Open	2	4
P2.2	Torque	Close	2	4
P4.1	Speed	Local Open	2	4
P4.2	Speed	Local Close	2	4
P4.3	Speed	Remote Open	2	4
P4.4	Speed	Remote Close	2	4
P4.5	Speed	Emerg. Open	2	4
P4.6	Speed	Emerg. Close	2	4
P4.7	Speed	Torque dep. oper.	2	4
P4.8	Speed	Minimal	2	4
P5.1	Ramp	Local	2	4
P5.2	Ramp	Remote	2	4
P5.3	Ramp	Emergency	2	4
P6.2	Control	Ready delay	2	4
P6.5	Control	24V Output	2	4
P6.6	Control	Min. Impuls	2	4
P6.17	Control	Remote Display	2	4
P7.1	User Level	Local	2	4
P7.2	User Level	Bus	2	4
P7.3	User Level	Remote Display	2	4
P7.4	User Level	Change Password	1	1
P8.1	Position	Intermed.pos.1	1	3
P8.2	Position	Intermed.pos.2	1	3
P8.3	Position	Intermed.pos.3	1	3
P8.4	Position	Intermed.pos.4	1	3
P8.5	Position	Emerg.position	1	3
P8.6	Position	Hysteresis	1	3
P8.7	Position	Intermed.pos.5	1	3
P8.8	Position	Intermed.pos.6	1	3
P8.9	Position	Intermed.pos.7	1	3
P8.10	Position	Intermed.pos.8	1	3
P8.11	Position	Dead Band	1	3
P8.12	Position	Gain	1	3
P8.13	Position	Hysteresis	1	3
P8.14	Position	Intermed.pos.9	1	3
P8.15	Position	Intermed.pos.10	1	3
P8.16	Position	Intermed.pos.11	1	3
P8.17	Position	Intermed.pos.12	1	3

continued on next page

continued from previous page

Parameter	Menu item	Sub-menu item	Default UL Read	Default UL Write
P8.18	Position	Intermed.pos.13	1	3
P8.19	Position	Intermed.pos.14	1	3
P8.20	Position	Intermed.pos.15	1	3
P8.21	Position	Intermed.pos.16	1	3
P9.1	Bin. Input	Input 1	2	4
P9.2	Bin. Input	Input 2	2	4
P9.3	Bin. Input	Input 3	2	4
P9.4	Bin. Input	Input 4	2	4
P9.5	Bin. Input	Input 5	2	4
P10.1	Bin. Output	Output 1	2	4
P10.2	Bin. Output	Output conf. 1	2	4
P10.3	Bin. Output	Output 2	2	4
P10.4	Bin. Output	Output conf. 2	2	4
P10.5	Bin. Output	Output 3	2	4
P10.6	Bin. Output	Output conf. 3	2	4
P10.7	Bin. Output	Output 4	2	4
P10.8	Bin. Output	Output conf. 4	2	4
P10.9	Bin. Output	Output 5	2	4
P10.10	Bin. Output	Output conf. 5	2	4
P10.11	Bin. Output	Output 6	2	4
P10.12	Bin. Output	Output conf. 6	2	4
P10.13	Bin. Output	Output 7	2	4
P10.14	Bin. Output	Output conf. 7	2	4
P10.15	Bin. Output	Output 8	2	4
P10.16	Bin. Output	Output conf. 8	2	4
P11.1	Analog Signal	Function 1	2	4
P11.2	Analog Signal	Begin 1 (at 0%)	2	4
P11.3	Analog Signal	End 1 (at 100%)	2	4
P11.4	Analog Signal	Calib.20mA 1	2	4
P11.5	Analog Signal	Function 2	2	4
P11.6	Analog Signal	Begin 2 (at 0%)	2	4
P11.7	Analog Signal	End 2 (at 100%)	2	4
P11.8	Analog Signal	Calib.20mA 2	2	4
P12.1	Step mode	Function	2	4
P12.2	Step mode	Start Open	2	4
P12.3	Step mode	End Open	2	4
P12.4	Step mode	ON time Open	2	4
P12.5	Step mode	OFF time Open	2	4
P12.6	Step mode	Start Close	2	4
P12.7	Step mode	End Close	2	4
P12.8	Step mode	ON time Close	2	4
P12.9	Step mode	OFF time Close	2	4
P12.10	Step mode	Time base	2	4
P12.11	Step mode	Speed adaption	2	4
P13.1	Positioner	Function	2	4
P13.2	Positioner	Begin (at 0%)	2	4
P13.3	Positioner	End (at 100%)	2	4
P13.4	Positioner	Dead band	2	4
P13.5	Positioner	Gain	2	4
P13.6	Positioner	Live zero detect.	2	4

continued on next page

continued from previous page

Parameter	Menu item	Sub-menu item	Default UL Read	Default UL Write
P13.7	Positioner	Emergency pos.	1	3
P13.8	Positioner	Calib.setpoint	2	4
P13.9	Positioner	Min.Impuls	2	4
P13.10	Positioner	Period	2	4
P13.11	Positioner	Begin pos. (a0)	2	4
P13.12	Positioner	End pos. (e0)	2	4
P13.13	Positioner	Begin setp. (a1)	2	4
P13.14	Positioner	End setp. (e1)	2	4
P13.15	Positioner	Calib.setpoint offset	2	4
P13.16	Positioner	Hysteresis	2	4
P14.1	PID-controller	Function	2	4
P14.2	PID-controller	Ext.setpoint	2	4
P14.3	PID-controller	Setpoint value	2	4
P14.4	PID-controller	Begin (at 0%)	2	4
P14.5	PID-controller	End (at 100%)	2	4
P14.6	PID-controller	Proportional	2	4
P14.7	PID-controller	Integral	2	4
P14.8	PID-controller	Differential	2	4
P14.9	PID-controller	Offset	2	4
P14.12	PID-controller	Live zero detect.	2	4
P14.13	PID-controller	Cal.ext.act.val	2	4
P14.14	PID-controller	Process begin	2	4
P14.15	PID-controller	Process end	2	4
P14.16	PID-controller	Process comma shift	2	4
P14.17	PID-controller	Process unit	2	4
P14.18	PID-controller	Dead band	2	4
P16.1	Stroketest	Stroketest	2	4
P16.2	Stroketest	Start position	2	4
P16.3	Stroketest	Test range	2	4
P16.4	Stroketest	Resting time	2	4
P16.5	Stroketest	Speed Open	2	4
P16.6	Stroketest	Speed Close	2	4
P16.7	Stroketest	Time trigger	2	4
P16.8	Stroketest	Max. time	2	4
P16.9	Stroketest	Start Time	2	4
P16.10	Stroketest	Start Test	2	4
P17.1	Characteristic	Torque Open	2	4
P17.2	Characteristic	Torque Close	2	4
P17.3	Characteristic	Speed Open	2	4
P17.4	Characteristic	Speed Close	2	4
P17.5	Characteristic	Valve	2	4
P18.1	Identification	KKS-Number	2	4
P19.6	System	Calib.IST	2	4
P19.7	System	Calib.SOLL	2	4
P19.8	System	Calib.EIST	2	4
P19.12	System	LCD Contrast	2	4
P19.15	System	Welcome Menu	4	4
P19.21	System	LED Function	1	3
P19.56	System	LCD Inverse	2	4

continued on next page

continued from previous page

Parameter	Menu item	Sub-menu item	Default UL Read	Default UL Write
P20.1	Miscellaneous	Language	1	3
P20.2	Miscellaneous	Smartcode	1	1
P20.3	Miscellaneous	Restore	4	4
P20.4	Miscellaneous	Backup	4	4
P20.5	Miscellaneous	Info display	1	3
P20.6	Miscellaneous	Wireless	1	3
P20.7	Miscellaneous	Menu Style	1	3
P20.9	Miscellaneous	Time	1	3
P20.10	Miscellaneous	Timezone	1	3
P20.11	Miscellaneous	Daylight saving time	1	3

8 Status area

The status area presents current process and diagnostic data. In this area, data is read-only. To access the status area, move the control switch in the direction where the selector switch should be in the neutral position or in the remote position.

The status area is divided into 2 sub-areas:

- Status
- History

8.1 Status

8.1.1 Status – binary outputs

Display of binary outputs: The display shows output control as opposed to output status, i.e. the supply of the binary outputs is ignored. A switched output is represented by 1.




Figure 67: 1... Output Number, 2... Signal (0 = LOW; 1 = HIGH)

8.1.2 Status – binary inputs

Display of binary inputs: A set input is represented by 1.




Figure 68: 1... Input number, 2... Signal (0 = LOW; 1 = HIGH)

8.1.3 Status – analog values

Display of analogue values: Input 1 (In1) is used by the positioner as the setpoint; Input 2 (In2) serves as an external value for the optional PID controller. In the analogue output (out), only the control signal is shown, regardless of whether the output current actually flows or not (interruption of the current loop).




Figure 69: 1... Input 1, 2... Input 2, 3... Output, 4... All values in mA

8.1.4 Status – absolute values

This status displays the absolut position of the actuator.




Figure 70: 1... Absolute value of the position unit, 2... Relative value of the position unit 3 and 4... Absolute and relative value for the torque unit (calibrated in factory)

8.1.5 Status – firmware




Figure 71: 1... Firmware version of the corresponding el. component, 2... Parameter set version, 3... Bootloader version

8.1.6 Status – serial number




Figure 72: 1... Serial number of the electronics, 2... Serial number of the actuator, 3... Serial number of the control unit

8.1.7 Status – meter readings




Figure 73: 1... Counters for power on cycles, power on time and motor run time, 2... Actual date and time

8.2 History

History shows the last 20 history entries. In addition to the plain text entry, the time since the last history entry and, in case of an error, the error value is also provided.

Please note that the actuator can only calculate time if energized. For error analysis, please refer to section 13, page 65.

NOTE: Up to 500 history entries are saved, and may be viewed with the SmartTool2.




Figure 74: Example for a history entry.

9 Infrared connection

For easier communication and better visualization of the menu options, the unit provides an infrared port for connection to a PC.

The required hardware (connection cable to the PC's RS-232 or USB connectors) and the corresponding software are available as options.

The SMARTTOOL software, in addition to communication with the actuator, allows the management of multiple actuators to transfer the configuration to different actuators.

This approach can greatly simplify operation.

Please refer to the SMARTTOOL software operating instructions manual for further information.

During operation, it must be ensured that the IR interface surface is protected from strong disturbances which may otherwise compromise the communication.

Before mounting the infrared adapter, clean the surface of the infrared interface with a damp cloth.

When the infrared interface is enabled, it is indicated by LED L5 (see section 6.2.2, Figure 75, page 19). The infrared interface can be enabled in the menu item P20.6.



Figure 75: 1... Infrared connection

10 Bluetooth connection

In addition to the infrared interface, it is also possible to configure the Control System using a Bluetooth interface.

Software required for Android equipment is available as an option.

In addition to communication with the actuator, the Android software also enables management of multiple actuators, allowing easy transfer of parameter sets to various actuators.

This approach can significantly simplify commissioning.

When the Bluetooth interface is enabled, this is indicated by LED L5 (see Figure 75 resp. section 6.2.2, page 19). The Bluetooth interface can be enabled in menu item P20.6.

11 Maintenance

WARNING: Maintenance work on open actuators may only be conducted if these are de-energized. Re-connection during maintenance is strictly prohibited. Work on the electrical system or equipment must be carried out only in accordance with electrical regulations by a qualified electrician himself or by specially instructed personnel under the control and supervision of a qualified electrician.



WARNING: For explosion-proof actuators, it is necessary to wait a certain time after switching off before opening the cover; see explosion protection sticker (Picture 76).



Following times are specified for the actuators.

- CM03: 5 min
- CM06: 10 min
- CM12: 15 min



Figure 76: 1... Explosion protection sticker

Actuators are ready for use after installation. By default, the actuator is delivered filled with oil.
On-going monitoring:

- Beware of increased running noise. During long downtime periods, operate the actuator at least every 3 months.
- For actuators with output types A, B and C according to DIN 3210-A, B1, B2 and C according to DIN ISO 5210, re-lubricate at least every 6 months on existing grease fittings (see section 16.3, page 69).

Actuators are designed for installation in any position (see section 2.5, page 7). Therefore, the main body is not equipped with a level indication or a drain plug.

The replacement of the lubricant from the main body must be performed via the handwheel.

Every approx. 10,000 to 20,000 hours (about 5 years, see section 16, page 68), depending on the workload, you must:

- change oil, and
- replace seals.

Check all roller bearings and the worm-wheel assembly and replace if necessary.

Check our lubricants table for recommended oils and greases (see section 16, page 68).

NOTE: Check the cable glands at regular intervals (annually) for tightness of the cables and retighten if necessary.

If the visual inspection (eg. dust or water penetration) indicates that the effectiveness of the sealing elements of the cable entry has suffered damage or aging, such elements have to be replaced preferably by using the original spare parts from

the manufacturer of the equipment or through cable entries of comparable quality as well as the same ex- or IP protection class.

If screws need to be replaced, it is preferable to use original replacement parts. The tensile strength of the screws must be at least 400 N/mm² !

CAUTION: In the case of explosion-proof actuators, repairs to the flameproof joints are **NOT** intended. If damage is found on the gap surfaces (control unit cover, motor shaft, sensor shaft, cable bushings), the device must be replaced!



12 Battery Replacement

WARNING: All work on the opened device is only permitted in a de-energized state. The device must not be switched on again during work!



WARNING: For explosion-proof actuators, it is necessary to wait a certain time after switching off before opening the cover (see section 11, page 64).



In order to be able to maintain the function of the real-time clock as well as the counter readings of the controller even in a de-energized state, it has a button cell battery. The service life of this battery varies depending on the ambient conditions, and must be replaced if necessary, at the latest as soon as the control unit issues the relevant warning (see section 13.1, page 65).

For replacement, pry the battery out of the socket using a plastic lever tool. Make sure that the tool is not placed under the socket, as this may cause damage to the circuit board. Then replace the battery with the following characteristics:

- Model Number: CR2032
- Electrochemical System: MnO₂/Li
- Nominal Voltage: 3V
- Rated Capacity: 225mAh

13 Troubleshooting

Upon warning or error, the bottom line of the display will show the corresponding plain text description. This event will also be entered into the history (see section 8.2, page 62).

13.1 History Entries

Listed below are all possible history entries. In case of a warning, the alarm will be visualized on the left side of the main display. If an alarm occurs, the display background light will be red, and the main display will show, that the actuator is not ready.

NOTE: Each error has a unique error number. Each error also has its separate “OK” message in the history after the fault has gone.

History Entry	Type	Description
#3: Mot. temp. warn. #19: Mot. temp. warn. OK	Warning	The motor temperature is in the critical range although the actuator remains fully functional.
#4: Mot. temp. switchoff #20: Mot. temp. switchoff OK	Alarm	Overtemp in motor, fault on Basis or BLDC, On Basis: loss of main power (3x400V) or cable break between CSC and motor; on BLDC: cable break between BLDC and motor.
#5: Phase sequ. fault #6: Phase sequ. OK	n.a.	Cause on Basis: Active phase sequence detection on single phase actuators, loss of main power while connected to external 24 VDC auxiliary voltage, or loss of phase L2.
#7: Ready	Information	Written to the history after all errors are gone.
#8: Power On	Information	Is written to the history after power on the actuator, even if there are some errors.

continued on next page

continued from previous page

History Entry	Type	Description
#9: Power supply Fault #21: Power supply OK	Alarm	No power supply to the power electronics (when the controller is powered from the auxiliary power input). Defect of power electronics – please contact the manufacturer.
#11: Failsafe Fault #12: Failsafe OK	Alarm	Communication error between Failsafe board and Logic, loss of external 24 V Failsafe Voltage, or overtemp. on Failsafe brake.
#13: Manual override #14: Manual override Off	Alarm	Manual override on Failsafe active (visible in status S4), cable/switch broken.
#17: Travel Sensor Fault #18: Travel Sensor OK	Alarm	The travel unit is outside the permitted range (potentiometer fault on Basis), cable broken, or multiturnsensor calibration lost on CM – please contact the manufacturer.
#22: Torque Sensor Fault #23: Torque Sensor OK	n.a.	Potentiometer fault on Basis, or cable broken.
#24: Bus Fault #25: Bus OK	Warning	No communication with the optional bus system.
#26: Bus Watchdog #27: Bus Watchdog OK	Warning	Watchdog for bus communication has reacted.
#28: Undervoltage> Warning #29: Voltage OK	Warning	The input voltage is below the regular voltage range, but motor operation is still possible.
#32: Internal Comm. Fault L>Error #33 Internal Comm. Fault L>OK	Alarm	Communication error between Logik and Basis/BLDC, cable broken between boards, or board defect.
#34: Internal Comm. Fault D>Error #35: Internal Comm. Fault D>OK	Alarm	Communication error between Display and Logik, cable broken between boards, boards defect, or firmware update on Logik not properly done.
#36: Failsafe not ready #37: Failsafe ready	n.a.	Failsafe voltage OK and Failsafe not initialized (LUS not tensioned).
#38: RTC Battery low #39: RTC Battery OK	Warning	Battery on Display board is empty, loss of time/date or counter values possible.
#44: Inverter Fault #45 Inverter OK	Alarm	BLDC parameter error or defective BLDC. Please contact the manufacturer.
#46: Analog Input 1 Signal Loss #47: Analog Input 1 OK	Warning	SRG active, Positioner live zero detection activated, no setpoint value recognized.
#48: Analog Input 2 Signal Loss #49: Analog Input 2 OK	Warning	Ext. setpoint active, Ext. setpoint live zero detection activated, no Ext. setpoint value recognized
#50: End Limits Are The Same #51: End Limits OK	Alarm	The End limits for OPEN and CLOSE are the same values.
#52: User Input Switches Error #53: User Input Switches OK	Alarm	The selector switches are not calibrated. Please use the the calibration function in the wizard in the SmartTool2.
#54: PVST Error #55: PVST OK	Information	The last PVST was not successful
#56: Internal Comm. Fault E>Error #57: Internal Comm. Fault E>OK	Warning	Communication error between remote display and main display. Cable to from remote display to EB2_2, EB2_2 to EB2_1, or EB2_1 to main display broken. Also, one of the boards may be faulty.
#58: Undervoltage Error	Alarm	The input voltage is below the minimum threshold voltage; motor operation is not given. May appear in the history, if the actuator was turned off, in which case no #29: Voltage OK entry will be registered.
#59: Undervoltage Switch.Off	Alarm	The input voltage line caused the actuator to turn off 6 times, indicating an unstable power supply.
#60: Overvoltage Warning	Warning	The input voltage is over the regular supply voltage range. Motor operation is possible.
#61: PVST Start	Information	A PVST procedure was started

continued on next page

continued from previous page

History Entry	Type	Description
#62: Parameter Write Access	Information	Shows information about, which value was written on a parameter. The values for N, L and S are internal values and useful for diagnosing.
#63: Restore	Information	A restore procedure via P20.3 was undertaken.
#64: Password Change	Information	A password change has been undertaken.
#65: History Cleared	Information	The complete history entry memory was cleared by the manufacturer.

14 Fuses

The Logik board of the controller cover (see Figure 77, page 68) features two miniature fuses for the control lines.




Figure 77: FL1... fuse for auxiliary supply, FL2... fuse for the binary outputs

Fuses on the logic board

Fuse	Value	Manufacturer	No. of spare parts
FL1	1AT	Littelfuse 454 NANO ² Slo-Blo [®] slow	FUSE-F1
FL2	4AT	Littelfuse 454 NANO ² Slo-Blo [®] slow	FUSE-F2

NOTE: The frequency inverter is protected by an input fuse and the explosion-proof version also has a thermal fuse (see section 2.7.3, page 8).

15 Spare parts

When ordering spare parts, please provide us with the serial number of the actuator (see section 2.2, page 6). Check the separate break-down image and separate list of spare parts.

16 Lubricant recommendation, lubricant requirements

CAUTION: Please note, that safety precautions such as the use of personal protective equipment (PPA) may have to be followed! Please consult the safety datasheet (in section 8) of the product in question.



16.1 Main body: -25 to +60 °C

Operating oil: DIN 51 517-CLP-HC

i.e. fully synthetic high-performance gear oils based on poly-alpha-olefins (PAO)

Viscosity class:	320 ISO VG
Pourpoint:	< -39 °C (according DIN ISO 3016)
Lubricant requirement CM03:	200... 250 ml
Lubricant requirement CM06:	300... 350 ml
Lubricant requirement CM12:	600... 650 ml

16.2 Main body: -40 to +60 °C

Operating oil: DIN 51 517-CLP-HC

i.e. fully synthetic high-performance gear oils based on poly-alpha-olefins (PAO)

Viscosity class:	68 ISO VG
Pourpoint:	< -54 °C (according DIN ISO 3016)
Lubricant requirement CM03:	200... 250 ml
Lubricant requirement CM06:	300... 350 ml
Lubricant requirement CM12:	600... 650 ml

16.3 Output type A and spindle drives (linear actuators) -40 to +60 °C

Grease DIN 51825-K(P) R -40

i.e. water repellent complex grease on Al-soap base with high resistance to acids and alkalis

Penetration 0.1 mm:	310 -340
Dropping point:	about 260 °C
NLGI No.:	1
acid-free, little or not water-reactive	

16.4 Basic lubricant service interval

NOTE: Schiebel actuators must be serviced 10 years after delivery by SCHIEBEL Antriebstechnik GmbH, A-1230 Vienna. The functionality and durability of the lubricant is however contingent upon the operating conditions. Where applicable, reduction factors must be considered.

Operating condition (s)	Definition	Reduction factor (multiplier)
Duty time DT	(Total engine running time)	
Extremely high DT	over 1250 hours/year	0.5
High DT	over 500 hours/year	0.7
Extremely low DT	less than 0.5 hours/year	0.8
Ambient temperature	(permanent or long-term)	
Extremely changeable	between -10 and +50 °C	0.5
Extremely high	above +50 °C	0.7
Extremely low	below -25 °C	0.9
Output speed	(on actuator main shaft)	
High speed	over 80 rpm	0.8
Utilisation	(relative to rated power)	
Very high	over 90%	0.8
High	between 80 and 90%	0.9

Application example:

Extremely low DT + extremely low ambient temperature + high speed + 87% utilization

*⇒ 0.8 * 0.9 * 0.8 * 0.9 = 0.51 reduction factor*

*Lubrication maintenance interval ⇒ 10 years * 0.51 = 5.1 years (62 months).*

CAUTION: This calculated maintenance interval does neither apply to the maintenance of output type A (threated bushing) units nor to the maintenance of linear and spindle drive units. These units must be periodically lubricated (at least every 6 months) via the grease nipples (see section 16.3)!



During maintenance of our actuators, remove and replace old grease with new one. **Mixing of different lubricant types is NOT permitted.**

Quantities needed for lubricant service are listed in section 16, page 68.

17 Training

NOTE: If you experience problems during installation or upon adjustments on site, please contact SCHIEBEL, Vienna at +43 (1) 66 108 or via the Internet at www.schiebel-actuators.com to prevent any operational errors or damage to the actuators. Schiebel recommends engaging only qualified personnel for installation of Schiebel actuators. Upon special request of the client, SCHIEBEL can conduct training on the activities listed in this operating manual at the factory of SCHIEBEL.

18 Original Declaration of Incorporation of Partly Completed Machinery

According Machinery Directive 2006/42/EC (Annex II, sub. B)

The manufacturer, the company:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Vienna

hereby declares that for the partly completed machinery described below:

Electric actuators series:

CM	rCM	exCM	exrCM
----	-----	------	-------

the following basic requirements of the Machinery Directive (2006/42/EC) are applied and fulfilled:

Annex I,	articles	1.1.2, 1.1.3, 1.1.5; 1.2.1, 1.2.1, 1.2.2, 1.2.6; 1.3.1, 1.3.2, 1.3.7; 1.5.1; 1.6.3; 1.7.1, 1.7.3, 1.7.4
----------	----------	--

The following European harmonized standards have been applied:

EN 12100:2010		
EN ISO 5210:1996	EN ISO 5211:2001	DIN 3358:1982

The relevant technical documentation for partly completed machinery referred to in Annex VII, Part B has been prepared. The manufacturer commits to electronically submitting the documents for the incomplete machine to the competent national authority upon request.

For the preparation of the technical documents is authorized:

Head of mechanical Engineering
Schiebel Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Vienna

This partly completed machinery must not be put into service until the final machinery into which it is to be incorporated has been declared in conformity with the provisions of the Machinery Directive 2006/42/EC, where appropriate.

The electric actuators as partly completed machinery are in conformity with the relevant regulations of the EU directives:

Directive 2014/30/EU ("EMV-Directive")
Directive 2014/35/EU ("Low voltage directive")
Directive 2014/34/EU ("ATEX-Directive") for correspondingly marked devices

The corresponding separate EC Declarations of Conformity are valid.

Vienna,
(location)

13th March 2018
(date)



.....
(Klaus Schiebel, general manager)

19 Declaration of Conformity

(EMV directive and Low voltage directive)

The producer:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Wien

herewith confirms that the equipment

electric actuators with integrated control unit model Actusmart and following types

- (r) CM03
- (r) CM03 FS
- (r) CM06
- (r) CM06 FS

meets the requirement of the EC directive:

2014/30/EU („EMV directive“)

and complies with the following harmonised standards in the version valid at signature date:

EN 61000-6-2:2005 **EN 61000-6-4:2014**

and are also consistent with the EC directive:

2014/35/EU („Low voltage directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

IEC 60204-1:2005 + A1:2008 **EN 60529:1991 + A1:2000**

Vienna,
(location)

14.2.2018
(date)



.....
(Klaus Schiebel, general manager)

20 Declaration of Conformity

(Ex directive, EMC directive and Low voltage directive)

The producer:

SCHIEBEL Antriebstechnik Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Wien

herewith confirms that the equipment

electric actuators with integrated control unit model Actusmart and following types

ex (r) CM03	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X
ex (r) CM03 FS	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X
ex (r) CM06	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X
ex (r) CM06 FS	⊕II 2 G Ex db eb (mb) II C T4(T6) Gb	TÜV-A13ATEX0006X

meets the requirement of the EC directive:

2014/34/EU

EC Directive for Operation of Equipment in Potentially Explosive Atmospheres

and complies with the following harmonised standards in the version valid at signature date:

EN IEC 60079-0:2018	EN 60079-1:2014	EN IEC 60079-7:2015
EN 60079-18:2015	EN ISO 80079-36:2016	EN ISO 80079-37:2016

For the above listed actuators, a type examination certificate TUV A13ATEX0006X, issued by TÜV Austria Services GMBH, is available. The following notified bodies certify the conforming type:

TÜV Austria Services GmbH	A-1230 Wien	NB 0408: Type examination certification
FTZU	CZ-716 07 Ostrava Radvanice	NB 1026: Quality system FTZU03ATEXQ019

Furthermore, they are consistent with the EC directive

2014/30/EU („EMC directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

EN 61000-6-2:2005	EN 61000-6-4:2014
--------------------------	--------------------------

and are also consistent with the EC-directive:

2014/35/EU („Low voltage directive“)

in consideration of the respective operating instructions, and the fulfilment of the Directive has been demonstrated by the following standards:

IEC 60204-1:2005 + A1:2008	EN 60529:1991 + A1:2000
-----------------------------------	--------------------------------

Vienna,
(location)

14.03.2022
(date)



.....
(Klaus Schiebel, general manager)

21 Technical data




Figure 78: Control unit




Figure 79: Logik board

21.1 Binary outputs

Count:	8
Power supply:	24 VDC nominal range: 11... 35 VDC (either from internal or external)
Max voltage drop at set output:	1 V
Output voltage at non-set output:	<1 V
Maximum current per output:	500 mA (short circuit proof)
Maximum permissible total current for all outputs:	4 A
Fuse (Fuse FL2, see Figure 79, page 73):	4 A slow (Littelfuse 454 NANO ² Slo-Blo [®])


Binary outputs with external supply are separated from other controllers via optocouplers.

It is allowed to connect binary outputs in parallel. If the outputs have the same setting (see chapter 7.9), the current of each output may be added together. If the settings of the outputs are different, a hardwired logical OR is realized.

21.2 Binary inputs

Count:	5
Nominal voltage:	24 VDC towards common ground
Voltage for input set:	>10 V (8.5 V typ.)
Voltage for input not set:	<7 V (8.5 V typ.)
Maximum voltage:	30 VDC
Current consumption at 24 VDC:	10.5 mA typ.

Binary inputs are separated from other controllers via optocouplers.



Ui ... Input voltage
 li ... Input current

Figure 80: Binary inputs, input characteristic

Jumpers JP1 ... JP3 can be used to interconnect the binary inputs to groups with separate earths:




Figure 81: 5 inputs with same common




Figure 82: 2 separated groups of 2 inputs with same ground
 Input IN3 is disabled.




Figure 83: 3 separated inputs
 Inputs IN2 and IN4 are disabled.




Figure 84: 3 inputs with same common and 1 separated input.
 Input IN4 is disabled.




Figure 85: 1 separated input and 3 inputs with same common.
 Input IN2 is disabled.

Examples:




Figure 86: 5 inputs with common = "-" using external 24V




Figure 87: 5 inputs with common = "-" using internal 24V
 (e.g. for dry contacts)




Figure 88: 3 separated inputs using 3 separated external 24V




Figure 89: 3 separated inputs with common = "+" using external 24V

21.3 Analog inputs

Input 1: setpoint value

- Current range:0... 25 mA
- Resolution: 14 bit
- Accuracy: 0.5%
- Input resistance: 60 Ω

Analog input 1 is electrically isolated from the rest of the electronic system.

Input 2: External actual value (only in combination with PID controller)

- Current range:0... 20.8 mA
- Resolution: 12 bit
- Accuracy: 0.5%
- Input resistance: 120 Ω

21 Technical data

Jumper JP6 can be used to switch analog input 2 from a passive input (default) to an input with internal 24 V power supply (for 4...20 mA, two-wire transmitters).




Figure 90: Passive input (default)




Figure 91: Input with internal supply (active input)

NOTE: The analog input 2 is referenced to common of the electronic system and the auxiliary power supply (see section 21.5).

21.4 Analog output

Current range: 0...20.8 mA
 Resolution: 12 bit
 Accuracy: 0.5%
 Max load: 600 Ω

The analog output is galvanically isolated from the rest of the electronic system. Jumper JP4 can be used to switch the analog output from an active power source (default) to a current sink, allowing the output to simulate a 4...20 mA, two-wire transmitter.




Figure 92: Current source




Figure 93: Current sink

Ground potential is the potential of the control unit and the auxiliary supply (see chapter 21.5).

21.5 Auxiliary voltage input and output

Input voltage range (auxiliary voltage input): 20...30 VDC
 Maximum current consumption (auxiliary voltage input): 500 mA
 Maximum current consumption in power-save mode 120 mA
 (auxiliary voltage input):
 Output voltage (auxiliary voltage output): typ. 23 V
 Maximum output current (auxiliary voltage output): 200 mA
 Resistance of common ground vs. earth: typ. 500 kΩ
 Resistance of common ground vs. earth (floating version): > 10 MΩ
 Capacitance of common ground vs. earth: typ. 100 nF
 Maximum allowed voltage of common ground vs. earth: max. 40 Vs
 Fuse (Fuse FL1, see picture 79, page 73): 1 A slow
 (Littelfuse 454 NANO² Slo-Blo[®])

Ground potential is the common ground of the controller and the analog inputs and outputs. The auxiliary voltage output can be set in menu P6.5 (see section 7.5, page 28).

The power-save mode is defined as follows:

- No power supply (the controller is powered exclusively through the 24 V auxiliary voltage input).
- The backlight of the LCD display switches off automatically.
- No additional hardware options included (Profibus Interface, DeviceNet interface, relay board, etc. ...).
- Binary outputs and the mA output are not enabled; when activating, the respective currents must be added to the total current consumption.

21.6 Connections

21.6.1 Connections for non explosion-proof version

Power/motor:	Industrial plug with 6 pins Screw connection 16 A, max. 2.5 mm ² , AWG14
Control signals:	Industrial plug with 24 pins Screw connection 16 A, max. 2.5 mm ² , AWG14

Optionally, contacts are available in crimp or cage clamp designs.

21.6.2 Connections for explosion-proof version

Power/motor:	terminals with screw connection 16 A, 0.5... 4 mm ² , AWG20... AWG12
Control signals:	terminals with screw connection 4 A, 0.5... 2.5 mm ² , AWG20... AWG14

21.7 Mode of operation CM

ON-OFF & INCHING operation		
CM03	CM06	CM12
S2 - 15 minutes acc. IEC 60034 or Class A and Class B acc. EN ISO 22153		
1,0 - 72 RPM	1,0 - 60 RPM	1,0 - 70 RPM
$M_{max} = 32 \text{ Nm}$	$M_{max} = 64 \text{ Nm}$	$M_{max} = 125 \text{ Nm}$
$M_{avg} = 16 \text{ Nm}$	$M_{avg} = 20 \text{ Nm}$	$M_{avg} = 40 \text{ Nm}$
Life time*		
10.000 cycles		

MODULATING operation		
CM03	CM06	CM12
S4 - 1.200 c/h - max. 50% DC acc. IEC 60034 or Class C acc. EN ISO 22153		S4 - 1200 c/h - max. 50% DC acc. IEC 60034 and Class C acc. EN ISO 22153
1,0 - 36 RPM	1,0 - 30 RPM	1,0 - 35 RPM
$M_{max} = 32 \text{ Nm}$	$M_{max} = 64 \text{ Nm}$	$M_{max} = 125 \text{ Nm}$
$M_{avg} = 16 \text{ Nm}$	$M_{avg} = 32 \text{ Nm}$	$M_{avg} = 64 \text{ Nm}$
Life time*		
1.800.000 starts		1.200.000 starts

CONTINUOUS MODULATING operation		
CM03	CM06	CM12
S9 - 1.800 c/h acc. IEC 60034		S9 - 1.800 c/h acc. IEC 60034 or Class D acc. EN ISO 22153
1,0 - 20 RPM	1,0 - 20 RPM	1,0 - 20 RPM
$M_{max} = 32 \text{ Nm}$	$M_{max} = 64 \text{ Nm}$	$M_{max} = 125 \text{ Nm}$
$M_{avg} = 10 \text{ Nm}$	$M_{avg} = 20 \text{ Nm}$	$M_{avg} = 40 \text{ Nm}$
Life time*		
10.000.000 starts		

*NOTE: life time is based on proper operation and maintenance according to SCHIEBEL operating manual

CYCLE = 25 turns in both directions with at least 30% of nominal torque and the ability to accept 100% of nominal torque for at least 10% of the stroke

START = movement of at least 1% of stroke in both directions with a load of minimum 30% of nominal torque

21.8 Miscellaneous

Ambient temperature:

non explosion-proof version:	-25 ... +60 °C
explosion-proof version:	-20 ... +40 °C (according EN 60079-0)
ex version with extended temperature range:	-40 ... +60 °C

Protection according to EN 60529: IP67

Standard colour: RAL7024

NOTE: If the actuator is exposed to excessive UV-light, colour deviations of the painting might occur.

22 Technical data CM03

The motor (brushless DC motor) is controlled via integrated power electronics, which also provide the supply voltage for the controller.

22.1 Standard version CM03

Output torque:	max. 32 Nm
Average permissible output torque:	max. 16 Nm
Setting range of tripping torque:	8 ... 32 Nm
Setting range of output speed:	1.0 ... 72.2 min ⁻¹
Travel range:	max. 100 revs / 1600 revs
Reduction ratio handwheel:	2,5
Output resolution:	about 0.25°
Supply voltage range AC:	100 ... 240 Vrms +/-10%, 50/60 Hz
Nominal current (16 Nm / 72,2 min ⁻¹):	1.47 A / 230 VAC
Idle power consumption:	12 W typ., 24 W max.
Weight:	11.5 daN

22.2 24 VDC version CM03

Output torque:	max. 32 Nm (BLDC version 200 or newer) max.: 10 Nm@20 min ⁻¹ /32 Nm@5 min ⁻¹ (BLDC version < 200)
Average permissible output torque:	max. 16 Nm
Setting range of tripping torque:	8 ... 32 Nm
Setting range of output speed:	1.0 ... 20 min ⁻¹
Supply voltage range:	24 VDC +/-10%
Nominal current (16Nm / 20U/min):	4.6 A
Idle power consumption:	6 W typ., 18 W max.

all other dates see output data - standard version

22.3 400 V version CM03

Output torque:	max. 32 Nm
Average permissible output torque:	max. 16 Nm
Setting range of tripping torque:	8 ... 32 Nm
Setting range of output speed:	1.0 ... 72.2 min ⁻¹
Travel range:	max. 100 revs / 1600 revs
Output resolution:	about 0.25°
Supply voltage range AC:	3 x 380... 480 VAC +/-10%, 50/60 Hz
Nominal current (16 Nm / 72.2 rpm):	0.46 A / 3 x 400 VAC
Weight:	11.5 daN

Idle power consumption is measured with an idle motor and is dependent on the existing hardware options.

23 Technical data CM06

The motor (brushless DC motor) is controlled via integrated power electronics, which also provide the supply voltage for the controller.

23.1 Standard version CM06

Output torque:	max. 64 Nm
Average permissible output torque:	max. 20 Nm
Setting range of tripping torque:	16 ... 64 Nm
Setting range of output speed:	1.0 ... 64 min ⁻¹
Travel range:	max. 100 revs / 300 revs / 1600 revs
Reduction ratio handwheel:	2,5
Output resolution:	about 0.25° / 0.75° / 0.25°
Supply voltage range AC:	100 ... 240 Vrms +/-10%, 50/60 Hz
Nominal current (20 Nm / 60min ⁻¹):	2.17 A / 230 VAC
Idle power consumption:	12 W typ., 24 W max.
Weight:	15.5 daN

23.2 400V version CM06

Output torque:	max. 64 Nm
Average permissible output torque:	max. 20 Nm
Setting range of tripping torque:	16 ... 64 Nm
Setting range of output speed:	1.5 ... 64 min ⁻¹
Travel range:	max. 100 revs / 300 revs / 1600 revs
Output resolution:	about 0.25° / 0.75° / 0.25°
Supply voltage range AC:	3 x 380... 480 VAC +/-10%, 50/60 Hz
Nominal current (32 Nm / 60min ⁻¹):	0.9 A / 3 x 400 VAC
Weight:	15.5 daN

Idle power consumption is measured with an idle motor and is dependent on the existing hardware options.

24 Technical data CM12

The motor (brushless DC motor) is controlled via integrated power electronics, which also provide the supply voltage for the controller.

24.1 Standard version CM12

Output torque:	max. 125 Nm
Average permissible output torque:	max. 40 Nm
Setting range of tripping torque:	32 ... 125 Nm
Setting range of output speed:	1.0 ... 70 min ⁻¹
Travel range:	max. 100 revs / 300 revs / 1600 revs
Reduction ratio handwheel:	2,5
Output resolution:	about 0.25° / 0.75° / 0.25°
Supply voltage range AC:	100 ... 240 Vrms +/-10%, 50/60 Hz
Nominal current (40 Nm / 70min ⁻¹):	3,8 A / 230 VAC
Idle power consumption:	12 W typ., 24 W max.
Weight:	22 daN

Idle power consumption is measured with an idle motor and is dependent on the existing hardware options.

25 Characteristic curves

25.1 Characteristic curves - CM03




Figure 94: Current draw of the standard version




Figure 95: Current draw of the 24 VDC version




Figure 96: Current draw of the standard version

25.2 Characteristic curves - CM06




Figure 97: Current draw of the standard version




Figure 98: Current draw of the standard version

25.3 Characteristic curves - CM12





Figure 99: Current draw of the standard version

Spare parts ACTUSMART (ex)(r)CM03.V1.2

SEC-SP-ENGLISH-CM03.V1.2-V1.01-2016.07.07



CAUTION: When ordering spare parts, you **must** provide the **serial number** (look type shield or status menu S6).

Use only original spare parts supplied by SCHIEBEL. Using other parts will render the warranty void. Illustrations may differ from actual spare parts.




Asm.	No.	Description
1		E-case
	1-1	Control unit cover
	1-2	Display circuit board
	1-3	Logic circuit board
	Fuse-F1	Micro fuse 1A
	Fuse-F2	Micro fuse 4A
	1-4	Expansion board (bus, relay)
	1-5	Multiturn sensor assembly
	1-5-1	Multiturn sensor
	1-6	BLDC
	Fuse-F3	Fuse 5AT (16AT for 24V actuators with BLDC version 200)
	1-7	Motor
	1-8-1	Sensor shaft
	1-8-2	Gear Z30
2		Mech. case
	2-1	Worm gear
	2-2	Output shaft
	2-3	Helical cut pinion gear
3		Handwheel assembly
	3-1	Handwheel
	3-2	Screw plug
4		Plug cover
	4-1	Plug frame customer side (socket)
	4-2	Plug frame actuator side (pins)
5		Terminal box cover
	5-1	Terminal block
6		Entire bus plug cover with plugs & circuit board
	6-1	Bus plug frame customer side (socket)
	6-2	Bus plug frame actuator side (pins)
	6-3	Bus connection board
7		Additional ring bus (Ex)
8		400V module
TS		Type plate

Asm.	No.	Description
20z1		Output form "A" assembly G0/F10
	2001	Threaded spindle nut
	2002	Flange "A"
	2003	Ring nut
	2004	Bearing assembly
21z1		Output form "B" assembly G0/F10
	2101	Std "B" socket
	2102	Std flange "B"
22z1		Output form "C" assembly G0/F10
	2201	Std claw coupling "C"
	2102	Std flange "B"
23z1		Std output form "D" assembly G0/F10
	2301	Output shaft D Ø20mm
	2402	Centering ring
24z1		Std output form "E" assembly G0/F10
	2401	Output shaft E Ø20mm
	2402	Centering ring

Spare parts ACTUSMART (ex)(r)CM06.V1.2

SEC-SP-ENGLISH-CM06.V1.2-V1.01-2016.07.07



CAUTION: When ordering spare parts, you **must** provide the **serial number** (look type shield or status menu S6).

Use only original spare parts supplied by SCHIEBEL. Using other parts will render the warranty void. Illustrations may differ from actual spare parts.




Asm.	No.	Description
1		E-case
	1-1	Control unit cover
	1-2	Display circuit board
	1-3	Logic circuit board
	Fuse-F1	Micro fuse 1A
	Fuse-F2	Micro fuse 4A
	1-4	Expansion board (bus, relay)
	1-5	Multiturn sensor assembly
	1-5-1	Multiturn sensor
	1-6	BLDC
	Fuse-F3	Fuse 5AT (16AT for 24V actuators with BLDC version 200)
	1-7	Motor
	1-8-1	Sensor shaft
	1-8-2	Gear
2		Mech. case
	2-1	Worm gear
	2-2	Output shaft
	2-3	Helical cut pinion gear
3		Handwheel assembly
	3-1	Handwheel
	3-2	Screw plug
4		Plug cover
	4-1	Plug frame customer side (socket)
	4-2	Plug frame actuator side (pins)
5		Terminal box cover
	5-1	Terminal block
6		Entire bus plug cover with plugs & circuit board
	6-1	Bus plug frame customer side (socket)
	6-2	Bus plug frame actuator side (pins)
	6-3	Bus connection board
7		Additional ring bus (Ex)
8		400V module
TS		Type plate

Asm.	No.	Description
20z1		Output form "A" assembly G0/F10
	2001	Threaded spindle nut
	2002	Flange "A"
	2003	Ring nut
	2004	Bearing assembly
21z1		Output form "B" assembly G0/F10
	2101	Std "B" socket
	2102	Std flange "B"
22z1		Output form "C" assembly G0/F10
	2201	Std claw coupling "C"
	2102	Std flange "B"
23z1		Std output form "D" assembly G0/F10
	2301	Output shaft D Ø20mm
	2402	Centering ring
24z1		Std output form "E" assembly G0/F10
	2401	Output shaft E Ø20mm
	2402	Centering ring

Spare parts ACTUSMART (ex)(r)CM12.V1.2

SEC-SP-ENGLISH-CM12.V1.2-V1.01-2016.07.07



CAUTION: When ordering spare parts, you **must** provide the **serial number** (look type shield or status menu S6).

Use only original spare parts supplied by SCHIEBEL. Using other parts will render the warranty void. Illustrations may differ from actual spare parts.



Asm.	No.	Description
1		E-case
	1-1	Control unit cover
	1-2	Display circuit board
	1-3	Logic circuit board
	Fuse-F1	Micro fuse 1A
	Fuse-F2	Micro fuse 4A
	1-4	Expansion board (bus, relay)
	1-5	Multiturn sensor assembly
	1-5-1	Multiturn sensor
	1-6	BLDC
	Fuse-F3	Fuse 10AT
	1-7	Motor
	1-8-1	Sensor shaft
	1-8-2	Gear
2		Mech. case
	2-1	Worm gear
	2-2	Output shaft
	2-3	Helical cut pinion gear
3		Handwheel assembly
	3-1	Handwheel
	3-2	Screw plug
4		Plug cover
	4-1	Plug frame customer side (socket)
	4-2	Plug frame actuator side (pins)
5		Terminal box cover
	5-1	Terminal block
6		Entire bus plug cover with plugs & circuit board
	6-1	Bus plug frame customer side (socket)
	6-2	Bus plug frame actuator side (pins)
	6-3	Bus connection board
7		Additional ring bus (Ex)
8		400V module
TS		Type plate

Asm.	No.	Description
20z1		Output form "A" assembly G0/F10
	2001	Threaded spindle nut
	2002	Flange "A"
	2003	Ring nut
	2004	Bearing assembly
	2005	Centering ring F10
21z1		Output form "B" assembly G0/F10
	2101	Std "B" socket
	2102	Std flange "B"
	2005	Centering ring F10
22z1		Output form "C" assembly G0/F10
	2201	Std claw coupling "C"
	2102	Std flange "B"
	2005	Centering ring F10
23z1		Std output form "D" assembly G0/F10
	2301	Output shaft D Ø20mm
	2302	Centering ring G0
24z1		Std output form "E" assembly G0/F10
	2401	Output shaft E Ø20mm
	2302	Centering ring G0

**schiebel
-actuators
.com**

SCHIEBEL

SCHIEBEL Antriebstechnik
Gesellschaft m.b.H.
Josef-Benc-Gasse 4
A-1230 Wien
Tel.: +43 1 66 108 - 0
Fax: +43 1 66 108 - 4
info@schiebel-actuators.com
www.schiebel-actuators.com